

[Manuals.plus](#) /

› [HANSA](#) /

› HANSA Scarlet Ibis 54 Plush Toy User Manual

HANSA BH8135

HANSA Scarlet Ibis 54 Plush Toy User Manual

Model: BH8135

INTRODUCTION

The HANSA Scarlet Ibis 54 plush toy (Model BH8135) is a meticulously crafted representation of the real Scarlet Ibis. HANSA, established in Australia in 1972, is renowned for creating realistic plush animals that appeal to both children and adults. Each HANSA product is designed with attention to detail, aiming to educate and inspire appreciation for the natural world.

This manual provides essential information regarding the care, handling, and specifications of your HANSA Scarlet Ibis plush toy.



Figure 1: The HANSA Scarlet Ibis 54 plush toy. This image shows the toy's vibrant red plumage, long curved black beak, and slender pink legs, accurately representing the real bird.

PRODUCT FEATURES

- **Product Type:** Realistic animal plush toy.
- **Animal:** Scarlet Ibis.
- **Realistic Design:** HANSA meticulously researches various organisms, focusing on animals inhabiting Earth, to reproduce plush toys with realistic details.
- **Quality Manufacturing:** All HANSA products are manufactured in their own 12,000 square meter factory in the Philippines, ensuring adherence to required quality standards without using subcontracted factories.
- **Environmental Conservation Philosophy:** HANSA's commitment to creating realistic plush toys stems from a philosophy of environmental preservation, aiming to educate future generations about the appearance and ecology of animals, and the impact of human activities like deforestation and environmental pollution on animal habitats.



Figure 2: A three-quarter view of the Scarlet Ibis plush toy, showcasing its realistic posture and detailed features.

SAFETY INFORMATION

Please read the following safety information carefully before using the product.

- **Paper Tag:** The product includes a paper tag. Please remove all tags and packaging materials before giving the product to a child.
- **Age Recommendation:** Manufacturer recommended age is 6 years and up.
- **Material Safety:** The main material is acrylic. All HANSA products undergo international inspection and are issued

inspection certificates for individual products to ensure safety.



Figure 3: A side profile of the Scarlet Ibis plush toy, illustrating its overall form and the placement of its legs.

SETUP

Your HANSA Scarlet Ibis plush toy comes ready for display or play. No assembly is required.

1. **Unpacking:** Carefully remove the plush toy from its packaging.
2. **Inspection:** Inspect the toy for any signs of damage or loose parts. If any issues are found, please contact customer support.
3. **Tag Removal:** Remove all attached paper tags and plastic fasteners before use, especially if the toy is intended for a child.

OPERATING

The HANSA Scarlet Ibis plush toy is designed for decorative purposes, collection, and gentle play.

- **Display:** Place the plush toy on a flat, stable surface where it can be admired. Its realistic design makes it an excellent addition to any room or office.
- **Collection:** This plush toy is part of a wide range of realistic animal creations by HANSA, making it a valuable

addition to any collection.

- **Gentle Play:** While durable, avoid rough handling to maintain the toy's appearance and integrity.



Figure 4: The Scarlet Ibis plush toy held by a person, illustrating its approximate size and how it can be comfortably handled.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your HANSA Scarlet Ibis plush toy, follow these care instructions:

- **Spot Cleaning:** For minor dirt or stains, gently spot clean with a damp cloth and mild soap. Do not immerse the entire toy in water.
- **Drying:** Allow the toy to air dry completely. Do not use a machine dryer or direct heat, as this may damage the material.
- **Brushing:** Gently brush the plush fur with a soft brush to maintain its texture and appearance.
- **Storage:** Store the toy in a clean, dry place away from direct sunlight to prevent fading and material degradation.



Figure 5: A close-up view of the soft, red plush material, demonstrating the quality and texture of the toy's fabric.

TROUBLESHOOTING

Most issues with plush toys are minor and can be resolved with simple care.

Problem	Solution
Plush fur appears matted or flattened.	Gently brush the fur with a soft-bristled brush. You can also lightly fluff the stuffing by hand.
Minor surface dirt.	Spot clean with a damp cloth and a small amount of mild soap. Blot dry with a clean towel.
Toy loses its shape slightly.	Gently reshape the toy by hand. HANSA toys are designed to hold their form, but minor adjustments may be needed over time.

SPECIFICATIONS

Attribute	Detail
Model Number	BH8135
Quantity	1
Batteries Required	No
Main Material	Acrylic
Target Gender	Unisex
Manufacturer Recommended Age	6 years and up
Product Dimensions	56 x 18 x 48 cm; 630 g (approximately 22 x 7 x 19 inches; 1.4 lbs)
ASIN	B08TQM111K
First Available Date	January 22, 2021

WARRANTY AND SUPPORT

HANSA is committed to producing high-quality, realistic plush toys. All products undergo rigorous quality control and are certified by international inspection agencies.

While specific warranty details are not provided in this manual, HANSA stands by the craftsmanship of its products. For any inquiries, concerns, or support needs regarding your HANSA Scarlet Ibis plush toy, please refer to the contact information provided on the product packaging or visit the official HANSA website.

Your satisfaction and the enjoyment of your HANSA product are important to us.

© 2024 HANSA. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.