

[Manuals.plus](#) /

› [Domo](#) /

› Domo DO719BL Soup Maker Blender - Instruction Manual

Domo DO719BL

Domo DO719BL Soup Maker Blender - Instruction Manual

Model: DO719BL | Capacity: 1.7 Liters | 6 Programs

1. INTRODUCTION

Thank you for purchasing the Domo DO719BL Soup Maker Blender. This appliance is designed to simplify your cooking process, allowing you to prepare a variety of dishes, from smooth soups to chunky stews, jams, and juices, with ease. Please read this instruction manual carefully before first use to ensure safe and optimal operation. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury. Please observe the following:

- Read all instructions before use.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for anything other than its intended use.

- Exercise extreme caution when handling the sharp blades and emptying the jug.
- Ensure the lid is securely locked in place before operating the appliance.

3. PRODUCT OVERVIEW

The Domo DO719BL is a versatile soup maker and blender featuring a durable stainless steel jug and an intuitive control panel. It is designed for efficient and convenient food preparation.

Key Features:

- **Capacity:** 1.7 Liters
- **Material:** Stainless Steel Jug
- **Programs:** 6 pre-set functions for various preparations
- **Memory Function:** 2-minute memory function
- **Audible Signal:** Final sound signal upon program completion



Image 1: The Domo DO719BL Soup Maker Blender, showcasing its stainless steel jug, red lid, and integrated handle. The control panel is visible on the top of the handle.

4. SETUP

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, clean the jug, lid, and accessories as described in the 'Maintenance and Cleaning' section.
3. **Placement:** Place the soup maker on a stable, flat, heat-resistant surface, away from the edge of the countertop. Ensure there is adequate ventilation around the appliance.
4. **Power Connection:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before plugging it in.

5. OPERATING INSTRUCTIONS

The Domo DO719BL features 6 pre-set programs for various cooking and blending tasks. Always ensure ingredients do not exceed the MAX fill line (1700ml) and are above the MIN fill line (1300ml) for optimal performance, especially for heating functions.

General Operation:

1. Add your desired ingredients into the stainless steel jug.
2. Securely place the lid on the jug, ensuring it is properly aligned and locked.
3. Plug the appliance into a suitable power outlet.
4. Select the desired program using the control panel buttons.
5. Press the Start/Stop button to begin the program.
6. The appliance will emit a final sound signal when the program is complete.
7. Unplug the appliance and carefully pour out the contents.

Program Descriptions:

- **Smooth:** This program is ideal for preparing creamy soups, purees, and sauces. It involves heating and blending cycles to achieve a smooth consistency.
- **Chunky:** Use this program for soups with larger pieces of vegetables or meat. It heats the ingredients without extensive blending, preserving texture.
- **Jam:** Specifically designed for making homemade jams and fruit compotes. This program manages heating and stirring to achieve the correct consistency.
- **Juice:** This program blends fruits and vegetables into fresh juices or smoothies. It primarily focuses on blending without heating.
- **Reheat:** Use this function to warm up pre-made soups or other liquid dishes. It heats the contents to a serving temperature without further cooking.
- **Blend/Clean:** This program offers manual blending control for desired consistency or can be used for initial cleaning of the jug.

Memory Function:

The appliance features a 2-minute memory function. If the lid is briefly removed during a program, the program will pause. If the lid is replaced within 2 minutes, the program will resume from where it left off. If the lid is off for longer than 2 minutes, the program will reset.



Image 2: The Domo DO719BL Soup Maker Blender positioned on a kitchen counter, surrounded by various prepared dishes such as a bowl of smooth soup, a bowl of chunky salad, and glasses of blended juice, illustrating its versatility.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your Domo DO719BL Soup Maker Blender.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Cool Down:** Allow the appliance to cool down completely before cleaning, especially after heating programs.
3. **Jug Cleaning:** For easy cleaning, add a small amount of water and a drop of dish soap to the jug. Select the 'Blend/Clean' program for a short cycle, then rinse thoroughly. Alternatively, wash the inside of the jug with warm soapy water and a non-abrasive sponge. Be extremely careful around the sharp blades.
4. **Lid and Accessories:** Wash the lid and any removable accessories in warm soapy water. Rinse and dry thoroughly.
5. **Exterior:** Wipe the exterior of the motor unit with a damp cloth. Do not immerse the motor unit in water.
6. **Storage:** Store the appliance in a dry place when not in use.

7. TROUBLESHOOTING

If you encounter issues with your Domo DO719BL, please refer to the following common problems and solutions:

- **Appliance does not start:**
 - Ensure the appliance is properly plugged into a working power outlet.
 - Check that the lid is securely placed and locked onto the jug.

- Verify that a program has been selected and the Start/Stop button has been pressed.

- **Poor blending results:**

- Ensure ingredients are cut into appropriate sizes for blending.
- Do not overfill the jug; stay below the MAX line.
- Add sufficient liquid to facilitate blending.
- Use the 'Blend/Clean' program for manual blending if a pre-set program does not achieve the desired consistency.

- **Heating function not working:**

- Ensure the liquid level is above the MIN fill line.
- Confirm that a heating program (Smooth, Chunky, Jam, Reheat) has been selected.

If the problem persists after checking these points, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	Domo
Model Number	DO719BL
Capacity	1.7 Liters
Voltage	230 Volts
Material	Stainless Steel
Item Weight	2.68 Kilograms
Features	Programmable, 2-minute memory function, Final sound signal

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Domo website. Keep your proof of purchase for any warranty claims.

© 2023 Domo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08TRH2SH3>

More documents and user manuals: **<https://manuals.plus/>**