Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arzum OK002B-US

ARZUM Okka Automatic Turkish Coffee Machine User Manual

Model: OK002B-US

1. Introduction

The Arzum Okka Automatic Turkish Coffee Machine is designed to brew authentic Turkish/Greek coffee with ease and consistency. It automatically prepares and pours coffee directly into your cup(s) with perfect foam and ideal taste. Featuring a "Slow Brew" function for a traditional experience and a self-cleaning mechanism, the Arzum Okka simplifies the art of Turkish coffee preparation.



Figure 1: Arzum Okka Automatic Turkish Coffee Machine in black, brewing two cups of Turkish coffee.

2. Safety Instructions

- Always ensure the machine is placed on a stable, level surface away from heat sources.
- Do not immerse the main unit in water or any other liquid.

- Unplug the machine from the power outlet before cleaning or when not in use.
- Exercise caution when handling hot liquids and surfaces. The brewing chamber and coffee will be hot after brewing.
- Keep out of reach of children and pets.
- Use only with 120V power outlets, as specified for the USA model.
- Do not operate the machine if the power cord or plug is damaged.



Figure 2: Side view of the Arzum Okka machine, highlighting its compact design.

3. Product Overview

Familiarize yourself with the main components of your Arzum Okka coffee machine:

- **Main Unit:** The primary body of the coffee machine.
- **Brewing Chamber:** Where coffee and water are combined and brewed.
- **Water Tank:** Removable tank for water supply.
- **Waste Water Grid:** Collects excess water or spills.
- **Measuring Spoon:** Included for precise coffee measurement.



Figure 3: Front view of the machine.



Figure 4: Removable water tank.



Figure 5: Waste water grid.



Figure 6: Included measuring spoon.

4. Setup

1. **Unpack:** Carefully remove all packaging materials and ensure all components are present.
2. **Initial Cleaning:** Before first use, clean the brewing chamber, water tank, and waste water grid with warm soapy water. Rinse thoroughly and dry.
3. **Fill Water Tank:** Remove the water tank from the back of the machine. Fill it with fresh, cold drinking water up to the MAX line. Place it back securely.
4. **Place Brewing Chamber:** Ensure the brewing chamber is correctly seated in its designated slot.
5. **Power Connection:** Plug the machine into a grounded 120V power outlet.
6. **Adjust Waste Water Grid:** The waste water grid can be adjusted for different cup heights. For shorter cups, remove the grid and place it directly on the base. For taller cups, keep the grid in its raised position.

Your browser does not support the video tag.

Video 1: This video demonstrates the setup process, including filling the water chamber, using the on/off button, and adjusting the waste water grid for different cup sizes (0:08 - 0:37).

5. Operating Instructions

The Arzum Okka offers options for single or double cup brewing, and a slow brew function for enhanced flavor.

5.1. Single Cup Brewing

1. Open the lid of the brewing chamber.
2. Add one level measuring spoon of Turkish coffee into the brewing chamber.
3. If desired, add sugar according to your preference.
4. Place a single Turkish coffee cup under the dispenser.
5. Press the "Single Cup" button. The machine will automatically brew and dispense the coffee.

Your browser does not support the video tag.

Video 2: This video illustrates the single cup brewing process, including adding coffee and sugar, and pressing the single cup button (0:42 - 1:20).

5.2. Double Cup Brewing

1. Open the lid of the brewing chamber.
2. Add two level measuring spoons of Turkish coffee into the brewing chamber.
3. If desired, add sugar according to your preference.
4. Place two Turkish coffee cups under the dispensers.
5. Press the "Double Cup" button. The machine will automatically brew and dispense coffee into both cups.

Your browser does not support the video tag.

Video 3: This video demonstrates the double cup brewing process, including adding coffee and sugar, and pressing the double cup button (1:24 - 2:10).

5.3. Slow Brewing Function

The slow brewing function extends the brewing time to approximately 5-6 minutes, offering a richer, more traditional Turkish coffee taste.

- Follow steps 1-4 for either single or double cup brewing.

- Instead of the regular brew button, press the "Slow Brew" button (indicated by a flame icon).
- The machine will brew the coffee slowly, enhancing its flavor profile.

Your browser does not support the video tag.

Video 4: This video shows how to activate the slow brewing function for both single and double cups (2:14 - 2:41).

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your Arzum Okka machine.

6.1. Self-Cleaning Function

- Ensure the water tank is filled.
- Press the "Self-Cleaning" button (indicated by a shower icon). The machine will perform an automatic cleaning cycle.

Your browser does not support the video tag.

Video 5: This video demonstrates the self-cleaning function (2:45 - 3:00).

6.2. Detailed Cleaning

1. Unplug the machine and allow it to cool completely.
2. Remove the waste water grid and empty the waste water chamber. Clean both with warm soapy water and rinse.
3. Remove the brewing chamber. Disassemble the chamber ring and clean all parts with warm soapy water. Use a soft brush if necessary to remove coffee residue. Rinse thoroughly and dry.
4. Wipe the exterior of the machine with a damp cloth. Do not use abrasive cleaners.
5. Reassemble all parts once dry.

Your browser does not support the video tag.

Video 6: This video provides instructions for detailed cleaning of the waste water chamber and brewing chamber (3:01 - 3:24).

7. Troubleshooting

If you encounter issues with your Arzum Okka, refer to the following common problems and solutions:

Problem Indicator (Light)	Possible Cause	Solution
Top light blinking	Empty or misplaced water chamber.	Ensure the water tank is filled with water and correctly seated.
Middle light blinking	Misplaced chamber ring.	Check that the brewing chamber ring is properly installed and secured.
Bottom light blinking	Full or misplaced waste water chamber.	Empty the waste water chamber and ensure it is correctly placed.

Your browser does not support the video tag.

Video 7: This video explains the warning signs indicated by the machine's lights and their corresponding solutions (3:25 - 3:45).

8. Specifications

Feature	Detail
Brand	Arzum
Model Name	Okka (OK002B-US)
Color	Black
Product Dimensions	10"D x 8"W x 12"H
Item Weight	7 pounds
Voltage	110 Volts
Coffee Maker Type	Turkish Coffee Machine
Operation Mode	Fully Automatic
Special Feature	DIRECT-TO-CUP serve
Filter Type	Reusable
Included Components	Measuring Spoon, User Manual, Quick Start Guide
Certifications	UL-approved

9. Warranty and Support

The Arzum Okka Automatic Turkish Coffee Machine is UL-approved, ensuring compliance with safety standards. For specific warranty details and customer support, please refer to the warranty card included with your product or contact Arzum customer service directly. Contact information can typically be found on the manufacturer's official website or in the Quick Start Guide.



Figure 7: UL certification mark.

© 2024 Arzum. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08TRNXF2S

More documents and user manuals: **https://manuals.plus/**