

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Air Wick](#) /

› [Air Wick Essential Mist Diffuser Instruction Manual](#)

### Air Wick 6233802318

# Air Wick Essential Mist Diffuser Instruction Manual

Model: 6233802318

Brand: Air Wick

## INTRODUCTION

---

The Air Wick Essential Mist Diffuser transforms fragrances infused with natural essential oils into a gentle mist, enhancing the ambiance of your home. Its portable and cordless design allows for flexible placement in any room. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your diffuser.



Figure 1: Air Wick Essential Mist Diffuser and its packaging.

## SAFETY INFORMATION

---

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Do not ingest essential oils. If swallowed, seek medical attention immediately.

## COMPONENTS

---

The Air Wick Essential Mist Diffuser typically includes the following components:

- Diffuser Unit (main device)
- Fragrance Refill (sold separately or included in starter kits)
- AA Batteries (usually 3, may be included)

# AN EASY WAY TO EXPERIENCE Irresistible Aromas



ADJUSTABLE



CORDLESS &  
PORTABLE



WATERLESS



READY TO USE



LONG-LASTING  
FRAGRANCE



QUIET

\*Per refill based on low setting

Figure 2: Key features of the Air Wick Essential Mist Diffuser, including its adjustable settings, cordless design, and long-lasting fragrance.

## SETUP INSTRUCTIONS

Follow these steps to set up your Air Wick Essential Mist Diffuser:

1. **Insert Batteries:** Open the bottom compartment of the diffuser unit. Insert 3 AA batteries, ensuring correct polarity.
2. **Insert Fragrance Refill:** Remove the cap from your chosen Air Wick Essential Mist fragrance refill. Insert the refill into the diffuser unit until it clicks into place. Ensure it is securely seated.
3. **Close Compartment:** Close the bottom compartment securely.
4. **Placement:** Place the device in your desired room. Its cordless design allows for placement anywhere without needing to be near an outlet.

Your browser does not support the video tag.

Video 1: A product overview video demonstrating the setup and use of the Air Wick Essential Mist Diffuser, including battery and refill insertion.



Figure 3: The diffuser producing an automatic, gentle mist, highlighting its battery-operated nature.

## OPERATING INSTRUCTIONS

---

The Air Wick Essential Mist Diffuser is designed for ease of use with adjustable settings:

- **Initial Boost:** Upon activation, the gadget provides a 2X initial fragrance boost to quickly fill the room.
- **Operating Cycle:** The device will then run for an 8-hour cycle, releasing mist regularly. After 8 hours, it will go into standby mode for 16 hours.
- **Adjustable Settings:** Use the control switch on the side of the device to select your preferred fragrance intensity. There are multiple settings (Low, Medium, High) to control the burst duration and pause time between bursts.

### Fragrance Burst and Pause Duration Settings

Setting	Burst Duration	Pause Duration
Low	4 seconds	17 minutes
Medium	5 seconds	12 minutes
High	6 seconds	10 minutes



Figure 4: The diffuser's control panel showing the adjustable settings for fragrance intensity.



Figure 5: Diagram illustrating the 8-hour ON and 16-hour OFF operating cycle, along with burst and pause durations for different settings.

**MAINTENANCE**

To ensure the longevity and optimal performance of your diffuser:

- **Refill Replacement:** Each refill provides up to 45 days of fragrance based on the low setting. Replace the refill when the fragrance diminishes or the bottle is empty. No need to add water.
- **Battery Replacement:** Replace batteries when the device stops misting or the light indicator (if present) signals low power.
- **Cleaning:** Periodically wipe the exterior of the diffuser with a soft, damp cloth. Do not submerge the device in water.



Figure 6: Illustration showing that refills are ready to use and can last up to 45 days on a low setting.

## TROUBLESHOOTING

---

If your Air Wick Essential Mist Diffuser is not functioning as expected, try the following solutions:

- **No Mist/No Scent:**
  - Check if batteries are correctly inserted and have sufficient charge. Replace if necessary.
  - Ensure the fragrance refill is properly seated and clicked into place.
  - Verify that the device is turned ON and the setting is not set to OFF.
  - The device operates on an 8-hour ON, 16-hour OFF cycle. If it's in the 16-hour standby period, it will not mist.
  - The refill might be empty. Replace with a new one.
- **Weak Scent:**
  - Adjust the setting to a higher intensity (Medium or High).
  - Ensure the room size is appropriate for the diffuser's output (suitable for medium to large rooms).
  - Consider replacing the refill if it has been in use for an extended period, as fragrance intensity can decrease over time.
- **Device Not Turning On:**
  - Check battery installation and replace batteries.
  - Ensure the power switch is in the ON position.

## SPECIFICATIONS

---

Feature	Detail
---------	--------

Feature	Detail
Product Dimensions	4.19 x 3.16 x 6.38 inches
Item Weight	7.05 ounces
Item Model Number	6233802318
Power Source	Battery Powered (3 AA batteries)
Scent	Gadget (device only, various refills available)
Color	Black
Operating Cycle	8 hours ON, 16 hours OFF
Refill Longevity	Up to 45 days (on low setting)

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or to purchase additional fragrance refills, please visit the official Air Wick website or contact their customer service. Keep your proof of purchase for any warranty claims.

Visit the [Air Wick Store on Amazon](#) for more products and information.