

[Manuals.plus](#) /

› [Gabby's Dollhouse](#) /

› Gabby's Dollhouse Purrfect Dollhouse Instruction Manual

Gabby's Dollhouse 6062028

Gabby's Dollhouse Purrfect Dollhouse Instruction Manual

Brand: Gabby's Dollhouse | **Model:** 6062028

1. PRODUCT OVERVIEW

The Gabby's Dollhouse Purrfect Dollhouse is an interactive playset designed for imaginative play. Standing over 2 feet tall, it features multiple levels and rooms, offering a comprehensive dollhouse experience. This set includes key characters and accessories to begin play immediately.




Figure 1.1: The Gabby's Purrfect Dollhouse, showcasing its open design and included accessories, along with the product packaging.

2. WHAT'S INCLUDED

Your Gabby's Purrfect Dollhouse package contains the following components:

- 1 Dollhouse
- 1 Gabby Girl Figure
- 1 Pandi Paws Figure
- 8 Furniture Pieces
- 2 Dollhouse Deliveries
- 3 Accessories
- 1 Instruction Sheet



15 DOLLHOUSE ACCESSORIES

Figure 2.1: A visual representation of all 15 accessories included with the dollhouse, neatly arranged.

3. FEATURES

The Purrfect Dollhouse offers several interactive features:

- **Over 2 Feet Tall:** The dollhouse is designed to be a prominent play structure, mirroring the one from the show.
- **Elevator and Delivery Tower:** Navigate between 4 floors and 7 rooms using the Cat-A-Vator. Drop deliveries into the tower for surprise accessories.
- **15 Pieces Included:** Comes with Gabby and Pandy Paws figures, furniture, and accessories for immediate play.
- **Sounds and Phrases:** Press the button on the front of the dollhouse to activate songs, sounds, and phrases from the show.
- **Expandable Design:** Additional themed rooms (sold separately) can be integrated into the dollhouse walls.



8 SOUNDS & PHRASES

Figure 3.1: A child demonstrating the sound and phrase feature of the dollhouse, which includes 8 unique sounds and phrases.



DOLLHOUSE DELIVERY TOWER

Figure 3.2: Detail of the Dollhouse Delivery Tower, where small accessories can be dropped and retrieved.



Figure 3.3: The Cat-A-Vator in action, allowing figures to move between different floors of the dollhouse.

4. SETUP

The Gabby's Purrfect Dollhouse requires some assembly before play. Follow these steps:

1. Unpack all components from the box.
2. Refer to the included instruction sheet for detailed assembly diagrams.
3. Assemble the main dollhouse structure, ensuring all connections are secure.
4. Attach the Dollhouse Delivery tower and Cat-A-Vator according to the instructions.
5. Insert 3 AAA batteries into the designated battery compartment to enable sounds and phrases. Ensure correct polarity.
6. Place the furniture pieces and accessories in their respective rooms or as desired for play.



STANDS 2-FEET TALL!

Figure 4.1: The dollhouse stands approximately 2 feet tall when fully assembled and closed.

5. OPERATING INSTRUCTIONS

To maximize your play experience with the Purrfect Dollhouse:

- **Dollhouse Delivery:** Place a Dollhouse Delivery capsule into the top of the tower and press the button to send it down. Open the capsule to reveal a surprise accessory.
- **Cat-A-Vator:** Place a figure inside the Cat-A-Vator and slide it up or down to move between the different floors of the dollhouse.
- **Sounds and Phrases:** Locate the button on the front of the dollhouse (often integrated into the design) and press it to activate various songs, sounds, and character phrases.
- **Interactive Furniture:** Explore furniture pieces like the kitchen table that can be flipped to change from breakfast to dinner settings.
- **Room Backdrops:** Discover hidden surprises or interactive elements on the backdrops of each room.
- **App Integration:** Scan the QR code found inside one of the Dollhouse Deliveries to unlock special rewards within the free Gabby's Dollhouse App (available on iOS and Android).



UNBOX DOLLHOUSE DELIVERIES

Figure 5.1: QR codes located on the Dollhouse Deliveries, which can be scanned to unlock digital content in the Gabby's Dollhouse App.

6. MAINTENANCE

To ensure the longevity of your Gabby's Purrfect Dollhouse:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Do not submerge the dollhouse or its electronic components in water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, the dollhouse can be closed for compact storage. Store in a dry, cool place away from direct sunlight.
- **Battery Replacement:** If sounds and phrases become faint or stop working, replace the 3 AAA batteries. Ensure the battery compartment is securely closed after replacement.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sounds or phrases	Batteries are dead or incorrectly installed.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Cat-A-Vator not moving smoothly	Obstruction in the track or mechanism.	Check for any small objects or debris in the elevator track. Ensure the elevator is properly aligned.
Dollhouse Delivery tower not functioning	Obstruction or incorrect placement of delivery capsule.	Ensure the delivery capsule is correctly inserted and there are no blockages in the tower.
Parts do not fit during assembly	Incorrect orientation or missing steps.	Review the instruction sheet carefully, paying attention to part orientation and sequence. Do not force parts.

8. SPECIFICATIONS

- **Product Dimensions:** 17 x 5.38 x 22.13 inches
- **Item Weight:** 7.04 pounds
- **Country of Origin:** China
- **Item Model Number:** 6062028
- **Manufacturer Recommended Age:** 3 years and up
- **Batteries:** 3 AAA batteries required (not included)
- **Release Date:** July 15, 2021
- **Manufacturer:** Spin Master

9. WARRANTY AND SUPPORT

This product is covered by the Spin Master Care Commitment. For full details regarding warranty, returns, or customer support, please refer to the official Spin Master website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Spin Master

For additional information or to explore other products, visit the official [Gabby's Dollhouse Store](#).

© 2024 Gabby's Dollhouse. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question