

Manuals.plus /

› Rowenta /

› Rowenta Pedestal Fan VU5840F0 User Manual

Rowenta VU5840F0

Rowenta Pedestal Fan User Manual

Model: VU5840F0 | Brand: Rowenta

1. PRODUCT OVERVIEW

The Rowenta Pedestal Fan VU5840F0 is a compact and powerful fan designed to provide optimal cooling and comfort. It features a 40 cm diameter and an adjustable height ranging from 103 cm to 145 cm, making it versatile for various room settings. Equipped with 5 blades and an integrated ergonomic handle, it is easy to transport and position.

This fan offers 4 speed settings, including an extra silent night mode operating at just 38 dB(A) for undisturbed sleep, and a powerful Turbo Boost mode for maximum airflow up to 80 m³/min. Its automatic oscillation feature provides wide air diffusion across a 120° angle, ensuring efficient cooling throughout your space. For enhanced safety, the fan includes a reinforced grille, preventing accidental contact with the blades.



Figure 1: Rowenta Pedestal Fan VU5840F0, a compact and powerful cooling solution.

2. SETUP AND ASSEMBLY

Your Rowenta Pedestal Fan requires minimal assembly before first use. Please follow these steps carefully:

1. **Base Assembly:** Attach the fan base to the main pole. Ensure it is securely fastened using the provided screws. A small screwdriver may be required.
2. **Height Adjustment:** Extend the telescopic pole to your desired height (between 103 cm and 145 cm) and secure it using the height adjustment knob or clamp.
3. **Fan Head Attachment:** Carefully attach the fan head assembly to the top of the main pole. Ensure all locking mechanisms are engaged to prevent the head from detaching during operation.
4. **Grille Installation:** Ensure the front and rear grilles are properly aligned and secured. The reinforced grille is designed for child safety.
5. **Power Connection:** Plug the 1.5-meter power cable into a suitable electrical outlet.



Figure 2: The fan is designed to blend seamlessly into various home environments.

3. OPERATING INSTRUCTIONS

The Rowenta Pedestal Fan offers intuitive controls for customized cooling.

Power On/Off and Speed Control:

Locate the control knob on the fan's main body. Rotate the knob to turn the fan on and select your desired speed setting. The fan features 4 distinct speeds:

- **Speed 0:** Off
- **Speed 1 (Silent Night Mode):** Provides a gentle breeze at a very low noise level (38 dB(A)), ideal for sleeping.
- **Speed 2:** Moderate airflow for general cooling.
- **Speed 3:** Stronger airflow for more intense cooling.
- **Speed 4 (Turbo Boost):** Maximum power for rapid and powerful air circulation (up to 80 m³/min).

Oscillation Function:

To activate the automatic oscillation, press the oscillation button located on the control panel. The fan head will automatically sweep up to a 120° angle, distributing air widely across the room. Press the button again to stop oscillation at a fixed position.



Figure 3: Detailed view of the control panel with speed knob and oscillation button.



Figure 4: The silent night mode ensures peaceful sleep while providing comfortable airflow.



High Airflow



Silent Operation



Automatic Oscillation

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Rowenta Pedestal Fan.

- **Cleaning the Grille and Blades:** Periodically wipe down the exterior of the fan, including the grilles, with a soft, damp cloth. For deeper cleaning, ensure the fan is unplugged. The grilles can be removed (refer to assembly instructions in reverse) to access the blades for cleaning. Use a soft brush or cloth to remove dust and debris from the blades.
- **Motor Housing:** Do not attempt to open the motor housing. Cleaning should be limited to the exterior surfaces.
- **Storage:** When not in use for extended periods, store the fan in a dry, dust-free environment.
- **Safety Grille:** Always ensure the reinforced safety grille is properly installed before operating the fan, especially in households with children.

5. TROUBLESHOOTING

If you encounter any issues with your Rowenta Pedestal Fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; Fan not plugged in; Power outlet faulty.	Ensure the fan is securely plugged into a working electrical outlet. Check the circuit breaker.
Low airflow.	Incorrect speed setting; Dust accumulation on blades/grille.	Increase the speed setting. Clean the fan blades and grilles as per maintenance instructions.
Excessive noise.	Fan not on a stable surface; Loose parts; Dust/debris in motor.	Place the fan on a flat, stable surface. Check for any loose components and tighten if necessary. Clean the fan thoroughly. If noise persists, contact customer support. Note that higher speeds will naturally produce more sound.
Oscillation not working.	Oscillation button not pressed; Obstruction.	Press the oscillation button firmly. Ensure there are no obstructions preventing the fan head from rotating.

6. SPECIFICATIONS

Feature	Detail
Brand	Rowenta
Model Number	VU5840F0
Color	Multicolor
Product Dimensions (L x W x H)	43 x 45.3 x 132 cm
Product Weight	7.84 kg
Power	70 Watts
Voltage	220 Volts
Noise Level	38 dB (Silent Night Mode)
Airflow	Up to 80 m ³ /min (Turbo Boost)
Speeds	4 (including Silent Night and Turbo Boost)
Oscillation Angle	Up to 120° automatic
Cable Length	1.5 m
Special Features	Portable, Adjustable Height, Reinforced Grille for Child Safety

7. WARRANTY AND SUPPORT

Rowenta is committed to providing high-quality products and excellent customer service. This product is designed for durability and ease of repair.

Rowenta offers a commitment to **15-year reparability at a fair price**, with access to 6200 authorized repair centers worldwide. This initiative underscores Rowenta's dedication to product longevity and reducing environmental impact.

For any questions, technical assistance, or to locate an authorized repair center, please visit the official Rowenta website or contact their customer support line. Keep your purchase receipt as proof of purchase for any warranty claims or service requests.

For more information, you can visit the [Rowenta Brand Store on Amazon](#).