

[Manuals.plus](#) /

› [Bombay Shaving Company](#) /

› [Bombay Shaving Company Cordless Beard Trimmer BEARD\\_CARE\\_BT1199\\_STYLING\\_KIT User Manual](#)

## Bombay Shaving Company BEARD\_CARE\_BT1199\_STYLING\_KIT

# Bombay Shaving Company Cordless Beard Trimmer User Manual

Model: BEARD\_CARE\_BT1199\_STYLING\_KIT

## 1. INTRODUCTION AND OVERVIEW

This manual provides essential instructions for the safe and effective use of your Bombay Shaving Company Cordless Beard Trimmer. This grooming kit includes a cordless beard trimmer with 20 length settings, beard shampoo and conditioner, beard softener, and a magnetic opener. Please read all instructions carefully before first use and retain this manual for future reference.

## 2. WHAT'S IN THE BOX

Your Bombay Shaving Company grooming kit includes the following components:

- Cordless Beard Trimmer
- Beard Shampoo and Conditioner
- Beard Softener (45 gm)
- Magnetic Bottle Opener
- Charger

## What's in the box?



Beard Trimmer

Beard Softner

Magnetic Opener

Beard Shampoo & Conditioner

Image: Contents of the Bombay Shaving Company Beard Care All-Rounder Kit.

### 3. SETUP

#### 3.1 Charging the Trimmer

1. Ensure the trimmer is switched off before charging.
2. Connect the charger to the trimmer's charging port.
3. Plug the charger into a suitable power outlet.
4. The indicator light will show the charging status. The trimmer features flash charging for quick power-ups.
5. Once fully charged, disconnect the charger.

#### 3.2 Attaching and Adjusting the Comb

1. Ensure the trimmer is switched off.
2. Align the comb attachment with the trimmer head and gently push until it clicks into place.
3. Rotate the adjustment dial on the trimmer to select your desired beard length from the 20 available settings.




Image: Cordless Beard Trimmer showing the 20-style length settings dial.

## 4. OPERATING INSTRUCTIONS

### 4.1 Trimmer Operation

1. After selecting your desired length setting, press the power button to turn on the trimmer.
2. Hold the trimmer with the blades facing your beard.
3. Move the trimmer against the direction of hair growth for an even trim.
4. For detailed styling, use a mirror and ensure good lighting.
5. After use, press the power button to turn off the trimmer.

### 4.2 Using Beard Shampoo & Conditioner

The antibacterial beard wash and conditioner cleanses and softens your beard while retaining natural skin oils. It contains Coconut oil, Glycerine, Wheat Protein, Vitamin E, and Aloe vera extracts.

1. Wet your beard thoroughly with warm water.
2. Dispense a small amount of beard shampoo and conditioner into your palm.
3. Massage it into your beard and the skin underneath, creating a lather.

4. Rinse thoroughly with water until all product is removed.

### 4.3 Using Beard Softener

The wood-scented beard softener, infused with olive and keratin, helps to soften and tame unruly whiskers, providing moderate hold for styling.

1. After washing and towel-drying your beard, take a small amount of beard softener.
2. Rub it between your palms to warm and distribute evenly.
3. Apply to your beard, working from the roots to the tips.
4. Style your beard as desired.



Image: Beard Shampoo & Conditioner for cleansing and hydrating, and Beard Softener for taming whiskers.

## 5. MAINTENANCE

### 5.1 Cleaning the Trimmer

1. Ensure the trimmer is switched off and unplugged from the charger.
2. Remove the comb attachment.

3. Use the provided cleaning brush to remove hair clippings from the blades and inside the trimmer head.
4. For thorough cleaning, the stainless steel blades can be rinsed under running water. Ensure the trimmer body remains dry.
5. Allow all parts to air dry completely before reassembling or storing.

## 5.2 Storage

Store the trimmer and accessories in a cool, dry place, away from direct sunlight and moisture. Keep out of reach of children.

## 5.3 Battery Care

To prolong battery life, avoid fully discharging the Lithium-Ion battery frequently. Charge the trimmer regularly, even if not in constant use.

## 6. TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the trimmer is fully charged. Check if the power button is pressed firmly.
- **Trimmer not charging:** Verify that the charger is properly connected to both the trimmer and the power outlet. Check the power outlet for functionality.
- **Poor trimming performance:** Clean the blades thoroughly to remove any accumulated hair. Ensure the comb attachment is correctly seated. The blades may require oiling (if specified in separate product documentation, not included here).
- **Blade becoming loose:** If the blade head becomes loose after use, ensure it is securely reattached. If the issue persists, contact customer support.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	BEARD_CARE_BT1199_STYLING_KIT
Product Dimensions	20 x 15 x 5 cm
Item Weight	300 g
Power Source	Battery Powered
Battery Type	Lithium-Ion
Blade Material	Stainless Steel
Length Settings	20
Manufacturer	Visage Lines Personal care Private Limited

## 8. WARRANTY AND SUPPORT

For warranty information, product support, or service inquiries, please contact Visage Lines Personal care Private Limited, the manufacturer. Refer to your purchase documentation for specific warranty terms and contact details.

Manufacturer Contact Information: Visage Lines Personal care Private Limited, F-213-B, First Floor, Old M.B. Road, Lado Sarai, Delhi-110030, India.

© 2024 Bombay Shaving Company. All rights reserved.