



Manuals.plus /

- › [Lenovo](#) /
- › [Lenovo HT18 TWS Headphones User Manual](#)

## Lenovo HT18

# Lenovo HT18 TWS Headphones User Manual

Model: HT18

## 1. INTRODUCTION

---

This manual provides comprehensive instructions for the Lenovo HT18 True Wireless Stereo (TWS) Headphones. Please read this manual carefully before using your headphones to ensure proper operation and to maximize your listening experience. Keep this manual for future reference.



Image 1.1: Lenovo HT18 TWS Headphones in their charging case with earbuds removed.

## 2. PACKAGE CONTENTS

---

Ensure all items are present in the package:

- Lenovo HT18 TWS Headphones (Left and Right earbuds)
- Charging Case
- User Manual

## 3. SETUP AND INITIAL USE

---

### 3.1. Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case. Place the earbuds into the charging case. Connect the charging case to a power source using a compatible USB cable (not specified if included, typically USB-C or Micro-USB). The charging case has a 1000mAh battery capacity.

# Stay Immersed with The Powerhouse



1000mAh  
Massive Charging Bin

120Hrs  
Standby Time

50Hrs  
Music Time

Image 3.1: Illustration of the 1000mAh charging case capacity, 120 hours standby time, and 50 hours music time.

## 3.2. Pairing with a Device

1. Ensure the headphones are charged.
2. Open the charging case and remove both earbuds. They will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "Lenovo HT18" from the list.
5. Once connected, a voice prompt will confirm successful pairing.

The headphones support wireless Bluetooth connectivity and are compatible with smartphones, tablets, laptops, desktops, and game consoles.

## 4. OPERATING INSTRUCTIONS

### 4.1. Touch Controls

The Lenovo HT18 headphones feature intuitive touch controls on each earbud for various functions:

# Intuitive, Elegant-Intelligent One-button Control



Image 4.1: Visual guide to touch controls for play/pause, next/previous song, voice assistant, and call management.

- **Single Tap:** Play/Pause music.
- **Double Tap (Right Earbud):** Next Song.
- **Double Tap (Left Earbud):** Previous Song.
- **Tap and Hold (Right Earbud):** Activate Voice Assistant.
- **Tap and Hold (Left Earbud):** Answer/Reject Call.

## 4.2. Audio Experience

The HT18 headphones are designed for music listening and calls. They feature echo cancellation for clearer communication.

# Hear What You Desire

Advanced Noise Reduction  
Cancels Ambient Noise and Let You Enjoy  
Rich, Premium and Detailed Sound



Astounding | Amenable | Abiding

Image 4.2: Illustration depicting advanced noise reduction for an enhanced listening experience.

## 5. MAINTENANCE AND CARE

---

### 5.1. Cleaning

Regularly clean your headphones and charging case to maintain optimal performance and hygiene. Use a soft, dry, lint-free cloth. Do not use abrasive cleaners or immerse the headphones in water, as they are not waterproof.

### 5.2. Storage

When not in use, store the headphones in their charging case to protect them from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Headphones not pairing	Bluetooth off on device, headphones not in pairing mode, out of range.	Ensure Bluetooth is on. Place headphones in case, then remove to re-enter pairing mode. Move closer to the device.
No sound	Volume too low, not connected, media paused.	Increase device volume. Check Bluetooth connection. Ensure media is playing.
Earbuds not charging	Poor contact in case, charging cable issue, case battery low.	Ensure earbuds are correctly seated. Check charging cable and power source. Charge the case.
Poor call quality	Weak signal, environmental noise.	Move to an area with better signal. Reduce background noise.

## 7. SPECIFICATIONS

---

- **Model Name:** HT18
- **Brand:** Lenovo
- **Color:** Black
- **Connectivity Technology:** Wireless (Bluetooth)
- **Ear Placement:** In-Ear
- **Form Factor:** In-Ear
- **Control Type:** Touch Control
- **Special Features:** Echo Cancellation
- **Impedance:** 32 ohms
- **Material:** Silicone, Plastic
- **Item Weight:** 100 Grams
- **Water Resistance Level:** Not Waterproof
- **Rechargeable Battery:** Yes
- **Charging Case Capacity:** 1000mAh (approx.)
- **Music Playback Time:** Up to 50 hours (with charging case)
- **Standby Time:** Up to 120 hours (with charging case)

## 8. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation provided at the time of purchase or visit the official Lenovo support website. Specific details regarding spare parts availability and software updates are not available in this manual.

For further assistance, please contact your retailer or Lenovo customer service.