

[Manuals.plus](#) /

› [Ascher](#) /

› Ascher 6-Light LED Track Lighting Kit (Model Y9164-6) Instruction Manual

Ascher Y9164-6

Ascher 6-Light LED Track Lighting Kit

Model: Y9164-6

Brand: Ascher

1. INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Ascher 6-Light LED Track Lighting Kit. This modern ceiling spotlight features a matte nickel finish and includes six GU10 LED bulbs, offering flexible illumination for various indoor spaces.



Image 1.1: Ascher 6-Light LED Track Lighting Kit overview.

Key Features:

- **Modern Stylish Design:** High-quality metal with matte nickel finish, resistant to fading and corrosion.
- **Multi-angle Illumination:** Six light heads and two lamp arms are adjustable. Light heads rotate 360° horizontally and 90° vertically for wide lighting angles.
- **Included LED Bulbs:** Comes with 6 x 4W GU10 LED bulbs (non-dimmable), providing 400 LM light output at 5000K Daylight White with CRI ≥ 80.
- **Easy Installation:** Includes all necessary mounting hardware and a canopy mounting plate. Suitable for sloped or vaulted ceilings.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or other hazards that could cause injury or property damage.

- **WARNING:** Always turn off the power at the main circuit breaker or fuse box before installing or servicing this fixture.
- Consult a qualified electrician if you are unsure about the installation process or electrical wiring.
- This fixture is intended for indoor use only.
- Do not attempt to modify the fixture or its components.
- Ensure all electrical connections are secure and comply with local codes and ordinances.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- 1 x Ascher 6-Light LED Track Lighting Fixture
- 6 x GU10 LED Bulbs (4W, 400LM, 5000K Daylight White)
- 1 x Mounting Hardware Kit (screws, wire nuts, etc.)
- 1 x Canopy Mounting Plate
- 1 x Hex Tool (for arm adjustment)

4. INSTALLATION INSTRUCTIONS

4.1 Pre-Installation

1. **Turn off Power:** Locate the circuit breaker that supplies power to the light fixture location and turn it off. Verify power is off using a voltage tester.
2. **Prepare Mounting Surface:** Ensure the ceiling or wall surface is clean, dry, and structurally sound to support the fixture's weight.

4.2 Mounting the Fixture

1. Attach the canopy mounting plate to the electrical junction box using the provided screws. Ensure it is securely fastened.
2. Carefully feed the electrical wires from the junction box through the center hole of the canopy mounting plate.

4.3 Wiring Connections

Connect the wires according to standard electrical codes. If you are unfamiliar with electrical wiring, consult a professional electrician.

- Connect the **black (hot)** wire from the fixture to the **black (hot)** wire from the junction box using a wire nut.
- Connect the **white (neutral)** wire from the fixture to the **white (neutral)** wire from the junction box using a wire nut.
- Connect the **copper (ground)** wire from the fixture to the **green or bare copper (ground)** wire from the junction box using a wire nut.

Once wired, carefully tuck all wires into the junction box.

4.4 Securing the Fixture

1. Align the fixture's canopy with the mounting plate and secure it using the provided screws.

4.5 Bulb Installation

The fixture uses GU10 LED bulbs.

1. Insert the two prongs of the GU10 bulb into the socket.
2. Gently push and twist the bulb approximately a quarter turn clockwise until it locks into place.

Easy & Quick to Replace Bulbs



Image 4.1: Installing a GU10 LED bulb.




Image 4.2: Fixture dimensions and bulb details (Beam Angle 120°, Daylight White 5000K).

After all bulbs are installed, restore power at the circuit breaker.

5. OPERATION

The Ascher 6-Light LED Track Lighting Kit offers versatile lighting control through its adjustable arms and light heads.

5.1 Adjusting Light Heads

Each individual light head can be rotated 360° horizontally and tilted 90° vertically. This allows you to direct light precisely where needed.

5.2 Adjusting Lamp Arms

The two main lamp arms are also adjustable. Use the included hex tool to loosen the joints, position the arms as desired, and then tighten the joints to secure them.



Image 5.1: Adjusting light heads and lamp arms.

6. MAINTENANCE

6.1 Cleaning

To clean the fixture, ensure the power is off. Wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents as they may damage the finish.

6.2 Bulb Replacement

If a bulb needs replacement:

1. Turn off power to the fixture at the circuit breaker.
2. Allow the bulb to cool completely if it has been recently in use.
3. Gently push the GU10 bulb into its socket and twist counter-clockwise to release it.
4. Insert a new GU10 LED bulb (4W, 5000K recommended) by pushing and twisting clockwise until secure.

5. Restore power at the circuit breaker.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture	Check circuit breaker, wall switch, and wiring connections.
Bulb not working	Bulb is loose or faulty	Ensure bulb is securely twisted into the socket. Replace with a new GU10 LED bulb if necessary.
Flickering lights	Loose wiring or incompatible dimmer (fixture is non-dimmable)	Check wiring connections. Ensure the fixture is not connected to a dimmer switch.

8. SPECIFICATIONS

Attribute	Detail
Brand	Ascher
Model Number	Y9164-6
Color	Matt Nickel
Material	Metal
Style	Modern
Light Fixture Form	Ceiling
Indoor/Outdoor Usage	Indoor
Power Source	AC
Installation Type	Semi Flush Mount
Special Feature	Non-dimmable
Light Source Type	LED
Finish Type	Matte Nickel, Metal
Number of Light Sources	6
Voltage	120 Volts
Light Color	Daylight White (5000K)
Bulb Base	GU10
Wattage (per bulb)	4 watts

Attribute	Detail
Brightness (per bulb)	400 Lumens
Item Weight	2.89 Pounds
Package Dimensions	16.67 x 5.1 x 4.49 inches

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Ascher customer service directly. Refer to the product packaging or the official Ascher website for contact details.

10. APPLICATION EXAMPLES

The versatile design of this track lighting kit makes it suitable for various indoor settings, providing focused or ambient illumination as needed.



Image 10.1: Living room application.



Image 10.2: Dining room application.




Image 10.3: Bedroom application.

© 2023 Ascher. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question