

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Glacier Bay](#) /

› [Glacier Bay All-in-One Drop-In Stainless Steel 32-inch 4-Hole Single Bowl Kitchen Sink User Manual](#)

Glacier Bay All-in-One Drop-In Stainless Steel 32 in. 4-Hole Single Bowl Kitchen Sink

Glacier Bay All-in-One Drop-In Stainless Steel 32-inch 4-Hole Single Bowl Kitchen Sink User Manual

Model: All-in-One Drop-In Stainless Steel 32 in. 4-Hole Single Bowl Kitchen Sink

1. INTRODUCTION AND OVERVIEW

This manual provides instructions for the installation, operation, and maintenance of your Glacier Bay All-in-One Drop-In Stainless Steel 32-inch 4-Hole Single Bowl Kitchen Sink. This workstation sink is designed for efficiency and durability, featuring a single-tier track for integrated accessories and constructed from high-quality stainless steel.

The sink includes a comprehensive set of accessories to enhance kitchen tasks, such as food preparation and cleanup. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product.

2. SAFETY INFORMATION

- Always wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all water supply lines are turned off before beginning any plumbing work.
- If you are unsure about any installation steps, consult a qualified plumber or professional installer.
- Do not use harsh chemicals or abrasive cleaners on the sink surface, as this can damage the finish.
- Keep small children away from the work area during installation.

3. PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before beginning installation:

- Stainless Steel Sink
- Bamboo Cutting Board

- Deep Stainless Steel Colander
- Dish-Drying Roll-Up Rack
- Bottom Rinse Grid
- Strainer Drain Assembly
- Cutout Template
- Mounting Clips
- Installation Manual (this document)
- Pull-Down Kitchen Faucet (solid 304 stainless steel, lead-free)



Image 1: All components of the Glacier Bay All-in-One Drop-In Stainless Steel Kitchen Sink, including the sink, cutting board, colander, roll-up rack, drain, and pull-down faucet.

4. SPECIFICATIONS

Feature	Detail
Brand	Glacier Bay
Material	18 Gauge Premium T-304 Grade Stainless Steel (18/10 Chromium/Nickel)
Finish Type	Brushed
Color	Stainless Steel
Overall Dimensions	32 x 18 x 8 inches (Length x Width x Depth)
Installation Type	Drop-In
Hole Count	4 (for faucet and accessories)
Drain Type	Standard 3.5" drain opening (Pop-Up)
Sound Insulation	Heavy duty SOUND GUARD UNDERCOATING and THICK RUBBER PADDING
Weight	Approximately 61 pounds

5. INSTALLATION

This section outlines the general steps for installing your drop-in kitchen sink and faucet. Refer to the included **Cutout Template** for precise countertop opening dimensions.

1. **Prepare Countertop:** Using the provided cutout template, mark and cut the opening in your

countertop. Ensure the edges are smooth and clean.

2. **Install Faucet and Accessories:** Before placing the sink into the countertop, install the pull-down faucet and any other desired accessories (e.g., soap dispenser, air gap) into the pre-drilled 4 holes on the sink deck. Follow the individual instructions provided with the faucet for proper installation.
3. **Apply Sealant:** Apply a bead of silicone sealant around the perimeter of the sink opening on the countertop.
4. **Position Sink:** Carefully lower the sink into the countertop opening, ensuring it is centered and level. Press down firmly to create a seal with the silicone.
5. **Secure Sink:** Attach the mounting clips to the underside of the sink rim and tighten them against the countertop to secure the sink in place.
6. **Connect Plumbing:** Connect the faucet's water supply lines to the hot and cold water valves. Install the strainer drain assembly and connect it to the P-trap and waste line. Ensure all connections are tight to prevent leaks.
7. **Test for Leaks:** Turn on the water supply and check all connections for leaks. Run water through the faucet and into the drain to verify proper function.



Image 2: The Glacier Bay workstation sink installed in a countertop, demonstrating the use of the bamboo cutting board and roll-up drying rack on the integrated track.

6. OPERATION

6.1 Faucet Operation

- The pull-down kitchen faucet features a single handle for controlling both water temperature and flow.
- The spout offers 360° rotation for extended reach and flexibility.
- The spray head has a dual-function spray pattern. Press the button on the spray head to switch between stream and spray modes.
- To use the pull-down feature, simply pull the spray head from the spout. It will retract

automatically when released.

6.2 Workstation Accessories

The sink's single-tier track allows for convenient use of the included accessories:

- **Bamboo Cutting Board:** Place the cutting board on the track to create an instant workspace over the sink for food preparation.
- **Stainless Steel Colander:** The deep colander can be placed on the track for rinsing fruits, vegetables, or draining pasta directly over the sink.
- **Roll-Up Rack:** Use the dish-drying roll-up rack on the track for air-drying dishes, glasses, or produce. It can be easily rolled up and stored when not in use.

7. MAINTENANCE AND CARE

7.1 Stainless Steel Sink Care

- **Daily Cleaning:** Wipe the sink surface with a soft, dry cloth after each use to prevent water spots and mineral buildup.
- **Regular Cleaning:** For general cleaning, use a mild dish soap and warm water with a soft cloth or sponge. Rinse thoroughly and dry.
- **Avoid Abrasives:** Do not use abrasive cleaners, steel wool, or scouring pads, as these can scratch the brushed finish.
- **Prevent Stains:** Avoid leaving acidic foods (e.g., citrus, tomatoes) or harsh chemicals in contact with the sink for extended periods. Rinse immediately if contact occurs.
- **Rust Prevention:** While stainless steel is highly resistant to rust, prolonged exposure to certain chemicals or metallic objects can cause surface rust. Remove any rust spots promptly with a non-abrasive stainless steel cleaner.

7.2 Accessory Care

- **Bamboo Cutting Board:** Hand wash with mild soap and water. Do not soak. Dry immediately. Periodically treat with food-grade mineral oil to maintain its condition.
- **Stainless Steel Colander & Roll-Up Rack:** These can be washed with mild dish soap and water or placed in a dishwasher. Ensure they are dry before storing.

8. TROUBLESHOOTING

- **Slow Drainage:** Check the strainer drain for food debris or blockages. Ensure the P-trap is clear.
- **Leaks Around Sink Rim:** This may indicate an improper seal during installation. Re-tighten mounting clips or reapply silicone sealant if necessary.
- **Faucet Drips or Leaks:** Check connections to water supply lines. If dripping from the spout, the internal cartridge may need inspection or replacement. Consult a plumber.
- **Water Spots on Sink:** These are typically mineral deposits. Use a solution of vinegar and water, then rinse and dry thoroughly.



9. WARRANTY AND SUPPORT

For warranty information regarding your Glacier Bay All-in-One Drop-In Stainless Steel Kitchen

Sink, please refer to the warranty documentation provided at the time of purchase or visit the official Glacier Bay website.

If you require technical assistance or have questions not covered in this manual, please contact Glacier Bay customer support.

Related Documents - All-in-One Drop-In Stainless Steel 32 in. 4-Hole Single Bowl Kitchen Sink

	<p><u>Glacier Bay Stainless Steel Single Bowl Kitchen Sink Use and Care Guide</u></p> <p>This guide provides essential information for the installation, use, care, and warranty of your Glacier Bay Stainless Steel Single Bowl Kitchen Sink. Learn how to properly install, maintain, and clean your sink for lasting performance.</p>
	<p><u>Glacier Bay Stainless Steel Kitchen Sink Use and Care Guide</u></p> <p>Comprehensive guide for installing, caring for, and troubleshooting your Glacier Bay stainless steel kitchen sink. Includes topmount and undermount installation instructions, maintenance tips, and parts lists.</p>
	<p><u>Glacier Bay Fireclay Kitchen Sink Use and Care Guide</u></p> <p>Comprehensive use and care guide for Glacier Bay fireclay kitchen sinks, including installation, maintenance, and cleaning instructions. Covers models 2ACLB-00-001 and 2ACLB-01-001.</p>
	<p><u>Glacier Bay Market Pull-Out Kitchen Faucet Replacement Parts List</u></p> <p>Detailed replacement parts list for the Glacier Bay Market Pull-Out Kitchen Faucet in Stainless Steel (Model HD67737-1208D2), including part numbers, SKUs, and purchase information.</p>
	<p><u>Glacier Bay 2-Handle Kitchen Faucet Replacement Parts List</u></p> <p>Detailed replacement parts list for the Glacier Bay 2-Handle Standard Kitchen Faucet with Side Sprayer (Model HD67794-1008D2), including part numbers and SKUs. Find replacement parts at HomeDepot.com or call 1-855-HD-GLACIER.</p>



[Glacier Bay All-in-One Laundry Sink Cabinet Use and Care Guide](#)

Comprehensive use and care guide for the Glacier Bay All-in-One Laundry Sink Cabinet, including assembly instructions, warranty information, and maintenance tips. Model numbers: 24101-LC20, 24101-LC24, 24101-LC28.