

[Manuals.plus](#) /

› [Timex](#) /

› Timex Women's Easy Reader 25mm Watch Instruction Manual

Timex TW2U791009J

Timex Women's Easy Reader 25mm Watch

Model: TW2U791009J

INTRODUCTION

This manual provides instructions for the Timex Women's Easy Reader 25mm Watch. This timepiece is designed for clear readability and comfortable wear, featuring a classic design with modern functionality.



Figure 1: Front view of the Timex Women's Easy Reader 25mm Watch with two-tone expansion band and white dial.

Key Features:

- **Easy to Read Dial:** White dial with full Arabic numerals and a date window at 3 o'clock.
- **Comfortable Expansion Band:** Two-tone 12mm stainless steel expansion band, designed for a 6-to-7.5-inch wrist circumference.
- **INDIGLO Backlight:** Electroluminescent backlight for visibility in low-light conditions.
- **Durable Construction:** Two-tone 25mm brass case with a mineral glass crystal.
- **Water Resistance:** Water resistant to 30 meters.

SETUP

1. Setting Time and Date

1. Pull the crown (located on the side of the watch case) out to the outermost position.
2. Turn the crown clockwise or counter-clockwise to set the correct time. Ensure AM/PM is correctly set if your watch has a 24-hour indicator or date changes at midnight.
3. Push the crown back in to the middle position to set the date. Turn the crown until the correct date appears in the date window.

4. Once time and date are set, push the crown fully back into the watch case to start the watch movement.



Figure 2: Side view of the watch, highlighting the crown used for setting time and date.

2. Band Adjustment

The Timex Easy Reader features an expansion band designed to fit a range of wrist sizes (6 to 7.5 inches). No tools are typically required for initial fitting as the band stretches to accommodate your wrist. If further adjustment (e.g., link removal) is needed, it is recommended to consult a professional jeweler.

Your browser does not support the video tag.

Video 1: Official Timex Sizing Chart video, demonstrating how different case sizes appear on wrists. This video helps visualize watch size on the wrist.

OPERATING INSTRUCTIONS

1. Using the INDIGLO Night-Light

To activate the INDIGLO night-light, simply press and hold the crown (the button on the side of the watch case). The entire dial will illuminate, allowing you to read the time in the dark. Release the crown to turn off the light.

Your browser does not support the video tag.

Video 2: Official Timex video showcasing the Easy Reader Women's watch, including a demonstration of the INDIGLO backlight feature.

2. Water Resistance

Your Timex Easy Reader watch is water resistant to 30 meters (100 feet). This means it is suitable for splashes, rain, and brief immersion in water, such as hand washing. It is **not** suitable for swimming, showering, or diving. Do not press any buttons or operate the crown while the watch is wet or submerged.




Figure 3: Timex water resistance chart, illustrating appropriate water exposure levels for different watch ratings. This watch is rated for 30 meters.

MAINTENANCE

1. Battery Replacement

The watch is powered by one Lithium Metal battery (included). The battery life is approximately up to 10 years. When the watch stops running or the INDIGLO light dims significantly, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.






Figure 4: Back view of the watch, showing the stainless steel case back where the battery is accessed.

2. Cleaning

To clean your watch, wipe the case and band with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. For the expansion band, ensure no debris is caught between the links.

TROUBLESHOOTING

- **Watch not running:** Ensure the crown is fully pushed in. If it is, the battery may need replacement.
- **INDIGLO not working:** Check if the crown is fully pushed in. If it is, the battery may be low or depleted.
- **Date not changing:** Ensure the time is set correctly for AM/PM. The date typically changes around midnight.

SPECIFICATIONS

Feature	Specification
Model Number	TW2U791009J
Case Diameter	25 Millimeters
Case Material	Brass
Band Material	Stainless Steel
Band Width	12 Millimeters
Band Length	7.5 Inches (fits 6-7.5 inch wrist)
Dial Color	White
Crystal Material	Mineral
Movement Type	Quartz
Water Resistance Depth	30 Meters (100 Feet)
Battery Type	1 Lithium Metal (included)
Special Features	INDIGLO Night-Light

WARRANTY AND SUPPORT

Warranty Information

This Timex watch comes with a Manufacturer's Warranty. For specific details regarding coverage, duration, and terms, please refer to the warranty card included with your purchase or visit the official Timex website.

Customer Support

For further assistance, troubleshooting, or service inquiries, please visit the official Timex website or contact their customer support directly. You can find contact information and FAQs on their website: www.timex.com

