

Abramtek M8

Abramtek M8 Portable Wireless Speaker User Manual

Model: M8

PRODUCT OVERVIEW

The Abramtek M8 is a powerful and portable wireless speaker designed to deliver high-quality audio with deep bass and clear highs. Featuring Bluetooth connectivity, microphone input, and True Wireless Stereo (TWS) pairing, it is suitable for various indoor and outdoor audio needs.



Image: Front view of the Abramtek M8 Portable Wireless Speaker, showcasing its retro green design and prominent speaker grille.

Key features include independent bass control, 60W output, and multiple playing modes (Bluetooth, AUX, USB, Microphone Input). Its compact design makes it easy to transport, while the robust build ensures durability.



Image: Rear view of the Abramtek M8 speaker, highlighting the various input ports including Bluetooth, Microphone Input, AUX, and USB.

PACKAGE CONTENTS

Upon unboxing your Abramtek M8 speaker, please ensure all the following items are present:

- Abramtek M8 Portable Wireless Speaker
- USB-C Charging Cable
- Auxiliary Audio Cable
- User Manual (this document)
- Wired Microphone (if included with your specific package)



Image: Contents of the Abramtek M8 speaker package, including the speaker, cables, and a microphone.

SETUP GUIDE

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included). The charging indicator light will show the charging status and turn off when fully charged. A full charge may take several hours.



Image: Illustration indicating the 5000mAh battery capacity of the Abramtek M8 speaker.

2. Powering On/Off

Press and hold the power button located on the control panel to turn the speaker on or off. A sound prompt will indicate the power status.



Image: Close-up view of the control knobs on the Abramtek M8 speaker, including the power button, mode selection, and bass control.

3. Bluetooth Pairing

1. Turn on the Abramtek M8 speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "ABRAMTEK M8" from the list of devices.
4. Once connected, the speaker will emit a confirmation sound, and the LED light will become solid.



Image: Diagram illustrating the internal Bluetooth chip within the Abramtek M8 speaker, signifying its wireless capabilities.

4. True Wireless Stereo (TWS) Pairing

To achieve a wider stereo soundstage, you can pair two Abramtek M8 speakers together:

1. Ensure both M8 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, double-press the Bluetooth button (often indicated by a 'BT' icon or similar). It will enter TWS pairing mode.
3. The speakers will automatically search for and connect to each other. A voice prompt will confirm "Left Channel" and "Right Channel" once paired.
4. Once TWS paired, connect your device to one of the speakers via Bluetooth as described in step 3. Both speakers will now play audio in stereo.

60X2 WATTS

Pair 2 speakers to enjoy
true wireless stereo sound



Image: Two Abramtek M8 speakers positioned to illustrate True Wireless Stereo (TWS) pairing, creating a 120-watt stereo sound experience.



Image: A desktop setup featuring two Abramtek M8 speakers, demonstrating their use for left and right channel true wireless surround sound.

OPERATING INSTRUCTIONS

1. Adjusting Volume

Rotate the main volume knob (often the largest knob) clockwise to increase volume and counter-clockwise to decrease it.

2. Bass Control

The Abramtek M8 features an independent bass control knob. Rotate this knob to adjust the bass intensity to your preference. This allows for optimization of bass performance based on your audio content and environment.



Image: The Abramtek M8 speaker with "Bass Control" prominently displayed, indicating the ability to customize sound output.

3. Switching Playback Modes

The M8 speaker supports multiple input modes: Bluetooth, AUX, USB, and Microphone Input. Use the mode selection button (often labeled with icons for BT, AUX, USB, Mic) to cycle through the available modes.

- **Bluetooth Mode:** For wireless audio streaming from your paired device.
- **AUX Mode:** Connect an external audio source using the 3.5mm auxiliary cable.
- **USB Mode:** Play audio files directly from a USB flash drive inserted into the USB port.
- **Microphone Input:** Connect a wired or wireless microphone for karaoke, public speaking, or other vocal applications.



Image: The Abramtek M8 speaker shown with a microphone connected, illustrating its microphone input capability.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Abramtek M8 speaker.

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the speaker frequently. Recharge it regularly, even if not in constant use.
- **Water Resistance:** The speaker is not waterproof. Avoid exposing it to water, rain, or excessive moisture.

TROUBLESHOOTING

If you encounter issues with your Abramtek M8 speaker, refer to the following common solutions:

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect it to a power source and try again.
No sound from the speaker.	Check the volume level on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, AUX, USB) is selected.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode. Turn off and on Bluetooth on your device. Move the speaker closer to your device. Disconnect from other Bluetooth devices.
TWS pairing fails.	Ensure both M8 speakers are not connected to any other Bluetooth device. Try resetting both speakers and attempting TWS pairing again.
Microphone not working.	Ensure the microphone is properly connected to the correct input port. Check the microphone's power (if applicable) and volume settings. Ensure the speaker is in Microphone Input mode.
Sound quality is poor.	Adjust the bass control knob. Ensure the audio source is of good quality. For Bluetooth, reduce interference by moving away from other wireless devices.

If the problem persists after trying these solutions, please contact Abramtek customer support.

SPECIFICATIONS

Feature	Detail
Model Name	M8
Brand	Abramtek
Speaker Maximum Output Power	60 Watts (120 Watts with TWS pairing)
Connectivity Technology	Bluetooth, Auxiliary (3.5mm), USB
Audio Output Mode	Surround (Stereo with TWS)
Special Features	Independent Bass Control, Microphone Input, True Wireless Stereo (TWS) Pairing
Recommended Uses	Outdoor, Multimedia, Karaoke, Party, Meeting, Fitness, School Teaching
Compatible Devices	Laptop, Gaming Console, Television, Tablet, Home Theater, Smartphone, Karaoke Machine
Batteries	1 Lithium Ion battery (included)
Product Dimensions	12.7 x 8 x 10.69 cm
Weight	900 g



Image: Diagram showing the dimensions of the Abramtek M8 speaker: 12.7cm (length), 8cm (width), and 10.69cm (height).



Image: Cutaway diagram of the Abramtek M8 speaker, illustrating its 60-watt full-range drivers and internal acoustic design for space-filling sound.

WARRANTY AND SUPPORT

Abramtek products are manufactured to high quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Abramtek website. For technical support or service inquiries, please contact Abramtek customer service through their official channels.

Manufacturer: Abramtek

ASIN: B08V1897PV