

[Manuals.plus](#) /

› [VAYDEER](#) /

› VAYDEER USB Mouse Jiggler (Model FM7011) Instruction Manual

VAYDEER FM7011

VAYDEER USB Mouse Jiggler (Model FM7011)

Instruction Manual

INTRODUCTION

The VAYDEER USB Mouse Jiggler is a compact and undetectable device designed to simulate mouse movement, preventing your computer from entering sleep mode or locking. It features three distinct movement modes, an easy-to-use ON/OFF button, and plug-and-play functionality for broad compatibility across various operating systems.

100% Indétectable

Il est reconnu comme un \ "périphérique composite USB \"



Setting up device
Setting up "USB Composite Device"



11:00 AM
6/21/2021



Indétectable



Aucun logiciel



Sécurité

The VAYDEER USB Mouse Jiggler is recognized as a standard mouse, ensuring 100% undetectability by IT systems.

SETUP

The VAYDEER USB Mouse Jiggler is designed for simple plug-and-play operation, requiring no driver installation.

1. **Connect the Device:** Insert the VAYDEER USB Mouse Jiggler into an available USB port on your computer.
2. **Automatic Recognition:** Your computer will automatically recognize the device as a standard mouse.

One-Click ON/OFF & Easier to Use

Step 01

Connect the device to the computer.



Step 02

Short press the button to turn the device ON/OFF. When on, the indicator lights up.



Step 03

Long press the button to choose among 3 jiggler modes.



Step-by-step guide for connecting the device to your computer.


The device features an ON/OFF button and three distinct jiggle modes to suit your needs.

1. **Power ON/OFF:** Short press the button on the device to turn it ON or OFF. The indicator light will illuminate when the device is active.
2. **Changing Modes:** Long press the button for approximately 3 seconds to cycle through the three available jiggle modes. The device has a memory function and will resume the last selected mode upon activation.

Jiggler Modes:

- **Mode 1: Small Random Movement** - The mouse cursor performs small, subtle, random movements.
- **Mode 2: Large Random Movement** - The mouse cursor performs larger, more noticeable random movements.
- **Mode 3: Continuous Jiggle Movement** - The mouse cursor performs a continuous, uninterrupted jiggle movement.

3 modes de jigglers optionnels



Mode 1

Petit aléatoire
mouvement



Mode 2

Large aléatoire
mouvement



Mode 3

Mouvement de jiggle
n'interrompt pas votre utilisation normale
de la souris

Visual representation of the three distinct jigglers movement modes.

VAYDEER

Nouvelle version améliorée

1 Matériau métallique

Plus stable et durable

2 Plus facile à utiliser



Appui court

- MARCHE/ARRÊT



Appui long pendant 3 s -
Changer de piste (3 options)



Detailed view of the device's button functionality for power and mode selection.

MAINTENANCE

To ensure the longevity and optimal performance of your VAYDEER USB Mouse Jiggler, follow these simple maintenance guidelines:

- Keep the device clean and dry. Use a soft, dry cloth to wipe away dust or debris.
- Avoid exposing the device to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or modify the device, as this will void the warranty.
- Store the device in a safe place when not in use to prevent physical damage.

TROUBLESHOOTING

If you encounter any issues with your VAYDEER USB Mouse Jiggler, please refer to the following common solutions:

Problem	Solution
Device not recognized by computer.	Ensure the device is fully inserted into a functional USB port. Try a different USB port or connect it to another computer to verify functionality.
Mouse cursor is not moving.	Verify that the device is powered ON (indicator light should be active). Short press the button to toggle power. Long press the button to cycle through the three juggler modes.
Computer still enters sleep mode or locks.	Check your computer's power management settings to ensure they are not set to override the juggler's function. Some corporate IT policies may have strict sleep or lock settings that cannot be bypassed by external devices.
Indicator light is off, but device is plugged in.	Short press the button to turn the device on. If it still doesn't light up, try a different USB port or contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	VAYDEER
Model Name	FM7011
Connectivity Technology	USB
Special Feature	3 adjustable movement modes, ON/OFF button
Motion Detection Technology	Optical
Number of Buttons	1 (for power and mode selection)
Hand Orientation	Ambidextrous
Recommended Uses	Office, Remote Work
Compatible Operating Systems	Windows (7/8/10), Mac OS, Linux
Compatible Devices	Computers, Laptops, USB Hubs
Power Source	USB Powered (Corded Electric)
Item Dimensions (L x W)	9 cm x 1.9 cm

Feature	Detail
Internal Material	ABS
What's in the Box	1x VAYDEER USB Mouse Jiggler

Grande compatibilité



Logiciel

Microsoft Teams / Zoom / Slack / Skype
Webex / Outlook / Lync / etc



Systèmes

Windows / Mac OS / Android
/ Linux / Unix / Chrome OS



Appareils

Ordinateur/Portable / Hub

The VAYDEER USB Mouse Jiggler offers wide compatibility with various operating systems and software.

WARRANTY

The VAYDEER USB Mouse Jiggler comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as described under normal use. Please retain your proof of purchase for warranty claims.

SUPPORT

For any questions, technical assistance, or warranty inquiries regarding your VAYDEER USB Mouse Jiggler, please contact VAYDEER customer support. You can typically find contact information on the VAYDEER official website or through your purchase platform.

© 2024 VAYDEER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question