

[Manuals.plus](#) /

› [TREBLAB](#) /

› TREBLAB X3 Pro True Wireless Earbuds User Manual

TREBLAB X3-Pro-W

TREBLAB X3 Pro True Wireless Earbuds User Manual

Brand: TREBLAB | Model: X3-Pro-W

INTRODUCTION

Welcome to your TREBLAB X3 Pro True Wireless Earbuds. This manual provides comprehensive instructions for setup, operation, maintenance, and troubleshooting to ensure you get the best experience from your device.



Image: TREBLAB X3 Pro earbuds in their charging case, with one earbud removed and placed next to the open case.

WHAT'S IN THE BOX



Image: Contents of the TREBLAB X3 Pro box including earbuds, charging case, eartips, USB-C cable, cleaning kit, and user manual.

- TREBLAB X3 Pro Earbuds
- Portable Charging Case
- 5 sizes of Silicone Eartips
- USB-C Charging Cable
- Cleaning Brush and Swab
- User Manual
- Insert card
- Sticker

SETUP

Charging the Earbuds and Case

Before first use, fully charge your TREBLAB X3 Pro earbuds and the charging case.

POWER BANK

PHONE CHARGING BACKUP FOR URGENT SITUATIONS



Image: The TREBLAB X3 Pro charging case connected to a phone via USB-C cable, illustrating its power bank function.

- Connect the USB-C charging cable to the charging port on the case.
- The LED indicator on the case will show charging status.
- A full charge takes approximately 2 hours for the case and 2.5 hours for the earbuds.

Pairing with Your Device

To pair your TREBLAB X3 Pro earbuds with a Bluetooth-enabled device:

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device, go to Bluetooth settings and select "TREBLAB X3 Pro" from the list of available devices.
4. Once connected, you will hear a confirmation tone.

OPERATING INSTRUCTIONS

Wearing the Earbuds

For optimal sound and comfort, ensure a secure fit. The TREBLAB X3 Pro comes with 5 sizes of silicone eartips to choose from.



Image: Diagram illustrating the correct way to wear the earbuds for a secure and comfortable fit, along with the different eartip sizes provided.

1. Put the earbud in your ear.
2. Place the ear hook behind your ear.
3. Twist the earbud to make it comfortable and secure.

Touch Controls

The TREBLAB X3 Pro features intuitive touch controls for easy management of your audio and calls.

One Touch Control

ON / OFF

NEXT / PREVIOUS

CALLS

VOLUME CONTROL

SIRI / GOOGLE ASSISTANT

PLAY / PAUSE



Image: Close-up of a TREBLAB X3 Pro earbud highlighting its touch control functions.

- **On/Off:** Tap and hold the touch area.
- **Play/Pause:** Single tap.
- **Next/Previous Track:** Double tap right/left earbud.
- **Volume Control:** Triple tap right/left earbud.
- **Answer/End Call:** Single tap during an incoming call.
- **Reject Call:** Tap and hold during an incoming call.
- **Activate Voice Assistant (Siri/Google Assistant):** Tap and hold for 2 seconds.

Power Bank Function

The charging case can also serve as a power bank to provide emergency charge to your smartphone via the USB-C port.

MAINTENANCE

- Clean the earbuds and charging case regularly with a soft, dry cloth.
- Use the provided cleaning brush and swab for eartips and charging contacts.
- Avoid exposing the earbuds to extreme temperatures or direct sunlight.
- Store in the charging case when not in use to protect them and keep them charged.

TROUBLESHOOTING

Problem	Solution
Earbuds not turning on	Ensure earbuds and charging case are fully charged. Place earbuds in the case and close the lid, then open again.
Earbuds not pairing	Ensure Bluetooth is enabled on your device. Forget "TREBLAB X3 Pro" from your device's Bluetooth list and try pairing again. Make sure earbuds are in pairing mode (LED blinking).
No sound or low volume	Check device volume and earbud volume. Ensure earbuds are properly seated in your ears. Try different eartip sizes for a better seal.
Disconnections during use	Ensure your device is within the 33 feet (10m) Bluetooth range. Avoid obstacles between the earbuds and your device.

SPECIFICATIONS

Feature	Detail
Model Name	X3-Pro-W
Connectivity Technology	Bluetooth 5.3
Audio Driver Size	14.2 Millimeters
Battery Life (Earbuds)	Up to 9 hours (single charge)
Total Playtime with Charging Case	Up to 145 hours
Charging Time	Earbuds: 2.5 Hours, Case: 2 Hours
Water Resistance Level	IPX5 Sweatproof
Bluetooth Range	33 Feet / 10 m

Feature	Detail
Microphones	4 built-in mics with cVc 8.0
Control Type	Touch, Voice
Earpiece Shape	Hook
Noise Control	Sound Isolation
Frequency Response	20 KHz
Sensitivity	96 dB
Carrying Case Battery Capacity	2600 Milliamp Hours

WARRANTY AND SUPPORT

TREBLAB X3 Pro comes with a 1-YEAR WARRANTY and 30-DAY RETURNS. For support, please visit the official TREBLAB website or contact customer service through your purchase platform.

You can also refer to the official User Manual (PDF) and User Guide (PDF) available for download:

[User Manual \(PDF\)](#) [User Guide \(PDF\)](#)