

[Manuals.plus](#) /

› [Polly Pocket](#) /

› Polly Pocket Rainbow Funland Theme Park Playset Instruction Manual

Polly Pocket HBT13

Polly Pocket Rainbow Funland Theme Park Playset

Model: HBT13

Brand: Polly Pocket

PRODUCT OVERVIEW

The Polly Pocket Rainbow Funland Theme Park Playset offers an engaging play experience with multiple attractions and interactive areas. This set includes micro Polly and Shani dolls, two unicorns, and 25 surprise accessories, totaling 30 play pieces for extended imaginative play.

- Features 3 rides, 7 play areas, Polly and Shani dolls, 2 unicorns, and 25 surprise accessories (30 total play pieces).
- Includes a roller coaster, a unicorn carousel, and a Ferris wheel that dispenses surprises.
- Seven castle play areas: three turrets, a throne room, gift shop, game room, and food court.
- Discover a secret golden unicorn by unlocking a turret area with a key.
- Designed for interactive play both inside and outside the playset.

PACKAGE CONTENTS

Your Polly Pocket Rainbow Funland Theme Park Playset includes the following items:

- 1 Rainbow Funland Theme Park Playset
- 2 Micro Dolls (Polly and Shani)
- 2 Unicorn Figures
- 25 Surprise Accessories



Image: The complete Polly Pocket Rainbow Funland Theme Park Playset, showcasing the main structure, micro dolls, and various accessories.



Image: A detailed view of all 25 surprise accessories, including the micro dolls and unicorns, laid out next to the playset.

SETUP AND ASSEMBLY

The Rainbow Funland Theme Park Playset comes mostly pre-assembled. Minor assembly is required for certain components, such as attaching the slide and placing accessories.

1. Carefully remove all components from the packaging.
2. Attach the yellow roller coaster track to the main castle structure as indicated in the visual guide.
3. Place the micro dolls and accessories in their designated play areas or as desired for imaginative play.



12.9 in
32.77 cm



15.55 in
39.50 cm

Image: An overhead view of the playset, illustrating its various sections and the placement of accessories. Dimensions are also shown.

Your browser does not support the video tag.

Video: A demonstration of the Polly Pocket Rainbow Funland Theme Park Playset, showing its assembly and various interactive features.

OPERATING INSTRUCTIONS

Engage with the various interactive elements of the theme park for a dynamic play experience:

- **Roller Coaster:** Place a micro doll in the roller coaster car and send it down the yellow track for a thrilling ride.
- **Unicorn Carousel:** Position micro dolls on the unicorn figures on the carousel and spin it for a fun ride.
- **Ferris Wheel:** Turn the yellow star knob on the Ferris wheel to make it spin. The Ferris wheel is designed to dispense surprise accessories, which can be reloaded for continuous fun.
- **Secret Golden Unicorn:** Use the provided key to unlock a turret area and discover the hidden golden unicorn.



Image: A micro doll enjoying a ride on the playset's yellow roller coaster track.



Image: Micro dolls riding the colorful unicorn carousel, which can be manually spun.



Image: A hand turning the yellow star knob on the Ferris wheel, which activates the surprise dispensing feature.

PLAYSET FEATURES

The Rainbow Funland Theme Park is rich with detailed play areas designed for endless storytelling:

- **Castle Turrets:** Explore three distinct turrets, one of which contains a bathroom, another offers extra play space, and a third hides a secret.
- **Throne Room:** A regal area for Polly and Shani to rule their theme park.
- **Gift Shop:** Imagine buying souvenirs and treats.
- **Game Room:** Engage in miniature games and activities.
- **Food Court:** A place for the dolls to enjoy snacks and meals after a day of rides.



Image: Polly and Shani micro dolls positioned within the playset, highlighting the various castle play areas and their interactive elements.

Your browser does not support the video tag.

Video: An official overview of the Polly Pocket Rainbow Funland Theme Park Playset, showcasing its full range of features and play possibilities.

SAFETY GUIDELINES

Please observe the following safety information to ensure a safe play environment:

- **WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.**
- Recommended age for this product is 4 years and up.
- Adult supervision is recommended during play, especially with small accessories.

PRODUCT SPECIFICATIONS

Feature	Detail
---------	--------

Product Dimensions	5 x 15.75 x 12.99 inches
Item Weight	1.63 pounds
Item Model Number	HBT13
Manufacturer Recommended Age	4 years and up
Batteries	3 LR44 batteries required (not included)
Manufacturer	Mattel
Release Date	May 28, 2021

MAINTENANCE

To ensure the longevity and cleanliness of your Polly Pocket playset:

- Wipe the playset and accessories with a damp cloth as needed. Avoid harsh chemicals.
- Ensure all small pieces are stored securely within the playset or a separate container to prevent loss.
- Replace batteries (3 LR44) as necessary for features requiring power.

TROUBLESHOOTING

If you encounter any issues with your playset, please refer to the following common solutions:

- **Accessories not dispensing from Ferris Wheel:** Ensure the Ferris wheel is properly loaded with accessories and the yellow star knob is turned completely.
- **Moving parts are stiff:** Check for any obstructions or debris. Gently clean the moving mechanisms.
- **Playset not closing properly:** Ensure all internal accessories and dolls are correctly placed within their compartments before attempting to close the playset.

WARRANTY AND CUSTOMER SUPPORT

For warranty information, product registration, or further assistance, please visit the official Mattel website or contact their customer support. Keep your purchase receipt for any warranty claims.

Mattel Customer Service:

- Website: www.mattel.com
- Phone: Refer to the Mattel website for regional contact numbers.

© 2024 Polly Pocket. All rights reserved. Mattel.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question