

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AlkiVision](#) /

› [AlkiVision C1 Security Camera User Manual](#)

AlkiVision C1

AlkiVision C1 Security Camera User Manual

Model: C1 | Brand: AlkiVision

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your AlkiVision C1 Wireless Rechargeable Battery Powered 1080P WiFi Home Surveillance Camera. Designed for outdoor use, this camera features waterproof construction, night vision, motion detection, and two-way audio for enhanced home security.



Figure 1: AlkiVision C1 Wireless Security Camera

The AlkiVision C1 camera is a compact, white, bullet-style security camera with a black front housing the lens and

sensors. It is designed for easy outdoor installation.

WHAT'S INCLUDED

Upon unboxing your AlkiVision C1 camera, please verify that all components are present:

- AlkiVision C1 Battery IP Camera
- Outdoor Wall Mount
- USB Cable (for charging)
- Screws Set (for mounting)
- Quick User Guide (this manual)



Figure 2: Contents of the AlkiVision C1 package, including the camera, wall mount, USB cable, screws, and quick user guide.

SETUP

1. Initial Charging

Before first use, fully charge the camera using the provided USB cable and a DC5V 1A/2A power adapter (not included). Full charge typically takes about 5-6 hours.



Figure 3: The camera features a rechargeable battery designed for extended use.

2. App Installation

Download the "Adorcam" app from your mobile device's app store (available for Android). Search for "Adorcam" or scan the QR code provided in the quick user guide.

3. Camera Pairing

1. Ensure your camera's indicator light is flashing red, indicating it's awaiting Wi-Fi setup. If not, short press the power button twice to reset.
2. Open the Adorcam app and select "Add Device" for a battery camera.
3. Select your 2.4GHz Wi-Fi network (5GHz networks are not supported) and enter the correct password.
4. Remove any protective film from the camera lens.
5. The app will generate a QR code. Aim the camera lens directly at the QR code on your phone screen from a distance of 5-8 inches.
6. A tone will be heard from the camera when successfully scanned, indicating successful pairing.



Figure 4: The camera setup process involves scanning a QR code from the Adorcam app on your smartphone.

OPERATING INSTRUCTIONS

Live View

Access real-time video streaming from your camera through the Adorcam app. This allows you to monitor your property from anywhere with an internet connection.

Motion Detection & Alerts


The camera is equipped with PIR smart detection to identify unusual motion. When motion is detected, the camera will send instant alerts to your smartphone, allowing you to respond quickly to potential security threats.



Figure 5: The camera's motion detection feature sends real-time alerts to your phone, showing detected activity.

Two-Way Audio

Utilize the built-in microphone and speaker for real-time, two-way audio communication. This feature allows you to speak to visitors or deter intruders directly through the camera.



**Rechargeable battery, provide
1 to 6 months of worry
free use for every charge**




Not support 5G WIFI

100% Cordless WIFI Camera



No Power Cords Needed



No Network Cable Needed



No Drilling Needed

Figure 6: The camera supports two-way audio, enabling communication with individuals near the camera.

Night Vision

The AlkiVision C1 provides clear surveillance even in low-light conditions or complete darkness, with a night vision range of up to 32 feet.



Figure 7: Visual comparison of video quality in 720P, 1080P, and the camera's night vision mode.

SD Card Storage

The camera supports local storage via an SD card (not included) for recording and saving footage. This allows for continuous recording or event-triggered recordings without a subscription.

INSTALLATION AND MOUNTING

The AlkiVision C1 camera is designed for easy, wire-free installation, requiring no power cords, network cables, or drilling (for certain mounting options).



Figure 8: The camera is IP65 weatherproof, ensuring reliable operation in various weather conditions.

Mounting Tips:

- Use the outdoor mount if you intend to place the camera outdoors.
- Before final installation, take your camera and phone to the desired mounting location. Use the app to check the Wi-Fi signal strength; ensure it is "Great" for optimal performance.
- Mount the camera 7-10 feet high for a wide field of view and effective motion detection.
- Avoid placing the camera under direct sunlight to prevent glare and overheating.
- Avoid placing the camera lens near walls or glass to prevent reflections into the IR LED, which can affect night vision clarity.

MAINTENANCE

Battery Life & Charging

The camera's rechargeable battery provides 1 to 6 months of use per charge, depending on activity and settings. When the battery is low, recharge it using the provided USB cable.

Cleaning

Regularly clean the camera lens and housing with a soft, damp cloth to ensure clear image quality and proper sensor function. Avoid abrasive cleaners.

TROUBLESHOOTING

Connectivity Issues:

- **"Unable to play live video" / Disconnection:**
 - a. Check your mobile phone's Wi-Fi signal strength.
 - b. Ensure the camera's Wi-Fi signal strength is adequate at its location. If too weak, move the camera closer to the wireless router.
 - c. If connection fails repeatedly, try resetting the camera by short pressing the power button twice.
- **Wi-Fi Compatibility:** Ensure you are connecting to a 2.4GHz Wi-Fi network. The camera does not support 5GHz Wi-Fi.

SPECIFICATIONS







Feature	Detail
Model Number	C1
Video Capture Resolution	1080p
Power Source	Battery Powered
Connectivity Protocol	Wi-Fi (2.4GHz only)
Indoor/Outdoor Usage	Outdoor
Special Features	Night Vision, Motion Sensor, 2-Way Audio
International Protection Rating	IP65 (Weatherproof)
Night Vision Range	32 Feet
Item Dimensions (L x W x H)	3.4 x 1.4 x 2.3 inches
Item Weight	10.2 ounces

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your product packaging or visit the official AlkiVision website. Keep your purchase receipt for warranty claims.

© 2024 AlkiVision. All rights reserved.

Related Documents - C1

	<p>AMOROM AM-C1 Quick Start Guide</p> <p>This guide provides instructions for setting up and configuring the AMOROM AM-C1 security camera, including app download, account registration, and Wi-Fi connection.</p>
	<p>COCOCAM Wire-Free Rechargeable Security Battery Camera User Guide</p> <p>Comprehensive user guide for the COCOCAM Wire-Free Rechargeable Security Battery Camera, covering setup, app installation, features, and troubleshooting.</p>
	<p>ELPRO 415U-2-Cx Wireless Mesh Networking I/O Gateway Installation Guide</p> <p>Comprehensive installation guide for the ELPRO 415U-2-Cx wireless mesh networking I/O and gateway. Covers antenna setup, power supply, I/O connections, and configuration.</p>
	<p>Dometic Oceanair Rollerblind Range: Stylish and Functional Window Coverings</p> <p>Explore the Dometic Oceanair Rollerblind range, offering customizable manual and powered roller blinds with a focus on durable hardware, stylish design, and high-quality fabrics. Ideal for yachts and marine environments, these blinds provide excellent light control and privacy.</p>
	<p>Sena Tufftalk M Industrial Bluetooth Communication System User Manual</p> <p>Comprehensive user manual for the Sena Tufftalk M industrial Bluetooth communication system, covering installation, features, operation, and troubleshooting. Learn how to pair devices, manage intercoms, use FM radio, and configure settings.</p>
	<p>MINIX Wireless USB-C to HDMI Dongle (1080P) Quick Start Guide</p> <p>Step-by-step instructions for setting up the MINIX Wireless USB-C to HDMI Dongle (1080P), including connection details for C1 and H1 transmitters and FCC compliance information.</p>