

VAYDEER FM701

VAYDEER Super Mini Mouse Jiggler (Model FM701) Instruction Manual

Keep your PC active and enhance productivity.

1. INTRODUCTION

Thank you for choosing the VAYDEER Super Mini Mouse Jiggler. This device is designed to keep your computer active by simulating mouse movement, preventing your system from going to sleep or showing an idle status. It features a durable aluminum alloy casing, plug-and-play functionality, and three distinct movement modes, all while remaining 100% undetectable by IT departments.

2. PRODUCT OVERVIEW

The VAYDEER Super Mini Mouse Jiggler is a compact and robust device. It features an upgraded aluminum alloy case for enhanced durability and a sleek appearance. The device includes two buttons for easy operation: an ON/OFF switch and a mode selection button. An LED indicator provides visual feedback on the device's status and selected mode.

アップグレードされた 金属ケース&2ボタン設計



Figure 2.1: VAYDEER Super Mini Mouse Jiggler with ON/OFF and Mode buttons.

This device is designed for portability and discretion, allowing you to use it in various environments without drawing attention.

3. SETUP

Setting up your VAYDEER Super Mini Mouse Jiggler is straightforward and requires no software installation.

1. **Connect the Device:** Insert the VAYDEER Super Mini Mouse Jiggler into an available USB-A port on your computer (PC or Mac).
2. **Power On:** Press and hold the ON/OFF button for 3 seconds. The device will power on, and the LED

indicator will light up blue.

3. **Ready for Use:** The device is now active and will begin simulating mouse movements according to the last selected mode.

Your browser does not support the video tag.

Video 3.1: Demonstrates connecting the mouse jiggler to a laptop and powering it on. It also shows how to switch between the three movement modes.

4. OPERATING INSTRUCTIONS

The VAYDEER Super Mini Mouse Jiggler offers three distinct modes of operation to suit various needs. The device remembers the last selected mode even after being powered off.

4.1 Mode Selection

To switch between modes, simply press the mode selection button (the button without the power symbol). Each press will cycle through the available modes:

- **Mode 1: Narrow Range Movement** - The mouse pointer moves within a small, confined area.
- **Mode 2: Wide Range Movement** - The mouse pointer moves across a larger area of the screen.
- **Mode 3: Subtle Jiggling Action** - The mouse pointer performs very slight, almost imperceptible movements (1-2 pixels). This mode is ideal for maintaining activity without interfering with precise mouse operations.

3種類のランダム動作軌道 & LEDインジケータ



Figure 4.1: Visual representation of the three movement modes.

4.2 Power On/Off

To power the device ON or OFF, press and hold the ON/OFF button (the button with the power symbol) for 3 seconds. The LED indicator will turn on or off accordingly.

5. COMPATIBILITY

The VAYDEER Super Mini Mouse Jiggler is broadly compatible with various operating systems and devices:

- **Operating Systems:** Windows 7/8/10, Mac OS, Linux, Unix, Chrome OS.

- **Devices:** Desktop Computers, Laptops, USB Hubs.
- **Mouse Types:** Works with both wired and wireless mice.



Figure 5.1: Broad compatibility with various systems and software.

6. USE CASES AND BENEFITS

This device is particularly useful for:

- **Remote Work:** Keeps your status active on communication platforms like Microsoft Teams, Zoom, Slack, Skype, and Webex, even when you step away from your desk.
- **Preventing Sleep Mode:** Ensures your computer does not enter sleep mode or activate screen savers during long downloads, presentations, or monitoring tasks.
- **Undetectable Operation:** Recognized as a standard USB composite device, making it invisible to IT monitoring software.
- **Uninterrupted Tasks:** Allows you to continue video conferences or large file downloads without interruption due to inactivity.



Figure 6.1: Examples of the mouse jiggler in action, maintaining online status and preventing interruptions.

7. SPECIFICATIONS

Brand	VAYDEER
-------	---------

Model Name	FM701
Color	Black
Connectivity Technology	USB
Number of Modes	3
Compatible Operating Systems	Windows, Mac OS, Linux, Unix, Chrome OS
Compatible Devices	PC, Laptop, USB Hub
Power Type	Plug and Play
Material	Aluminum Alloy Case
GTIN/UPC	769044131018
Batteries Required	No

8. TROUBLESHOOTING

- **Device not powering on:**
 - Ensure the device is fully inserted into a functional USB port.
 - Press and hold the ON/OFF button for 3 seconds until the blue LED lights up.
 - Try a different USB port or computer to rule out port issues.
- **Mouse pointer not moving:**
 - Verify the device is powered on (blue LED is lit).
 - Cycle through the modes by pressing the mode selection button to ensure a mode is active.
 - Ensure your computer's power settings are not overriding the jigglers function (e.g., aggressive sleep timers).
- **Interference with normal mouse operation:**
 - If precise mouse control is needed, switch the jigglers to Mode 3 (subtle jigglers) or power it off temporarily.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact VAYDEER customer service through the retailer where the product was purchased. Keep your purchase receipt for warranty claims.