



Manuals.plus /

› Lazmin112 /

› Lazmin112 USB Wired Stereo Soundbar (Model: Lazmin112o71kzmndxi6060-01) Instruction Manual

Lazmin112 Lazmin112o71kzmndxi6060-01

Lazmin112 USB Wired Stereo Soundbar

Model: Lazmin112o71kzmndxi6060-01

INTRODUCTION

This manual provides instructions for the proper setup, operation, maintenance, and troubleshooting of your Lazmin112 USB Wired Stereo Soundbar. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

3.5mm audio input plug

Widely compatible with most devices



Image: Front view of the Lazmin112 USB Wired Stereo Soundbar.

PRODUCT FEATURES

- **3D Stereo Sound:** Equipped with two speakers and DSP bass sound technology for clear audio output.
- **Wide Compatibility:** Connects to various devices including desktops, laptops, smartphones, tablets, MP3, and MP4 players via a 3.5mm audio port. Powered by USB.
- **Durable and Portable Design:** Constructed from high-quality plastic, making it lightweight and suitable for various indoor settings.
- **Integrated Volume Control:** Features a volume knob on the cable for easy sound adjustment.
- **Blue LED Lighting:** Incorporates a blue LED breathing light for visual indication.




Image: Soundbar displaying the blue LED breathing light.



Image: Illustration of the soundbar's 3D stereo sound capability with two speakers.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Lazmin112 USB Wired Stereo Soundbar
- USB Cable (integrated)

SETUP GUIDE

1. **Connect USB Power:** Insert the USB plug into an available USB port on your computer, laptop, or a compatible USB power adapter. This provides power to the soundbar.
2. **Connect Audio:** Insert the 3.5mm audio plug into the audio output jack (headphone jack) of your device (PC, laptop, smartphone, tablet, etc.).
3. **Position the Soundbar:** Place the soundbar on a stable surface, such as a desk or shelf, ensuring it is not obstructed for optimal sound projection.
4. **Verify Connection:** Ensure both the USB and 3.5mm audio plugs are securely connected.

Volume Adjustment Knob

Stepless adjustment of sound volume to meet your various needs



Image: Illustration of connecting the 3.5mm audio input plug and USB power plug to various devices.

OPERATING INSTRUCTIONS

1. **Power On:** Once the USB cable is connected to a power source, the soundbar will power on automatically, indicated by the blue LED light.
2. **Adjust Volume:** Use the inline volume knob located on the cable to increase or decrease the sound output. Rotate clockwise to increase volume and counter-clockwise to decrease.
3. **Play Audio:** Begin playing audio from your connected device. The sound will be routed through the soundbar.
4. **Power Off:** Disconnect the USB cable from the power source to turn off the soundbar.



Breathing LED Light

Pretty light effect adding much more atmosphere to music

Image: A hand adjusting the inline volume knob on the soundbar's cable.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the soundbar. Avoid using liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or twisting the cables excessively to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound output	<ul style="list-style-type: none"> • USB power not connected. • 3.5mm audio plug not fully inserted. • Device volume too low or muted. • Soundbar volume too low. 	<ul style="list-style-type: none"> • Ensure USB is connected to a working port. • Firmly insert the 3.5mm audio plug into the device's audio output. • Increase volume on your connected device. • Adjust the soundbar's inline volume knob.
Distorted sound	<ul style="list-style-type: none"> • Volume set too high on device or soundbar. • Poor audio source quality. 	<ul style="list-style-type: none"> • Reduce volume on both the device and the soundbar. • Test with a different audio source or file.
Blue LED not lit	USB power not connected or faulty.	Ensure the USB cable is securely connected to a functional USB port. Try a different USB port or power adapter.

SPECIFICATIONS

Feature	Detail
Brand	Lazmin112
Model Name	Lazmin112o71kzmdxi6060-01
Speaker Type	Soundbar
Connectivity Technology	USB (for power), 3.5mm Audio Jack (for signal)
Audio Output Mode	Stereo, Surround
Speaker Maximum Output Power	3 Watts
Material	Plastic
Color	White
Product Dimensions (L x W x H)	12.6" x 2.5" x 2.7" (32cm x 6.4cm x 6.8cm)
Item Weight	1.32 pounds
Control Method	Volume Knob (inline)
Compatible Devices	Smartphone, Tablet, MP3 Player, Desktop, Laptop




Image: Diagram illustrating the physical dimensions of the soundbar.

WARRANTY AND SUPPORT

This product comes with a limited warranty. For detailed warranty information or technical support, please refer to the product packaging or contact Lazmin112 customer service through the retailer where the product was purchased.