

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iLuv](#) /

› [iLuv Smart Shaker 3 User Manual](#)

## iLuv SMSHAKER3BK

# iLuv Smart Shaker 3 User Manual

Wireless Shaker for Hearing Impaired & Heavy Sleepers

## INTRODUCTION

The iLuv Smart Shaker 3 is an innovative wireless vibration alarm designed to provide a powerful and discreet wake-up solution for individuals with hearing impairment, heavy sleepers, or anyone who prefers a silent alarm. This device connects to your smartphone via Bluetooth, allowing you to manage alarms, receive call alerts, and get notifications from various apps directly through strong vibrations.

Its compact and portable design makes it ideal for use at home or while traveling. With a long-lasting rechargeable battery and customizable vibration strengths, the Smart Shaker 3 offers a reliable and personalized alarm experience.

## SAFETY INFORMATION

Please read and follow all safety instructions carefully before using the iLuv Smart Shaker 3 to ensure safe operation and prevent damage.

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water or other liquids.
- Do not attempt to disassemble, repair, or modify the device. This will void the warranty and may cause harm.
- Use only the provided charging cable or a certified USB-C cable for charging.
- Keep out of reach of children and pets.
- Dispose of the device and its battery responsibly according to local regulations.

## PACKAGE CONTENTS

- iLuv Smart Shaker 3 (Black)
- USB-C Charging Cable
- Quick Start Guide (This manual provides detailed instructions)

## PRODUCT OVERVIEW



Image: The iLuv Smart Shaker 3 showing its key features including the Snooze Button, Battery Level LEDs, and Power Switch.



Image: The iLuv Smart Shaker 3 device positioned next to a smartphone screen, which displays the Smart Shaker 3 application interface for setting alarms.

The Smart Shaker 3 features a sleek, round design with LED indicators for battery level and a conveniently located snooze button. It is designed to be placed under a pillow or mattress for effective vibration alerts.

## SETUP

---

### 1. Charging the Smart Shaker 3

Before first use, fully charge your Smart Shaker 3. Connect the provided USB-C charging cable to the charging port on the device and plug the other end into a USB power adapter (not included) or a computer's USB port. The LED indicators will show charging progress.



Image: A diagram illustrating the three easy steps for setting up the Smart Shaker 3: charging the device, downloading the companion app, and powering on to pair.

## 2. Downloading the Smart Shaker 3 App

The Smart Shaker 3 requires the companion app for full functionality. Download the "Smart Shaker 3" app from the Apple App Store (for iOS devices) or Google Play Store (for Android devices).

**For iOS:** Search for "Smart Shaker 3" in the App Store.

**For Android:** Search for "Smart Shaker 3" in the Google Play Store.

## 3. Pairing with Your Smartphone

1. Ensure Bluetooth is enabled on your smartphone.
2. Slide the power switch on the Smart Shaker 3 to the "On" position. The LED light should blink blue, indicating it's in pairing mode.
3. Open the Smart Shaker 3 app on your smartphone.
4. Follow the on-screen instructions within the app to search for and connect to your Smart Shaker 3. The app will guide you through the pairing process.
5. Once successfully paired, the LED light on the Smart Shaker 3 will stop blinking and remain solid, and the app will confirm the connection.

## iOS & Android Compatible

Manage all your alarm settings and vibration strength through the SmartShaker 3 app.




Image: A series of smartphone screenshots demonstrating the easy setup instructions for pairing the Smart Shaker 3 with the app, including holding the snooze button, searching for the device, and successful connection.

## OPERATING THE SMART SHAKER 3

### Setting Alarms

The Smart Shaker 3 app allows you to set up to 20 different alarms with various customization options.

### Benefits of Using the Smart Shaker

Thousands of satisfied customers have used Smart Shakers to:




Image: A screenshot of the Smart Shaker 3 app's alarm homepage, showing options to add new alarms, view existing ones, and toggle them on/off.

1. Open the Smart Shaker 3 app.
2. Navigate to the "My Alarms" section.
3. Tap "Add Alarm" to create a new alarm.
4. **Customize Alarm Settings:**
  - **Alarm Time:** Set the desired wake-up time.
  - **Repeat:** Choose specific days of the week for the alarm to repeat, or set it as a one-time alarm.
  - **Vibration Strength:** Select from 5 different vibration strengths to suit your preference. You can test the vibration level within the app.
  - **LED Alert Light:** Toggle the LED light on/off during the alarm.
  - **Alarm Name:** Assign a custom name to your alarm for easy identification.

5. Save your alarm settings.

## 3-Step Easy Setup

Follow the steps below to get your Smart Shaker up and running in no time!



1

### Charge it up

Fully charge the Smart Shaker 3 with an external power source



2

### Download App

Download the Smart Shaker 3 app on the App Store or Google Play



3

### Power On & Pair

Slide the power switch to on and start the pairing process

Image: Two screenshots from the Smart Shaker 3 app showing detailed alarm settings, including options to set time, repeat days, LED alert, and vibration strength.

## Snooze and Stop Alarm

- When an alarm vibrates, press the large snooze button on the Smart Shaker 3 device to activate snooze. The snooze duration is typically 9 minutes.
- To stop the alarm completely, open the Smart Shaker 3 app on your phone and tap the "Stop" button on the active alarm screen.

## Receiving Notifications and Alerts

The Smart Shaker 3 can also provide vibration alerts for incoming calls and app notifications.

## Easy Setup Instructions

Get started using the Smart Shaker in no time by following the easy setup process




Image: Two screenshots from the Smart Shaker 3 app displaying alert settings, allowing users to enable or disable alerts for phone calls, health services, and social network messages, along with vibration duration and strength customization.

- In the Smart Shaker 3 app, navigate to "Alert Settings".
- Enable or disable alerts for:
  - Phone Calls:** Receive vibrations for incoming calls.
  - Health Care:** Get alerts from health-related apps (e.g., CGM/BGM for diabetic reminders).

- **SNS Messages:** Receive notifications from social media and messaging apps.

3. Customize vibration duration and strength for these alerts as desired.




Image: Three smartphone lock screen examples demonstrating how Smart Shaker 3 alerts appear for various notifications, including general alarms, health reminders, and other app alerts.

## MAINTENANCE

### Cleaning

To clean your Smart Shaker 3, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water.

### Battery Care

- For optimal battery life, avoid fully discharging the device frequently.
- Charge the device regularly, especially if it will not be used for an extended period.
- Store the device in a cool, dry place when not in use.

## TROUBLESHOOTING

Problem	Possible Solution
Device not turning on.	Ensure the device is charged. Connect it to a power source using the USB-C cable.
Cannot pair with smartphone.	<ul style="list-style-type: none"> <li>• Ensure Bluetooth is enabled on your phone.</li> <li>• Make sure the Smart Shaker 3 is powered on and within range.</li> <li>• Restart both the Smart Shaker 3 and your smartphone.</li> <li>• Try forgetting the device in your phone's Bluetooth settings and re-pairing.</li> <li>• Ensure the Smart Shaker 3 app is updated to the latest version.</li> </ul>
Vibration is too weak/strong.	Adjust the vibration strength setting within the Smart Shaker 3 app for each alarm or alert type.

Problem	Possible Solution
Alarms/Notifications not working.	<ul style="list-style-type: none"> <li>Check if the alarms are enabled in the app.</li> <li>Verify that notification permissions are granted to the Smart Shaker 3 app in your phone's settings.</li> <li>Ensure the Smart Shaker 3 is connected via Bluetooth to your phone.</li> <li>Check the battery level of the Smart Shaker 3.</li> </ul>
Short battery life.	<ul style="list-style-type: none"> <li>Ensure the device is fully charged.</li> <li>Frequent use of high vibration strength or continuous alerts can reduce battery life.</li> <li>Make sure the device is powered off when not in use.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Model Name	SmartShaker 3
Model Number	SMSHAKER3BK
Brand	iLuv
Connectivity Technology	Bluetooth
Wireless Communication Standard	Bluetooth
Battery Type	Lithium Polymer (included)
Battery Capacity	1500 Milliamp Hours
Battery Life	Up to 14 days (with 5 minutes vibration per day)
Vibration Strengths	5 different levels
Alarm Settings	Up to 20 alarms via app
Operating System	FreeRTOS
Product Dimensions	1.7 x 5.3 x 6.9 inches
Item Weight	6.4 ounces (0.4 Pounds)
Special Feature	Perfect for Heavy Sleeper, Hearing Impaired & Deaf-Blind!

## WARRANTY AND SUPPORT

iLuv is committed to providing high-quality products and customer satisfaction. For any questions, issues, or warranty claims, please refer to the information below:



## Need Help?

Your satisfaction matters to us! Please contact us through the official iLuv seller page if you're experiencing any problems. Our support team is on standby 24/7 to help you with any product issues.



## Got a Question?

Not sure if your device is compatible with our product? Feel free to leave a question on the product page in the customer questions & answers section and our team will get back to you within the next day.



## 30 Day Return

Dissatisfied with a product? Unable to resolve the issue through support? Worry not! All products are eligible for a full hassle free refund within 30 days of purchase.

For further assistance, please visit the official iLuv store on Amazon:[amazon.com/iLuv](https://www.amazon.com/iLuv)

© 2024 iLuv. All rights reserved.

## Related Documents - SMSGAKER3BK



### [iLuv SmartShaker 3 User Manual and Setup Guide](#)

Comprehensive guide to setting up and using the iLuv SmartShaker 3, a smart vibrating alarm device. Learn about device features, app operations, specifications, FAQs, and troubleshooting.

	<p><a href="#"><u>iLuv TimeShaker 6Q Wow: User Manual for Wireless Charging Bluetooth Alarm Clock</u></a></p> <p>Comprehensive user manual for the iLuv TimeShaker 6Q Wow, detailing setup, features, and operation of this wireless charging Bluetooth alarm clock with FM radio and bed shaker.</p>
	<p><a href="#"><u>iLuv TimeShaker 6Q Wow User Manual: Wireless Charging Bluetooth Alarm Clock with FM Radio and Bed Shaker</u></a></p> <p>Comprehensive user manual for the iLuv TimeShaker 6Q Wow, detailing setup, operation, and features of this wireless charging Bluetooth alarm clock. Includes instructions for dual alarms, FM radio, USB charging, bed shaker, and sleep timer.</p>
	<p><a href="#"><u>Troubleshooting Tips for Morning Call 5Q Alarm Clock</u></a></p> <p>This document provides troubleshooting tips for the iLuv Morning Call 5Q alarm clock, covering setting the time and alarms, and addressing phone charging issues.</p>
	<p><a href="#"><u>iLuv Morning Call 5Q: Jumbo LED Dual Alarm Clock with Wireless Charging - User Manual</u></a></p> <p>User manual for the iLuv Morning Call 5Q alarm clock. Features include a jumbo white LED display, dual alarms, Qi wireless charging, USB charging port, FM radio, and sleep timer. Learn setup, operation, and safety instructions.</p>
	<p><a href="#"><u>iLuv Morning Call 5 Qi User Manual: Jumbo LED Alarm Clock with Wireless Charging and FM Radio</u></a></p> <p>Comprehensive user manual for the iLuv Morning Call 5 Qi, a jumbo white LED display dual alarm clock featuring Qi-certified wireless charging, FM radio, and USB charging port. Learn how to set time, alarms, use the radio, sleep timer, and charging features.</p>