

Walfront CBB65

Walfront CBB65 45uF 450V Capacitor Instruction Manual

For Air Conditioning Compressors and Industrial Equipment

1. INTRODUCTION

This manual provides essential information for the safe and effective use of the Walfront CBB65 45uF 450V capacitor. This component is designed for starting and running single-phase AC motors in applications such as air conditioning compressors, refrigerators, and various industrial equipment. Please read this manual thoroughly before installation and operation.

2. PRODUCT OVERVIEW

The Walfront CBB65 capacitor is a non-polarity electrolysis capacitor featuring a round aluminum foil construction. It is engineered for reliable performance in demanding environments.

- **Voltage Rating:** 450V AC, suitable for various motor applications.
- **Capacitance:** 45uF (microfarads) with a tolerance of $\pm 5\%$.
- **Operating Temperature:** Designed to operate within a range of 40/70/21 (meaning -40°C to +70°C, with 21 days humidity test).
- **Construction:** Round shape with aluminum foil material, ensuring durability and compact size.
- **Application:** Primarily used as a motor start or run capacitor for air conditioners, refrigerators, and other industrial motor-driven equipment.




Figure 1: Front view of the Walfront CBB65 capacitor, showing its specifications including 45uF ±5%, 450 VAC, and CBB65A-1 model designation.

3. SPECIFICATIONS

Parameter	Value
Brand	Walfront
Model	CBB65
Capacitance	45 μF

Parameter	Value
Voltage Rating	450 VAC
Capacitance Tolerance	±5%
Working Temperature	40/70/21 (-40°C to +70°C)
Shape	Round
Material	Aluminum Foil
Dimensions (approx.)	0.39 x 0.39 x 0.39 inches
Item Weight (approx.)	6.3 ounces

Note: The provided product dimensions (0.39 x 0.39 x 0.39 inches) and item weight (6.3 ounces) may refer to packaging or shipping specifications. Actual capacitor dimensions may vary.

4. SAFETY INFORMATION

WARNING: Capacitors can store a dangerous electrical charge even after power is disconnected. Improper handling can result in severe injury or death. Always follow proper safety procedures.

- **Professional Installation Recommended:** Installation and replacement of this capacitor should only be performed by qualified personnel with experience in electrical systems.
- **Disconnect Power:** Always disconnect the main power supply to the equipment before attempting any work on the capacitor or associated circuitry. Verify power is off using a multimeter.
- **Discharge Capacitor:** Before touching, always discharge the capacitor using a properly insulated resistor or a specialized capacitor discharge tool. Never short the terminals with a screwdriver or bare wire, as this can cause damage to the capacitor and create a dangerous spark.
- **Wear Personal Protective Equipment (PPE):** Use insulated gloves and safety glasses when working with electrical components.
- **Check Polarity:** While this is a non-polarity capacitor, always double-check the wiring diagrams of your equipment to ensure correct connections.
- **Inspect for Damage:** Before installation, visually inspect the capacitor for any signs of physical damage, leaks, or bulging. Do not install a damaged capacitor.

5. SETUP AND INSTALLATION

This capacitor is designed for use in AC motor circuits. The installation process typically involves replacing an existing capacitor or integrating it into a new circuit. Refer to the specific wiring diagram of your appliance or motor for precise connection instructions.

1. Preparation:

- Ensure the main power to the equipment is completely disconnected and locked out.
- Discharge any existing capacitors in the circuit before handling.
- Gather necessary tools: insulated screwdriver, wire cutters/strippers, multimeter, capacitor discharge tool (recommended).

2. Identify Connections:

- Note the existing wiring configuration if replacing a capacitor. Take photos for reference.
- The CBB65 capacitor typically has multiple terminals (spades) for connection. These are usually labeled or designed for specific motor windings (e.g., Herm, Fan, C for common). Consult your equipment's wiring diagram.



Figure 2: Example of a CBB65 capacitor in an air compressor setup. Note: Always refer to your specific equipment's wiring diagram for correct installation.

3. Connect the Capacitor:

- Connect the wires to the appropriate terminals on the new capacitor. Ensure connections are secure and tight.
- This capacitor is non-polarized, meaning it can be connected in either direction in an AC circuit, but always follow the equipment's wiring diagram.



Figure 3: Close-up of the capacitor terminals, showing the spade connectors for electrical wiring.

4. **Secure the Capacitor:**

- Mount the capacitor securely within the equipment, ensuring it does not vibrate excessively or come into contact with moving parts or sharp edges.

5. **Final Check:**

- Double-check all connections for correctness and security.
- Ensure no tools or debris are left inside the equipment.

6. **Restore Power:**

- Carefully restore power to the equipment and observe for proper operation.

6. **OPERATION**

The CBB65 capacitor functions as a critical component in single-phase AC motor circuits, primarily for starting and running. It works by creating a phase shift in the motor's auxiliary winding, providing the necessary torque to initiate rotation (start capacitor) and/or improving efficiency during continuous operation (run capacitor).

- **Start Capacitor Function:** Provides a temporary boost of current to the motor's start winding, allowing it to overcome inertia and begin rotating. Once the motor reaches a certain speed, a centrifugal switch or electronic relay typically disconnects the start capacitor from the circuit.
- **Run Capacitor Function:** Remains in the circuit continuously, improving the motor's power factor and efficiency by maintaining a phase shift between the main and auxiliary windings. This results in smoother operation and reduced energy consumption.

This specific CBB65 model is commonly used as a dual-purpose start/run capacitor in applications like air conditioning compressors, where it assists both in starting and continuous operation.

7. MAINTENANCE

Capacitors are generally maintenance-free components. However, periodic inspection can help identify potential issues before they lead to equipment failure.

- **Visual Inspection:** Annually, or as part of routine equipment maintenance, visually inspect the capacitor for:
 - **Bulging or Swelling:** A sign of internal pressure buildup, indicating failure.
 - **Leaks:** Any oily residue around the terminals or casing suggests a leak.
 - **Corrosion:** Rust or corrosion on terminals can lead to poor connections.
 - **Discoloration:** Signs of overheating.
- **Cleanliness:** Ensure the capacitor and its terminals are free from dust, dirt, and moisture, which can affect performance and lead to short circuits.
- **Secure Connections:** Verify that all electrical connections to the capacitor are tight and free from looseness.
- **Environmental Conditions:** Ensure the operating environment remains within the specified temperature range (40/70/21) to prolong capacitor life.

If any signs of damage or failure are observed, the capacitor should be replaced immediately by a qualified technician.

8. TROUBLESHOOTING

If your motor or appliance is experiencing issues, a faulty capacitor could be a contributing factor. Always ensure power is disconnected and the capacitor is discharged before performing any checks.

Symptom	Possible Cause	Action
Motor hums but does not start	Failed start capacitor	Test capacitor capacitance with a multimeter. Replace if out of specification or visibly damaged.
Motor starts slowly or runs inefficiently	Weak run capacitor	Test capacitor capacitance. Replace if significantly lower than rated value.
Capacitor is bulging, leaking, or discolored	Internal failure, overheating	Immediately replace the capacitor. Investigate potential causes of overheating (e.g., incorrect voltage, motor overload).
No power to motor	Loose or corroded connections	Inspect and clean terminals. Secure all connections.

If troubleshooting steps do not resolve the issue, consult a qualified electrician or appliance repair technician.

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Walfront CBB65 capacitor, please refer to the documentation provided with your purchase or contact Walfront customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Walfront

For further assistance, you may visit the Walfront store on Amazon: [Walfront Store](#)

© 2023 Walfront. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08V8GLTZM>

More documents and user manuals: <https://manuals.plus/>