

[Manuals.plus](#) /

› [PAGARIA](#) /

› PAGARIA WALKIE Portable Alarm Clock FM Radio User Manual

PAGARIA L837BT-WALKIE (Black)

PAGARIA WALKIE Portable Alarm Clock FM Radio

USER MANUAL

Model: L837BT-WALKIE (Black)

Product Overview

The PAGARIA WALKIE is a versatile portable device combining an FM radio, alarm clock, Bluetooth speaker, voice recorder, and media player. Designed for ease of use, it features a clear LCD display and multiple playback options.



Image: Front view of the PAGARIA WALKIE device, displaying the time 20:38 on its large LCD screen, with control buttons and a speaker grille visible.

Key Features:

- **Digital FM Radio:** Auto scan and direct station selection for easy tuning.
- **Clock with Big Display:** Clear time display with AM/PM indication.
- **Dual Alarm Function:** Set two independent alarms.
- **Portable & Pocket Size:** Compact design for easy carrying.
- **Voice Recorder:** Record voice directly onto a TF card.
- **Bluetooth V5.0:** Seamless wireless connectivity with smartphones, tablets, and laptops.
- **USB/TF Music Support:** Play audio files from USB drives and TF cards up to 32 GB.
- **6 Hours Playback:** Long-lasting rechargeable battery.
- **Sleep Timer:** Automatically turn off the radio after a set period.
- **Rotary Volume Knob:** Easy and precise volume control.
- **3 Watts Digital Audio Sound:** Clear and robust sound output.
- **Earphone Support:** Listen privately with included earphones.

Controls and Components

Familiarize yourself with the various buttons, ports, and indicators on your PAGARIA WALKIE device.



Image: Detailed diagram showing the various controls and ports of the PAGARIA WALKIE, including the LCD display, number keys, function buttons, USB slot, TF slot, earphone jack, charging port, power switch, volume knob, and hand strap/FM antenna.

- **LCD Display:** Shows time, FM frequency, mode indicators (BT, FM, TF), and battery status.
- **Number Keys (0-9):** Used for direct FM station tuning and inputting alarm times.
- **Backward / Last Select / Time Setting (◀◀):** Navigate backward, select previous track/station, or adjust time settings.
- **Play / Pause (▶▶):** Play or pause audio playback.
- **Forward / Next Select / Time Setting (▶▶):** Navigate forward, select next track/station, or adjust time settings.
- **Mode Key (M):** Switches between FM, Bluetooth, and TF/USB playback modes.
- **Radio / REC / Save (FM):** Short press for FM functions, long press to start/stop voice recording, or save recordings.

- **Clock Mode / Sleep Timer ():** Access clock settings and set sleep timer.
- **Repeat / Single / Off Key (⏮):**Control playback repeat modes.
- **USB Slot:** For connecting USB flash drives for audio playback.
- **TF Slot:** For inserting TF (microSD) cards for audio playback and voice recording.
- **Earphone Jack:** 3.5mm port for connecting earphones.
- **Charging Port:** Micro USB port for charging the device.
- **Power Switch:** On/Off toggle switch.
- **Volume Knob:** Rotary control for adjusting audio volume.
- **Hand Strap / FM Antenna:** Integrated strap that also functions as an FM antenna.
- **Battery Compartment:** Located at the bottom, for accessing the rechargeable battery (if removable).

Setup

Charging the Device:

The PAGARIA WALKIE comes with a built-in rechargeable battery. Before first use, or when the battery is low, connect the device to a 5V DC power source using the provided USB cable. The charging indicator will illuminate during charging and turn off when fully charged. A full charge provides approximately 6 hours of playback.



Image: The PAGARIA WALKIE device connected to a power adapter via a USB cable, illustrating the charging process. Note: Adapter is not provided.

Initial Power On and Time Setting:

1. Slide the **Power Switch** to the ON position.
2. The LCD display will light up, showing the current time or default time.
3. To set the time, press and hold the **Clock Mode / Sleep Timer** button ().
4. Use the **Backward** (◀◀) and **Forward** (▶▶) buttons to adjust hours and minutes. Press the **Clock Mode / Sleep Timer** button again to confirm each setting (hours, minutes, AM/PM).

Operating Instructions

FM Radio Operation:

The device features a digital FM radio with easy tuning options.

walkie
MODEL NO. L837BT

INBUILT MIC FOR RECORDING

Long Press FM Key
To Start Recording



Image: The PAGARIA WALKIE displaying an FM frequency (94.3) on its screen, illustrating the digital tuning function. The hand strap/antenna is shown extended.

- **Switching to FM Mode:** Press the **Mode Key (M)** until "FM" appears on the display.
- **Auto Scan:** Long press the **Play / Pause** button (▶▶) to automatically scan and save available FM stations.
- **Direct Station Selection:** Enter the desired frequency using the **Number Keys (0-9)** (e.g., for 94.3 FM, press 9-4-3).
- **Manual Tuning:** Use the **Backward** (◀◀) and **Forward** (▶▶) buttons to fine-tune or switch between saved stations.
- **Antenna:** For best reception, ensure the hand strap/FM antenna is fully extended.

Bluetooth Operation:

Connect your device wirelessly via Bluetooth for audio playback.

SUPPORT BLUETOOTH FUNCTION

Short Press M Key
To Select Bluetooth
Mode



Image: A person using a smartphone, with the PAGARIA WALKIE device nearby, illustrating the Bluetooth connectivity feature. The device's screen shows 'BT' indicating Bluetooth mode.

1. Press the **Mode Key (M)** repeatedly until "BT" appears on the display. The device will enter pairing mode, indicated by a flashing Bluetooth icon.
2. On your smartphone or Bluetooth-enabled device, search for "WALKIE" in the Bluetooth settings.
3. Select "WALKIE" to pair. Once connected, a confirmation sound will play, and the Bluetooth icon on the display will become solid.
4. You can now play audio from your connected device through the PAGARIA WALKIE. Use the **Play / Pause**, **Backward**, and **Forward** buttons on the WALKIE to control playback.

USB/TF Card Playback:

Play music directly from a USB flash drive or TF (microSD) card.

1. Insert a USB flash drive into the **USB Slot** or a TF card into the **TF Slot**.
2. The device will automatically switch to USB or TF mode and begin playing audio files. If not, press the **Mode Key (M)** until the corresponding indicator (USB or TF) appears.

3. Use the **Play / Pause**, **Backward**, and **Forward** buttons to control playback.
4. The **Repeat / Single / Off Key** (⏮) can be used to cycle through repeat modes (e.g., repeat one, repeat all).

Alarm Clock Function:

Set up to two independent alarms.



Image: The PAGARIA WALKIE displaying time with alarm icons, indicating its dual-alarm capability. The image also shows people sleeping, suggesting the alarm clock's use.

1. Press the **Clock Mode / Sleep Timer** button () once to view the current alarm settings.
2. Press and hold the **Clock Mode / Sleep Timer** button to enter alarm setting mode. The alarm 1 hour will flash.
3. Use the **Backward** (◀◀) and **Forward** (▶▶) buttons to adjust the hour, then press **Clock Mode / Sleep Timer** to confirm. Repeat for minutes and AM/PM.
4. After setting Alarm 1, the display will automatically move to Alarm 2 settings. Repeat the process.
5. To enable/disable an alarm, short press the **Clock Mode / Sleep Timer** button to cycle through alarm states (Alarm 1 ON, Alarm 2 ON, Both ON, Both OFF).

Voice Recording:

Record your voice directly onto a TF card.



Image: A person singing, with the PAGARIA WALKIE device in the foreground, highlighting its inbuilt microphone for recording. The text indicates to long press the FM key to start recording.

1. Ensure a TF card is inserted into the **TF Slot**.
2. Long press the **Radio / REC / Save (FM)** button to start recording. A recording indicator will appear on the display.
3. Long press the **Radio / REC / Save (FM)** button again to stop and save the recording.
4. To play back recordings, switch to TF card mode and navigate through files using the **Backward** and **Forward** buttons.

Using Earphones:

For private listening, connect the included earphones to the **Earphone Jack**.

walkie
MODEL NO. L837BT



POCKET RADIO WITH EARPHONE

Image: A person walking outdoors, holding the compact PAGARIA WALKIE device with earphones connected, demonstrating its portability and earphone usage.

Sleep Timer:

Set the device to automatically turn off after a specified duration.

- While in any mode, short press the **Clock Mode / Sleep Timer** button () repeatedly to cycle through available sleep timer options (e.g., 15 min, 30 min, 60 min, OFF).
- The device will automatically power off after the selected time.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the device. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Avoid Water:** This device is not waterproof. Keep it away from water and high humidity.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Battery is discharged. Power switch is OFF.	Charge the device. Ensure the power switch is in the ON position.
No sound or low volume.	Volume is too low. Device is muted.	Adjust the Volume Knob . Ensure the device is not muted (if applicable).
Poor FM reception.	Antenna not extended. Weak signal area.	Fully extend the hand strap/FM antenna. Try moving to a location with better signal.
Bluetooth not connecting.	Device not in pairing mode. Bluetooth disabled on source device.	Ensure the WALKIE is in Bluetooth pairing mode ("BT" flashing). Enable Bluetooth on your source device and re-scan.
Cannot record voice.	No TF card inserted. TF card full or corrupted.	Insert a TF card. Check TF card capacity or try a different card.

Specifications

Feature	Detail
Model	L837BT-WALKIE (Black)
Brand	PAGARIA
Display Type	LCD
Product Dimensions	11W x 5.9H Centimeters
Item Weight	103 Grams
Power Source	Battery Powered (Rechargeable)
Connectivity Technology	Bluetooth, USB, TF Card
Radio Bands Supported	FM
Speakers Maximum Output Power	3 Watts
Battery Playback Time	Up to 6 Hours
TF/USB Support	Up to 32 GB
Included Components	Radio, USB Cable, Earphone, User Manual

Warranty and Support

Your PAGARIA WALKIE device comes with a**One Year Warranty**. For warranty registration and support, please visit the [manufacturer's website](#).

Manufacturer: MELODY ELECTRONICS

Website: www.melodymedia.in

For any technical assistance or service inquiries, please contact the manufacturer directly through their official website.

© 2023 PAGARIA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question