

HOMCOM B08V8SZB2N

HOMCOM Convertible Floor Sofa Chair Instruction Manual

Model: B08V8SZB2N

[Safety Information](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &
Support](#)

1. SAFETY INFORMATION

Please read all safety information before using the HOMCOM Convertible Floor Sofa Chair.

- Supervise children and pets to avoid entrapment risks.
- Keep the product away from open flames or high heat sources to prevent damage or fire hazards.
- Ensure the product is placed on a stable, level surface to prevent tipping.
- Do not exceed the maximum weight limit of 264 pounds (120 kg).

2. SETUP

The HOMCOM Convertible Floor Sofa Chair requires no assembly. It arrives ready for use. Follow these steps to prepare your sofa chair:

1. **Unpacking:** Carefully remove the sofa chair from its packaging. Retain packaging materials for future transport or storage if needed.
2. **Placement:** Place the sofa chair on a clean, flat, and stable surface in your desired location.
3. **Initial Unfolding:** The unit may be folded for shipping. Gently unfold the main body of the sofa chair.
4. **Pillow Placement:** Position the two included pillows as desired for comfort, either for head support or back support.



Image: The HOMCOM Convertible Floor Sofa Chair in its upright sofa configuration, placed on a rug in a room.

3. OPERATION

This convertible floor sofa chair offers multiple configurations for various uses. Adjustments are made via the integrated mechanisms in the backrest and headrest.

3.1. Adjusting the Backrest

The backrest features a 3-level adjustment mechanism (each level 15°). To adjust:

1. Gently push the backrest forward until you hear a click.
2. Continue pushing forward to release the current position.
3. Slowly recline the backrest to your desired angle. It will click into place at each available level.
4. To fully flatten the backrest, push it all the way forward until it releases, then lay it flat.

ADJUSTABLE BACKREST

Help you find the perfect sitting angle



Image: A diagram illustrating the adjustable backrest and headrest positions. The backrest can be set to three different angles, and the headrest to five.

3.2. Adjusting the Headrest

The headrest offers 5-level adjustment (each level 18°). To adjust:

- Similar to the backrest, push the headrest forward to release its current position.
- Adjust it to one of the five available angles for optimal head and neck support.

3.3. Converting Between Sofa, Lounger, and Bed

The sofa chair can be easily converted into different modes:

- **Sofa Mode:** Keep the backrest and headrest in an upright or slightly reclined position.
- **Lounger Mode:** Partially recline the backrest and adjust the headrest for a comfortable lounging position.
- **Bed Mode:** Fully flatten the backrest and headrest to create a flat sleeping surface. Ensure the leg section is fully extended.

3 IN 1 DESIGN




Image: A visual representation of the sofa chair transforming from a cozy sofa to a lounger, and finally to a flat bed.

4. MAINTENANCE

Proper care will extend the life of your HOMCOM Convertible Floor Sofa Chair.

- **Cleaning:** Wipe the upholstery with a damp cloth. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **General Care:** Periodically check all moving parts and connections to ensure they are secure.
- **Storage:** When not in use, the sofa chair can be folded for compact storage, saving floor space.

HIGH COMFORT



Thick Padding



Soft Suede Fabric



Two Pillows

Image: Detailed views highlighting the thick padding, soft suede fabric, and the two included pillows, emphasizing the comfort features.

5. TROUBLESHOOTING

If you encounter issues with your sofa chair, refer to the following common solutions:

Problem	Possible Cause	Solution
Backrest does not stay in position or adjusts too easily.	Mechanism not fully engaged or worn.	Ensure the backrest is pushed fully forward to reset the mechanism before reclining to a new position. If the issue persists, contact customer support.
Difficulty flattening the chair into bed mode.	Incorrect adjustment sequence.	Ensure the leg section is fully extended first. Then, push the backrest completely forward to release the locking mechanism before laying it flat.

Problem	Possible Cause	Solution
Squeaking noises during adjustment.	Friction in the metal frame.	Apply a small amount of silicone-based lubricant to visible pivot points in the adjustment mechanism. Avoid oil-based lubricants.

6. SPECIFICATIONS

Key technical specifications for the HOMCOM Convertible Floor Sofa Chair:

- **Brand:** HOMCOM
- **Model:** Convertible Floor Sofa Chair
- **Product Dimensions (Sofa):** 28.75"D x 40.25"W x 23.5"H
- **Reclined Length (Bed):** 68 Inches
- **Seat Depth:** 23.5 inches
- **Seat Height:** 6 Inches
- **Item Weight:** 26.4 Pounds
- **Weight Limit:** 264 Pounds (120 kg)
- **Seating Capacity:** 2
- **Assembly Required:** No
- **Material Type:** Polyester (Upholstery), Metal (Frame)
- **Fill Material:** Foam
- **Adjustable Back:** Yes (3 positions, 15° each)
- **Adjustable Headrest:** Yes (5 positions, 18° each)
- **Included Components:** 2 Throw Pillows
- **Indoor/Outdoor Usage:** Indoor
- **Product Care Instructions:** Wipe with Damp Cloth



Image: A detailed diagram illustrating the dimensions of the HOMCOM Convertible Floor Sofa Chair in both its upright sofa form and fully reclined bed form.

7. WARRANTY & SUPPORT

Manufacturer: Aosom LLC

Warranty: This product comes with a 1-year limited manufacturer's warranty.

For warranty claims, technical support, or any inquiries regarding your HOMCOM Convertible Floor Sofa Chair, please contact Aosom LLC customer service. Refer to your purchase documentation for specific contact details or visit the official HOMCOM website.

Please retain your proof of purchase for warranty purposes.