

[Manuals.plus](#) /

› [Diffuserlove](#) /

› Diffuserlove 400ML Essential Oil Diffuser with Remote Control and 7-Color Mood Light User Manual

Diffuserlove Diffuserlove Essential Oil Diffuser (Model B08VCZDQ3K)

Diffuserlove 400ML Essential Oil Diffuser User Manual

Model: Diffuserlove Essential Oil Diffuser (B08VCZDQ3K)

INTRODUCTION

Thank you for choosing the Diffuserlove 400ML Essential Oil Diffuser. This device combines aromatherapy, humidification, and ambient lighting to create a pleasant and relaxing environment. Please read this manual carefully before use to ensure proper operation and maintenance.

SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- Avoid direct contact with undiluted essential oils.
- Keep the diffuser out of reach of children and pets.
- Ensure adequate ventilation in the area where the diffuser is used.
- Do not exceed the maximum water fill line.
- Use only the provided power adapter.
- Unplug the device before cleaning or refilling.
- The diffuser features an automatic shut-off function when water runs out, ensuring safe operation.
- Do not tilt or move the diffuser when it is operating or contains water.

PACKAGE CONTENTS

- Diffuserlove 400ML Essential Oil Diffuser Unit

- Power Adapter
- Remote Control
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your diffuser.




Image: Diffuserlove 400ML Essential Oil Diffuser showing the Light and Mist buttons on the front.

Main Unit

- **Mist Outlet:** Where the mist is released.
- **Water Tank:** Holds up to 400ML of water and essential oils.
- **Max Water Line:** Indicates the maximum water level.
- **Ultrasonic Plate:** Generates mist (located at the bottom of the water tank).
- **Air Outlet:** For air circulation.

- **Power Jack:** Connects to the power adapter.

Control Buttons

- **MIST Button:** Controls mist output and timer settings.
- **LIGHT Button:** Controls the LED mood lighting.

SETUP

Follow these steps for initial setup:

1. Place the diffuser on a flat, stable surface.
2. Remove the top cover by lifting it upwards.
3. Connect the power adapter to the power jack at the bottom of the diffuser. Do not plug into a wall outlet yet.
4. Fill the water tank with clean tap water up to the maximum water line (400ML capacity). Do not overfill.
5. Add 3-5 drops of your preferred essential oil directly into the water tank. Adjust the quantity based on personal preference and room size.
6. Replace the top cover, ensuring it is securely seated.
7. Plug the power adapter into a wall outlet. The diffuser is now ready for operation.



Eucalyptus



Frankincense



Lavender



Lemongrass



Sweet Orange



Peppermint



Rosemary



Tea Tree

Image: A selection of essential oil bottles, illustrating the variety that can be used with the diffuser.

OPERATING INSTRUCTIONS

Mist Control

Press the **MIST** button to cycle through the mist modes:

- **1H:** Diffuser operates for 1 hour, then automatically shuts off.
- **3H:** Diffuser operates for 3 hours, then automatically shuts off.
- **6H:** Diffuser operates for 6 hours, then automatically shuts off.
- **ON (Continuous):** Diffuser operates continuously until water runs out, then automatically shuts off.
- Pressing the MIST button again after 'ON' will turn the mist off.

The mist output can be adjusted between strong and weak. To adjust, press and hold the MIST button for 2 seconds while the mist is on. The diffuser will beep once for strong mist and twice for weak mist.

Light Control

Press the **LIGHT** button to control the LED mood lighting:

- **First Press:** Turns on the light with automatic color cycling through 7 different colors.
- **Subsequent Presses:** Fixes the light to a specific color. Continue pressing to cycle through the 7 available colors.
- **Press and Hold:** To adjust the brightness of the current fixed color (dim or bright).
- **Long Press (2 seconds):** Turns off the light.

7 MOOD LIGHTS

Adjustable between dim and bright
Auto-color cycle or fixed color



Image: The Diffuserlove 400ML Essential Oil Diffuser showcasing its 7 mood light options, demonstrating the variety of ambient lighting available.

REMOTE CONTROL

The included remote control allows for convenient operation from a distance.

REMOTE CONTROL

Easily set up light, timing and mist modes



Image: Remote control for the Diffuserlove diffuser, demonstrating its ease of use for setting light, timing, and mist modes.

- **ON/OFF:** Turns the diffuser mist and light on or off.
- **MIST:** Cycles through 1H, 3H, 6H, and Continuous mist modes.
- **LIGHT:** Cycles through light colors and turns the light on/off.
- **HIGH/LOW:** Adjusts mist output intensity (strong/weak).
- **BRIGHT/DIM:** Adjusts the brightness of the fixed light color.

MAINTENANCE AND CLEANING

Regular cleaning helps maintain optimal performance and extends the lifespan of your diffuser.

1. Unplug the diffuser from the power outlet and remove the top cover.
2. Empty any remaining water from the water tank.
3. Wipe the inside of the water tank with a soft cloth.
4. For thorough cleaning, use a cotton swab dipped in white vinegar to gently clean the ultrasonic plate at the

bottom of the water tank. Do not scrub forcefully.

- 5. Rinse the water tank with clean water, avoiding direct contact with the air outlet.
- 6. Wipe the exterior of the diffuser with a soft, dry cloth.
- 7. Ensure all parts are completely dry before reassembling and storing or reusing.

Note: Do not immerse the diffuser base in water. Do not use harsh detergents or abrasive cleaners.

TROUBLESHOOTING

If you encounter any issues, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No mist or weak mist	- Insufficient water - Water level too high - Ultrasonic plate dirty - Top cover not properly seated	- Add water to the tank (below max line). - Empty some water if overfilled. - Clean the ultrasonic plate with a cotton swab and vinegar. - Ensure the top cover is correctly aligned and closed.
Diffuser not turning on	- No power connection - No water in tank (auto shut-off)	- Check if the power adapter is securely plugged into the diffuser and wall outlet. - Add water to the tank.
Light not working	- Light function turned off - Power issue	- Press the LIGHT button to activate. - Ensure the diffuser is powered on.
Unusual noise	- Water level too low - Foreign object in water tank	- Add water. - Unplug, empty, and check for any obstructions.

SPECIFICATIONS

Feature	Detail
Brand	Diffuserlove
Model Name	Diffuserlove Essential Oil Diffuser
Capacity	400 ml
Dimensions (L x W x H)	17L x 17W x 16H centimeters
Power Source	Electric

Feature	Detail
Wattage	8 Watts
Run Time	Up to 10 hours (continuous mode)
Auto Shut-off	Yes (when water runs out)
Noise Level	<30dB
Material	BPA-free
Light Type	LED (7 colors)
Coverage Area	Medium to large room

WARRANTY AND SUPPORT

Diffuserlove products are manufactured with high-quality standards. For any questions, concerns, or warranty claims, please contact our customer support team. Please refer to your purchase documentation for specific warranty terms and contact information.

For further assistance, please visit our official website or contact the retailer from whom you purchased the product.

