

[Manuals.plus](#) /

› [YUSWKO](#) /

› YUSWKO Black Handheld Milk Frother Wand for Coffee, Rechargeable Electric Whisk with 3 Heads 3 Speeds Drink Mixer Coffee Frother For Latte, Cappuccino, Hot Chocolate, Egg Black Without Stand

YUSWKO milkfrother2023new

YUSWKO Handheld Milk Frother Instruction Manual

Model: milkfrother2023new

1. INTRODUCTION

This manual provides instructions for the safe and efficient use of your YUSWKO Handheld Milk Frother. Designed for versatility and ease of use, this rechargeable electric whisk is perfect for creating creamy milk froth for coffee, mixing beverages, and even whisking eggs.



Image: The YUSWKO Handheld Milk Frother, showcasing its main unit, three interchangeable whisk heads (spring, hook, and balloon), and the USB charging cable.

2. PRODUCT FEATURES

- **USB Rechargeable Design:** Equipped with a 1500mAh built-in battery, offering an environmentally friendly and convenient charging solution.
- **Three Detachable Stainless Steel Whisking Heads:** Includes a spring stirrer for milk froth, a hook stirrer for powdered drinks, and a balloon mixer for eggs and cream.
- **Three-Speed Settings:** Adjustable low, medium, and high speeds for optimal frothing and mixing results.
- **Battery Indicator Light:** Provides clear indication of battery level (low, medium, full) for timely recharging.
- **Ergonomic Design:** Features an easy and comfortable grip with an ergonomic handle and buttons.
- **Low-Noise Operation:** Built-in powerful motor ensures quiet operation.

3. COMPONENTS

Your YUSWKO Handheld Milk Frother package includes:

- Main Frother Body
- Spring Whisk
- Hook Whisk
- Balloon Whisk
- USB Charging Cable
- User Manual (this document)



Image: Detailed view of the three replaceable whisk heads, showing their distinct designs and approximate lengths.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the frother.

1. Locate the USB charging port at the bottom of the frother body.
2. Connect the provided USB charging cable to the frother and a compatible USB power source (e.g., wall adapter, computer, power bank).
3. The indicator light will show charging status (e.g., red for charging, green for fully charged).
4. A full charge typically provides multiple uses.



Image: Illustrates the USB-C charging port and the charging indicator light on the frother.

4.2 Attaching Whisk Heads

Select the appropriate whisk head for your task.

1. Ensure the frother is turned off.
2. Align the small rivets on the whisk shaft with the corresponding slots on the frother's motor shaft.
3. Gently push the whisk head into place until it clicks securely.
4. To remove, pull the whisk head straight out.

5. OPERATING INSTRUCTIONS

5.1 General Usage

1. Pour your desired liquid (milk, coffee, protein shake, etc.) into a cylindrical container. For frothing milk, do not fill more than 1/3 full to prevent overflow. Recommended container dimensions: diameter 90-100mm, height no less than 110mm.
2. Insert the whisking head into the liquid. Ensure the whisking head is at least 10mm from the container wall and 5mm from the bottom.
3. Press the power button to start the frother. The frother has three speed settings: Low, Medium, and High. Press the corresponding button to select your desired speed.
4. For frothing, slowly move the frother horizontally and vertically through the liquid. Keep the whisking head immersed to increase whisking area and create rich foam.
5. Once desired consistency is achieved (typically 15-20 seconds for milk froth), press the power button again to stop the frother.
6. Carefully remove the frother from the container.



Image: Visual representation of the three-speed settings and their application for different beverage types.

5.2 Specific Applications

- **Milk Froth (Spring Whisk):** Ideal for lattes, cappuccinos, and hot chocolate. Use cold milk for best results.
- **Powdered Drinks (Hook Whisk):** Perfect for mixing milk powder, protein powder, nutritional powder, or oatmeal.
- **Eggs & Cream (Balloon Whisk):** Suitable for beating eggs, whipping cream, or mixing condensed milk for baking.

Your browser does not support the video tag.

Video: Official demonstration of the YUSWKO Milk Frother Handheld, showcasing its features and how to use it for various tasks like frothing milk and whisking eggs.

6. MAINTENANCE & CLEANING

Proper cleaning ensures longevity and hygiene of your frother.

- **Whisk Heads:** After each use, detach the whisk head and rinse it under running water. The whisk heads are dishwasher safe.
- **Frother Body:** Wipe the main frother body with a damp cloth. **Do not immerse the main body of the machine in water** to avoid damaging the electronic components.
- Allow all parts to air dry completely before storing.



CLEAN AND STORE EASILY



NOTE

Do not immerse the milk frother body in water

Image: Illustrates the easy cleaning process for the whisk heads, emphasizing the caution against immersing the main unit.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Frother not turning on	Low battery; improper whisk attachment	Charge the frother; ensure whisk is securely attached
Weak frothing/mixing	Low battery; incorrect speed setting; too much liquid	Recharge; select higher speed; reduce liquid volume
Liquid overflowing	Container too small; too much liquid	Use recommended container size; do not fill more than 1/3

8. SPECIFICATIONS

- **Brand:** YUSWKO
- **Model Name:** milkfrother2023new
- **Color:** Black
- **Material:** Stainless Steel, Acrylonitrile Butadiene Styrene (ABS)
- **Product Dimensions:** 1.3"W x 6.7"H
- **Item Weight:** 170 Grams (6 ounces)
- **Power Source:** Battery Powered (Rechargeable USB)
- **Battery Capacity:** 1500mAh (internal)
- **Wattage:** 800 watts
- **UPC:** 663918691519
- **Country of Origin:** China

9. WARRANTY & SUPPORT

YUSWKO offers a 1-year replacement warranty for manufacturing defects.

If you receive a wrong or defective product, or are unsatisfied with its use, please contact our customer service for support and satisfied solutions.

For assistance, please visit the official YUSWKO Store on Amazon: [YUSWKO Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question