

NKF ONC50UB18C05

NKF Replacement Remote Control User Manual

MODEL: ONC50UB18C05

Compatible with ONN 4K Ultra HD (2160P) UHD LED TVs

1. INTRODUCTION

This manual provides instructions for the NKF Replacement Remote Control, model ONC50UB18C05. It is designed to operate various ONN 4K Ultra HD (2160P) UHD LED TV models. This remote control requires no programming or pairing, offering a straightforward user experience.

2. PACKAGE CONTENTS

- 1 x NKF Replacement IR Remote Control (Model ONC50UB18C05)
- **Note:** Batteries and additional instructions are not included in the package.

3. SETUP

3.1 Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover off.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Important: Ensure correct battery polarity to prevent damage to the remote control.





Image Description: A close-up view of the back of the remote control with the battery cover removed, showing two AAA batteries correctly inserted into their compartments.

4. OPERATING INSTRUCTIONS

Once batteries are installed, the remote control is ready for immediate use with compatible ONN TV models. No programming or pairing is required.

4.1 Basic Functions

- **Power Button (Red):** Turns the TV on or off.
- **Input Button:** Cycles through available input sources (HDMI, AV, Media, TV).
- **Number Buttons (0-9):** Directly select channels.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the TV channel.
- **MUTE:** Mutes or unmutes the TV audio.
- **MENU:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **BACK/EXIT:** Returns to the previous screen or exits the current menu.





Image Description: A front view of the NKF Replacement Remote Control, displaying all buttons clearly labeled for various TV functions such as power, input, volume, channel, and menu navigation.

5. COMPATIBILITY

This remote control is compatible with the following ONN 4K Ultra HD (2160P) UHD LED TV models:

- ONC50UB18C05
- ONA24HB19E02
- ONA43UB19E04
- ONA50UB19E05
- ONA55UB19E06

- ONA65UB19E07
- ONA50UB19E09

6. SPECIFICATIONS

Feature	Detail
Brand	NKF
Model Number	ONC50UB18C05
Connectivity Technology	Infrared (IR)
Compatible Devices	Television
Power Source	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	6.3 x 2 x 0.8 inches
Item Weight	2.5 ounces
Special Feature	Ergonomic Design

7. TROUBLESHOOTING

7.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are new and inserted with correct polarity. Replace if necessary.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the TV's IR receiver. Obstructions can block the signal.
- **Distance:** Operate the remote control within a reasonable distance from the TV.
- **TV Power:** Confirm the TV is powered on and not in standby mode.

7.2 Specific Buttons Not Working

- **Clean Remote:** Dust or debris might be interfering with button contacts. Gently clean the remote surface with a soft, dry cloth.
- **Battery Check:** Weak batteries can cause intermittent button functionality. Replace batteries.

8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.

- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage.

9. SUPPORT AND CONTACT INFORMATION

For any questions or concerns regarding this product, please contact the manufacturer, NKF, or the seller through your purchase platform.

Note: Please refer to your specific ONN TV's user manual for detailed TV functions and advanced settings.

© 2023 NKF. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08VDY5SFH>

More documents and user manuals: <https://manuals.plus/>