

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Logitech](#) /

› [Logitech G735 Wireless Gaming Headset Instruction Manual - Model 981-001082](#)

## Logitech G735

# Logitech G735 Wireless Gaming Headset Instruction Manual

Model: G735 (981-001082)

## INTRODUCTION

The Logitech G735 Wireless Gaming Headset is designed for comfort and versatility across multiple platforms. Featuring customizable LIGHTSYNC RGB lighting, multi-platform connectivity via LIGHTSPEED wireless, Bluetooth, or 3.5 mm aux, and a detachable Blue VO!CE microphone, this headset provides immersive audio and clear communication. Its lightweight design and breathable ear cups ensure comfort during extended use.

## WHAT'S IN THE BOX

- Logitech G735 Wireless Gaming Headset
- Detachable Microphone
- LIGHTSPEED USB-A Receiver (Dongle)
- USB-C to USB-A Charging Cable

Your browser does not support the video tag.

**Video:** Unboxing the Logitech G735 Wireless Gaming Headset, showing the headset, detachable microphone, LIGHTSPEED dongle, and charging cable.

## SETUP

1. **Attaching the Microphone:** Insert the detachable microphone into the 3.5mm jack located on the left ear cup. Adjust the flexible boom to your preferred position.
2. **Connecting via LIGHTSPEED Wireless:** Plug the LIGHTSPEED USB-A receiver into a USB-A port on your PC or compatible device. Power on the headset. The headset should automatically connect.
3. **Connecting via Bluetooth:** Power on the headset. Press and hold the Bluetooth button (indicated by a Bluetooth icon) on the ear cup until the LED indicator blinks rapidly. Select 'Logitech G735' from your device's Bluetooth settings to pair.
4. **Connecting via 3.5mm Aux:** Connect a 3.5mm audio cable (not included) from your device to the 3.5mm aux port on the headset.

## OPERATING INSTRUCTIONS



Image: Annotated diagram highlighting key features and controls of the Logitech G735 headset.

- **Power On/Off:** Use the dedicated power button on the ear cup.
- **Volume Control:** Adjust audio levels using the volume roller/buttons on the ear cup.
- **Microphone Mute:** The detachable mic features an on-ear mute button for quick privacy.
- **Dual Audio Mixing:** The headset supports simultaneous audio from two devices (one via Bluetooth, one via LIGHTSPEED or 3.5mm). Use the on-ear controls to mix audio levels between devices, allowing you to balance in-game sound with voice chat or music.
- **LIGHTSYNC RGB Lighting:** The headset features soft, dual-zone LIGHTSYNC RGB lighting with preloaded Play Mood animations. Customize your own lighting effects using the Logitech G HUB software.
- **Blue VO!CE Microphone:** The detachable microphone utilizes Blue VO!CE filters to enhance voice clarity and reduce background noise. Settings can be adjusted via G HUB.

## CUSTOMIZATION

Unlock the full potential of your Logitech G735 headset with the free Logitech G HUB software. This software allows you to:

- Customize LIGHTSYNC RGB lighting with 16.8 million programmable colors and animation effects.
- Adjust Blue VO!CE microphone settings for optimal voice clarity and noise reduction.
- Fine-tune audio equalizer settings for personalized sound profiles.

## SPECIFICATIONS

Feature	Detail
Model Name	G735
Connectivity Technology	Wireless (Bluetooth, RF)
Noise Control	Passive Noise Cancellation

Frequency Response	20 Hz - 20 kHz
Sensitivity	88 dB
Headphones Jack	3.5 mm Jack
Item Weight	260 Grams (9.2 ounces)
Bluetooth Version	5.0
Bluetooth Range	20 Meters
Battery Life	Up to 16+ hrs (50% volume with lighting on), 56 hrs (50% volume with lighting off)

## TROUBLESHOOTING

- Bluetooth Connectivity Issues:** If you experience problems with Bluetooth connectivity, turn off the Bluetooth function on your device for a couple of minutes, then turn it back on and attempt to reconnect.
- No Audio/Low Volume:** Ensure the headset is powered on and fully charged. Check volume levels on both the headset and your connected device. Verify correct audio output selection in your device's sound settings.
- Microphone Not Working:** Ensure the microphone is securely attached and not muted. Check microphone input settings on your device and in Logitech G HUB.

## MAINTENANCE

To ensure the longevity and optimal performance of your Logitech G735 headset, follow these maintenance guidelines:

- Cleaning:** Use a soft, dry cloth to clean the headset. Avoid abrasive cleaners or solvents.
- Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the headset regularly.

## WARRANTY AND SUPPORT

The Logitech G735 Wireless Gaming Headset comes with a limited hardware warranty. For detailed warranty information, technical support, or to access additional resources, please visit the official Logitech support website or refer to the documentation included with your product.