PALONE WD-942

PALONE Electric Fly Swatter User Manual

Model: WD-942 | Brand: PALONE

1. Introduction

Thank you for choosing the PALONE Electric Fly Swatter. This 2-in-1 device combines a powerful 4000V bug zapper racket with a mosquito killer lamp, designed for effective pest control both indoors and outdoors. Featuring a 1200mAh rechargeable battery and a 3-layer safety mesh, it offers a safe and efficient solution for eliminating flies, mosquitoes, and other flying insects.



Figure 1: PALONE Electric Fly Swatter and its components.

2. Important Safety Information

WARNING: To reduce the risk of injury, fire, or electric shock, always follow these basic safety precautions:

- Do not touch the high-voltage grid directly. The 3-layer safety mesh is designed to prevent accidental contact, but caution is advised.
- Keep out of reach of children and pets.
- Do not use in close proximity to electrical equipment, sources of static electricity, or machinery with moving parts.
- Store in closed, airtight safety containers after use.
- Do not use in high-temperature environments for extended periods.
- Do not use near flammable liquids or gases.
- Do not wash the device with water. Clean with a dry cloth.

- Ensure the device is switched off before charging or cleaning.

3. Package Contents

Please check the package contents upon unboxing to ensure all items are present:

- 1 x PALONE Electric Fly Swatter
- 1 x Charging Base
- 1 x USB Charging Cable
- 1 x User Manual



Figure 2: All items included in the package.

4. Setup

Before first use, ensure the device is fully charged.

1. Place the charging base on a stable, flat surface.
2. Connect the USB charging cable to the charging base and then to a compatible power source (e.g., USB wall adapter, computer USB port, power bank).
3. Ensure the fly swatter is switched to the "OFF" position.
4. Insert the handle of the fly swatter into the charging base. The indicator lights on the handle will illuminate to show charging progress.



Figure 3: Battery indicator lights and power switch on the handle.

5. Operating Modes

The PALONE Electric Fly Swatter offers two distinct operating modes:

5.1. ON1 Mode (Manual Swatting)

- Slide the power switch to the "ON1" position.
- Press and hold the gray button on the handle to activate the high-voltage grid. A red working light will illuminate.

- Wave the racket to manually swat and eliminate flying insects.
- Release the button to switch off the current.

5.2. ON2 Mode (Automatic Mosquito Killer Lamp)

- Slide the power switch to the "ON2" position.
- The bug zapper racket will work automatically. The 6 mosquito trap purple UV lights will turn on.
- Place the swatter in its charging base or stand it upright in an area where mosquitoes are present. The UV light will attract mosquitoes to the high-voltage grid for instant electrocution.



Figure 4: Automatic mosquito killer lamp mode with UV light.

6. Usage

The PALONE Electric Fly Swatter is versatile for both indoor and outdoor use.

6.1. Manual Swatting (ON1 Mode)

For direct elimination of flies, mosquitoes, fruit flies, and other flying insects, hold the swatter by the handle, activate the grid by pressing the gray button, and swing it towards the insect. The 4000V high-voltage grid will instantly zap the pest.



Figure 5: Effective physical bug control.

6.2. Lamp Mode (ON2 Mode)

For hands-free operation, especially during nighttime, place the swatter in its charging base or stand it in an area requiring pest control. The UV light will continuously attract and eliminate insects, providing a comfortable, bug-free environment.



Figure 6: Safe and eco-friendly operation in lamp mode.

Your browser does not support the video tag.

Video 1: Official product demonstration of the Electric Fly Swatter with 3 Layers and 2-in-1 Bug Zapper Racket functionality.

7. Charging the Device

The fly swatter is equipped with a built-in 1200mAh rechargeable lithium-ion battery, eliminating the need for disposable dry cells.

- To charge, ensure the swatter is in the "OFF" position.
- Insert the swatter into its charging base, ensuring it is properly seated.
- Connect the USB cable from the base to a power source.
- The four indicator lights on the handle will display the battery status during charging. Each light represents approximately 25% charge.



Figure 7: Innovative base charging and battery indicators.

8. Maintenance

Proper maintenance ensures the longevity and effectiveness of your fly swatter.

- **Cleaning:** After use, ensure the device is switched off. Gently tap the swatter to dislodge any insect remains. For stubborn debris, use a dry brush or cloth. Do NOT use water or wet cloths to clean the grid.
- **Storage:** Store the fly swatter in a cool, dry place, away from direct sunlight and moisture.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge when the battery indicator shows low power.

9. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Swatter not zapping/no power.	Battery is low or depleted. Power switch is OFF or not in ON1/ON2. Gray button not pressed (ON1 mode).	Charge the device fully. Ensure switch is in ON1 or ON2 position. Press and hold the gray button while swatting.
UV light not turning on (ON2 mode).	Power switch not in ON2 position.	Slide the power switch to the ON2 position.
Device not charging.	USB cable or adapter faulty. Swatter not properly seated in base. Swatter not in OFF position.	Try a different USB cable or adapter. Re-seat the swatter firmly in the base. Ensure the switch is in the OFF position before charging.
Flies not attracted to lamp mode.	Too much ambient light. Device placed too far from insect activity.	Use in darker environments for best results. Place closer to areas with insect presence.

10. Specifications

- **Brand:** PALONE
- **Model:** WD-942
- **Color:** White
- **Material:** Metal
- **Product Dimensions:** 16.14"L x 12.2"W x 1.97"H
- **Item Weight:** 1.15 pounds
- **High-Voltage Grid:** 4000V
- **Battery:** 1200mAh Lithium Ion (included)
- **Safety Mesh:** 3-layer
- **UV Light Wavelength:** 395-400nm (for mosquito attraction)
- **Recommended Uses:** Indoor, Outdoor
- **UPC:** 791809184489

11. Warranty and Support

PALONE products are designed for quality and reliability. For any questions, technical support, or warranty claims, please contact PALONE customer service through the retailer's platform or the official PALONE website. Please retain your proof of purchase for warranty purposes.

© 2025 PALONE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question