

- Manuals.plus /
- > AXA /
 - > AXA Echo 15 Headlight User Manual

AXA 93915395WS

AXA Echo 15 Headlight User Manual

Model: 93915395WS

1. PRODUCT OVERVIEW

The AXA Echo 15 is a compact and robust LED headlight designed for bicycles. It provides a light output of 15 Lumens, creating a light cone of 35 meters, enhancing visibility and safety during cycling. This headlight is battery-powered and features a single light setting.



Image 1.1: Front view of the AXA Echo 15 Headlight, showcasing its compact design and clear lens.

2. INCLUDED COMPONENTS

Upon unpacking, ensure all the following components are present:

- AXA Echo 15 Headlight unit
- Mounting bracket (integrated or separate, as supplied)

3. SETUP AND INSTALLATION

The AXA Echo 15 Headlight is designed for frame mounting. Follow these steps for proper installation:

1. **Identify Mounting Location:** Choose a suitable location on your bicycle's front frame or fork crown. The headlight should be positioned to provide optimal forward illumination without obstructing other components.
2. **Attach Mounting Bracket:** Secure the headlight's mounting bracket to the chosen location using appropriate tools (not included). Ensure the bracket is firmly tightened to prevent movement during cycling.
3. **Insert Batteries:** The headlight is battery-powered. Locate the battery compartment, typically at the rear of the unit. Insert the required batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. **Adjust Angle:** Once mounted, adjust the angle of the headlight to illuminate the path ahead effectively. Avoid pointing the light too high, which could blind oncoming traffic, or too low, which would limit visibility.



Image 3.1: The AXA Echo 15 Headlight correctly mounted on the front fork of a bicycle.



Image 3.2: Rear view of the AXA Echo 15 Headlight, indicating the battery compartment and terminals.

4. OPERATING INSTRUCTIONS

The AXA Echo 15 Headlight features a simple operation with a single setting.

- **Power On/Off:** Locate the power button or switch on the headlight unit. Press or toggle it to turn the light on. Repeat the action to turn the light off.
- **Light Output:** The headlight provides a consistent 15 Lumens of light output when active. There are no adjustable brightness settings.

5. MAINTENANCE

To ensure the longevity and optimal performance of your AXA Echo 15 Headlight, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the lens and housing with a soft, damp cloth to remove dirt and debris. Avoid using abrasive cleaners or solvents, as these can damage the plastic components.
- **Battery Replacement:** When the light appears dim or fails to turn on, replace the batteries. Always use the recommended battery type and dispose of old batteries responsibly.
- **Water Resistance:** The headlight is rated IPX4, meaning it is resistant to splashing water from any direction. While it can withstand rain, avoid submerging the unit in water. Ensure the battery compartment cover is securely closed after battery changes to maintain water resistance.
- **Mounting Check:** Periodically check that the mounting bracket is secure and the headlight is firmly attached to your bicycle. Tighten any loose screws as needed.

6. TROUBLESHOOTING

If you encounter issues with your AXA Echo 15 Headlight, refer to the following common problems and solutions:

- **Light Does Not Turn On:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace the batteries with fresh ones.
 - Ensure the power button/switch is fully engaged.
- **Light is Dim:**
 - Batteries may be low. Replace them with fresh batteries.
 - Clean the headlight lens to remove any dirt or grime that might be obstructing the light output.
- **Headlight is Loose:**
 - Tighten the screws on the mounting bracket.
 - Ensure the bracket is properly seated on the bicycle frame.

7. SPECIFICATIONS

Feature	Specification
Brand	AXA
Model Number	93915395WS
Light Output Maximum	15 Lumens
Light Cone Distance	35 meters
Power Source	Battery Powered
Number of Settings	1
Mounting Type	Frame Mount
Water Resistance Level	Water Resistant (IPX4)
Color	Black
Material	Other
Auto Part Position	Front

8. WARRANTY INFORMATION

Please note that the AXA Echo 15 Headlight is sold without a manufacturer's guarantee. For specific return or replacement policies, please refer to the retailer's terms and conditions at the time of purchase.

9. SUPPORT

For further assistance, technical inquiries, or if you have questions not covered in this manual, please contact AXA customer support through their official website or the retailer from whom you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08VJ9ZR26>

More documents and user manuals: <https://manuals.plus/>