

[Manuals.plus](#) /

> [MENEEA](#) /

> MENEEA Cooling Fan and Charging Stand for Xbox Series X: Instruction Manual

MENEEA PG-XBX013

MENEEA Cooling Fan and Charging Stand for Xbox Series X: Instruction Manual

Model: PG-XBX013 | Brand: MENEEA

1. PRODUCT OVERVIEW

The MENEEA Cooling Fan and Charging Stand is a 5-in-1 accessory designed for the Xbox Series X console and controllers. It integrates a powerful cooling fan, dual controller charging docks, two 1400mAh rechargeable batteries, a headset stand, and storage for up to 10 game discs. This system helps optimize space and maintain console performance.



Image 1: Overview of the MENEAA Cooling Fan and Charging Stand components, including the main base, headset stand, rechargeable batteries, and the Xbox Series X console.

2. INCLUDED COMPONENTS

- 1 x Charging Stand with Cooling Fan for Xbox Series X
- 2 x 1400mAh Rechargeable Battery and Cover
- 1 x Headset Stand

3. SETUP INSTRUCTIONS

1. **Place the Console:** Carefully place your Xbox Series X console vertically onto the designated slot

on the charging stand. Ensure it is securely seated.

2. **Connect the Stand:** The stand connects to the Xbox Series X via a built-in USB connector. Align and insert the connector from the stand into the corresponding USB port on the back of your console.
3. **Attach Headset Stand:** Insert the headset stand into its designated slot on the main unit.
4. **Install Rechargeable Batteries:**
 - Open the battery compartment on your Xbox Series X controller.
 - Insert one of the provided 1400mAh rechargeable batteries into the compartment.
 - Replace the battery cover.
5. **Organize Games:** Utilize the 10 game disc storage slots on the side of the stand to keep your game collection organized.

Your browser does not support the video tag.

Video 1: Official MENEAA video demonstrating the assembly and setup of the Cooling Fan and Charging Stand for Xbox Series X Console. This video shows how to connect the console, install batteries in controllers, and place the headset.



Image 2: A visual representation of the Xbox Series X console, controllers, and headset neatly organized on the MENEAA vertical stand, highlighting its space-saving design.

4. OPERATING INSTRUCTIONS

1. Cooling Fan Operation:

The cooling fan is located on the side of the stand, designed to accelerate air circulation within the console. Press the dedicated button on the stand to turn the fan ON or OFF as needed. The metal base also contributes to cooling.



Image 3: A diagram illustrating the high-efficiency cooling system, showing how the side-mounted fan and metal base work together to dissipate heat from the Xbox Series X console.

2. Controller Charging:

Place controllers equipped with the rechargeable batteries into the dual charging slots. Ensure the Type-C interface on the battery pack aligns with the Type-C plug in the base.

- **Red LED Indicator:** Controller is currently charging.
- **Green LED Indicator:** Controller is fully charged or in standby mode.

Note: The charging indicator on this product may not always perfectly match the Xbox controller's internal charge status when nearly full. This is normal.



Image 4: Close-up of the dual charging slots with Xbox controllers, showing the LED indicators for charging status (red for charging, green for fully charged).

- Headset Storage:** Hang your gaming headset on the integrated headset stand for convenient storage and easy access.
- Additional USB Ports:** The stand includes additional USB ports. One port is for connecting to the console, and another can be used for charging other USB-powered devices like keyboards, phones, or tablets. Note that the extended USB port does not support data transmission.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the stand and console regularly. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** To prolong the life of the rechargeable batteries, avoid completely draining them before recharging. Store them in a cool, dry place when not in use for extended periods.
- **Airflow:** Ensure the cooling fan and console vents are free from dust and obstructions to maintain optimal airflow and cooling efficiency.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cooling fan not operating.	Not powered on; loose connection.	Ensure the stand is properly connected to the Xbox Series X USB port. Press the fan power button.

Problem	Possible Cause	Solution
Controllers not charging.	Improper placement; battery not installed correctly; console off.	Verify controllers are correctly seated in the charging slots. Ensure rechargeable batteries are properly installed. Note that charging stops when the console is fully off, but works in sleep mode.
LED indicator for charging is red even when controller is almost full.	Normal operation.	This is a normal phenomenon and does not indicate a fault. The product's indicator may not perfectly synchronize with the controller's internal status when near full charge.

7. SPECIFICATIONS

- **Model Number:** PG-XBX013
- **Brand:** MENEAA
- **Compatible Devices:** Xbox Series X Console, Xbox Series X Controller
- **Included Components:** Charging Stand with Cooling Fan, 2 x 1400mAh Rechargeable Battery and Cover, Headset Stand
- **Material:** Metal (base)
- **Color:** Black
- **Connector Type:** USB
- **Unit Count:** 1 Count

8. WARRANTY AND SUPPORT

This product comes with a 1-year warranty. For technical support, warranty claims, or further assistance, please contact MENEAA customer service through the retailer where the product was purchased or visit the official MENEAA website for contact information.