

[Manuals.plus](#) /

> [Yaheetech](#) /

> Yaheetech 144.5cm Multi-Level Cat Tree Instruction Manual (Model: MM-00101479-144)

Yaheetech MM-00101479-144

Yaheetech 144.5cm Multi-Level Cat Tree Instruction Manual

Model: MM-00101479-144

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, safe use, and maintenance of your Yaheetech 144.5cm Multi-Level Cat Tree. Designed to offer a stimulating and comfortable environment for small to medium-sized cats, this cat tree features multiple levels, scratching posts, condos, and perches. Please read these instructions carefully before assembly and use to ensure the safety and longevity of the product.





Image 1.1: The Yaheetech 144.5cm Multi-Level Cat Tree, showcasing its various platforms, condos, and scratching posts.

2. SAFETY INFORMATION

Adhering to these safety guidelines will help prevent accidents and ensure the well-being of your pets and household.

- **Keep the cat tree dry:** Moisture can damage the materials and compromise the structural integrity.
- **Pay attention to fire hazards:** Keep the cat tree away from open flames, heaters, or other heat sources.
- **Keep the cat tree clean:** Regular cleaning ensures a hygienic environment for your beloved cat.
- **Measurement tolerance:** Please allow a 1cm (0.5 inch) measurement tolerance for all dimensions.
- **Secure to wall:** For enhanced stability and safety, especially with active cats, utilize the provided anti-toppling strap to secure the cat tree to a wall.



Image 2.1: Illustration of the anti-toppling strap being secured to the wall, demonstrating how to enhance the cat tree's stability.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. The package should contain:

- 1 x Yaheetech Multi-Level Cat Tree (all structural components)
- 1 x Assembly Instructions Manual
- 1 x Accessory Kit (including screws, tools, and anti-toppling strap)

4. SPECIFICATIONS

Feature	Detail
---------	--------

Overall Dimensions	49 cm L x 49 cm W x 144.5 cm H (19.5 in L x 19.5 in W x 57 in H)
Small Condo Size	28 cm L x 28 cm W x 24 cm H (11 in L x 11 in W x 9.4 in H)
Big Condo Size	45.5 cm L x 28 cm W x 24 cm H (18 in L x 11 in W x 9.4 in H)
Scratching Board Size	20.5 cm W x 38 cm H (8 in W x 15 in H)
Round Platform Diameter	29.5 cm (11.6 in)
Maximum Load Bearing	45 kg (99.2 lb)
Net Weight	13.8 kg (30.4 lb)
Materials	Particle board, paper, plush, sisal rope, plastic
Color	Dark Grey
Breed Recommendation	Small Breeds / Small to Medium Cats




Image 4.1: Detailed diagram illustrating the dimensions of the Yaheetech Multi-Level Cat Tree.

5. SETUP AND ASSEMBLY

Assembly of the Yaheetech Cat Tree is designed to be straightforward. Please follow the step-by-step instructions provided in the separate Assembly Instructions Manual included in your package. Ensure you have adequate space and all components before starting.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Check against the parts list in the Assembly Instructions Manual.
2. **Follow Manual Steps:** Assemble the cat tree according to the numbered steps in the dedicated Assembly Instructions Manual. Use the provided accessory kit for all connections.

3. **Tighten Connections:** Ensure all screws and fasteners are securely tightened to maintain stability. Do not overtighten.
4. **Install Anti-Toppling Strap:** Once assembled, position the cat tree in its desired location. Attach the anti-toppling strap to a wall stud or appropriate anchor point to prevent accidental tipping. Refer to Image 2.1 for guidance.



Image 5.1: A collage showcasing various features of the cat tree, including perches, condos, and scratching areas.

6. OPERATING INSTRUCTIONS

The Yaheetech Multi-Level Cat Tree offers various features for your cat's entertainment and comfort:

- **Scratching Posts:** The sisal rope-covered posts are designed for your cat to sharpen their claws, diverting attention from furniture. Encourage use by gently guiding your cat's paws to the posts.
- **Condos:** Two enclosed condos provide private, cozy spaces for napping and hiding. The lower condo features two entry/exit points.

- **Perches and Platforms:** Multiple elevated platforms and perches allow your cat to observe their surroundings from a height, satisfying their natural climbing instincts.
- **Hanging Toys:** The included fur balls are designed to engage your cat in playful activity. These are replaceable and removable.
- **Ladder/Ramp:** The integrated ladder provides easy access to different levels, especially for kittens or less agile cats.



Image 6.1: A cat comfortably resting inside one of the plush condos, highlighting the cozy interior.



Image 6.2: Close-up view of the replaceable and removable dangling ball, a feature for interactive play.

7. MAINTENANCE

Regular maintenance will extend the life of your cat tree and keep it hygienic for your pet.

- **Cleaning:** Use a lint roller or a soft brush to remove loose fur and debris from the plush surfaces. For spot cleaning, use a damp cloth with mild soap and water, then allow to air dry completely. Avoid harsh chemicals.
- **Inspect for Wear:** Periodically check the sisal scratching posts for significant wear. While designed to be durable, heavily used posts may eventually need replacement.
- **Check Stability:** Regularly inspect all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected. Verify the anti-toppling strap is still securely attached.
- **Replace Toys:** If the dangling toys become damaged or detached, they can be replaced to maintain your cat's interest.



Image 7.1: Detail showing the natural sisal rope used for scratching posts and the eco-friendly particle board construction.

8. TROUBLESHOOTING

- **Cat Tree is Wobbly:** Ensure all screws are fully tightened. Verify the anti-toppling strap is correctly installed and secured to a stable wall.
- **Cats Not Using Scratching Posts:** Try sprinkling catnip on the sisal posts or gently guiding your cat's paws to demonstrate. Ensure the posts are stable and appealing.
- **Dangling Toys Detached:** Reattach the toys if possible. If damaged, consider replacing them with new cat-safe toys.
- **Parts Missing or Damaged:** Refer to the warranty and support section to contact customer service for assistance.

9. WARRANTY AND SUPPORT

For any questions regarding assembly, missing parts, or product performance, please refer to the contact information

provided with your purchase documentation or visit the official Yaheetech website for customer support. Please have your model number (MM-00101479-144) and purchase details ready when contacting support.

© 2023 Yaheetech. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08VN3RBBW>

More documents and user manuals: <https://manuals.plus/>