Bajaj Pygmy Mini

Bajaj Pygmy Mini Fan 110MM Instruction Manual

Model: Pygmy Mini (Item Model Number: 251268)

Introduction

Thank you for purchasing the Bajaj Pygmy Mini Fan. This portable, rechargeable fan is designed to provide personal cooling with convenience and efficiency. Featuring a multi-clip function, USB charging, and a 4-hour battery backup, it is suitable for various indoor environments. Please read this manual carefully before use to ensure proper operation and maintenance.



Image: Bajaj Pygmy Mini Fan showing its dimensions (9.5D x 15.8W x 20.4H Centimeters).

Product Features

- **Li-Ion Battery:** Provides up to 4 hours of battery backup for continuous operation during power outages.
- **Multi-Utility Clamp Mechanism:** Allows for both table-top and wall-mounted operation.
- **USB Charging:** Easy charging compatibility with standard USB power cables.
- **Three Speed Settings:** Adjust airflow to your preference.
- **Compact and Portable:** With dimensions of 158 L x 95 W x 204 H MM, it offers instant comfort and high air thrust in a small form factor.
- **Silent Operation:** Engineered for low noise levels (8 Decibels).

- **Energy Efficient:** Designed for low power consumption.
- **Adjustable Tilt:** Fan head can be tilted to direct airflow.






Image: Front and angled views of the Bajaj Pygmy Mini Fan, highlighting its compact design.

Setup

1. **Unboxing:** Carefully remove the fan and all accessories from the packaging. Ensure all components are present: the fan unit and a USB charging cable.
2. **Placement:**
    - **Table-top:** Place the fan on a stable, flat surface.
    - **Clip-on:** Use the integrated multi-utility clamp to securely attach the fan to a desk, shelf, or other suitable surface. Ensure the clamp is firmly attached before use.
3. **Initial Charge:** Before first use, fully charge the fan. Connect the provided USB charging cable to the fan's charging port and plug the other end into a compatible USB power adapter (not included) or a computer USB port. The charging indicator light will show the charging status. A full charge typically takes approximately 4 hours if completely discharged.


BAJAJ



Image: The fan demonstrating its clip-on functionality on a table, and a rear view showing the USB charging port.

Operating Instructions

1. **Power On/Off:** Press the power button located on the fan to turn it on. Press it again to cycle through speed settings and to turn it off.
2. **Adjusting Fan Speed:** The fan has three speed settings. Each press of the power button will cycle to the next speed level (Low > Medium > High). After the highest speed, pressing the button again will turn the fan off.
3. **Adjusting Airflow Direction:** The fan head can be manually tilted up or down to direct the airflow as desired.
4. **Charging During Operation:** It is recommended not to operate the fan while it is charging to ensure optimal battery life and charging efficiency.
5. **LED Indicator:** The fan features an LED indicator that shows charging status and potentially speed settings (refer to product for specific LED behavior).

Maintenance

- **Cleaning:**
  - Ensure the fan is turned off and unplugged before cleaning.
  - The front grill is detachable for easy cleaning. Gently remove the front grill to access the fan blades.
  - Wipe the fan blades and housing with a soft, damp cloth. Do not use abrasive cleaners or immerse the fan in water.
  - Allow all parts to dry completely before reassembling and using the fan.
- **Battery Care:**
  - To prolong battery life, avoid completely draining the battery frequently.
  - If storing the fan for an extended period, charge it to about 50% every three months.

Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is discharged. Power button not pressed correctly.	Charge the fan using the USB cable. Ensure the power button is pressed firmly.
Low air throw.	Fan blades are dirty. Fan is on a low-speed setting.	Clean the fan blades as per maintenance instructions. Increase the fan speed using the power button.
Battery not charging.	USB cable or adapter is faulty. Charging port is damaged.	Try a different USB cable and power adapter. Contact customer support if the issue persists.
Unusual noise during operation.	Obstruction in fan blades. Fan not placed on a stable surface.	Turn off and unplug the fan, then check for any obstructions and remove them. Ensure the fan is on a stable, flat surface or securely clipped.

If you encounter any issues not listed here or if the problem persists after attempting the solutions, please contact Bajaj customer support.

Specifications

Feature	Detail
Brand	Bajaj
Model Name	Pygmy Mini
Item Model Number	251268
Colour	White Smoke
Electric Fan Design	Table Fan
Power Source	Electric (USB Powered)
Product Dimensions	9.5D x 15.8W x 20.4H Centimeters
Special Features	Adjustable Tilt, Lightweight, Portable, Rechargeable battery, USB Powered
Noise Level	8 Decibels
Wattage	10 Watts
Number of Blades	3
Blade Length	110 Millimetres
Speed Settings	3 (Levels)
Voltage	5 Volts
Switch Type	Push Button
Item Weight	410 Grams
Included Components	Fan unit, USB charging cable
Indoor/Outdoor Usage	Indoor
Control Method	Push Button
Efficiency	Energy Efficient
Is It Cordless?	Yes
Country of Origin	China

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Bajaj Electricals website. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: Bajaj Electricals

Contact Information:

Address: M/S. Bajaj Electricals Ltd, #45/47 Veer Nariman Road, Mumbai - 40001

Phone: 022-41280000

Email: customercare@bajajelectricals.com

For further assistance or service requests, please contact the customer care team.

© 2026 Bajaj Electricals. All rights reserved.