

ZURU 100183

ZURU Sparkle Girlz Bake Off Doll Playset Instruction Manual

Model: 100183

PRODUCT OVERVIEW

The ZURU Sparkle Girlz Bake Off Playset offers a comprehensive baking experience with a 10.5-inch doll and 30 accessories. This set allows children to engage in imaginative play by mixing, making, and baking sweet treats in a miniature kitchen environment.

What's Included:

- 1x Sparkle Girlz 10.5" Doll
- 1x Removable Outfit
- 1x Apron
- 1x Baker's Hat
- 1x Pair of Shoes
- 4x Toy Doughs
- 1x Kitchen Set
- 1x Rolling Pin
- 1x Spatula
- 1x Spinning Mixing Bowl
- 1x Cupcake Tray
- 1x Oven Mitt
- 3x Toy Dough Cookie Cutters
- 1x Toy Dough Rolling Pin
- 1x Cake Decorator Mold
- 1x Toy Dough Cutter
- 1x Icing Tube
- 3x Icing Tube Toppers

SAFETY INFORMATION

CHOKING HAZARD: Small parts. Not for children under 3 years.

Manufacturer recommended age: 36 months - 15 years.

SETUP

Unpack all components from the packaging. Ensure all listed accessories are present. No complex assembly is required; the kitchen set is designed for immediate play.



Figure 1: Side view of the Sparkle Girlz Bake Off Playset, featuring the doll and kitchen setup.



Figure 2: Back view of the playset box, highlighting various kitchen features and accessories.

OPERATING INSTRUCTIONS

Preparing the Dough:

1. Select one of the four toy doughs provided.
2. Use the toy dough rolling pin to flatten the dough.
3. Utilize the cookie cutters to create various shapes for your treats.



Figure 3: The four containers of toy dough included in the playset.



Figure 4: Demonstrating the use of the toy rolling pin to flatten dough.



Figure 5: Using a cookie cutter to create a dough shape.

Baking and Decorating:

1. Place your shaped dough treats into the oven. The oven door opens for realistic play.

2. Use the spinning mixing bowl to simulate mixing ingredients.
3. Decorate your baked goods using the icing tube and its toppers.



Figure 6: The Sparkle Girlz doll using the oven mitt to place items into the oven.



Figure 7: A hand demonstrating the use of the dough cutter for precision shaping.

Interactive Play:

- The kitchen set includes a sink and an opening cupboard for cleanup and storage.
- Engage the Sparkle Girlz doll in various baking scenarios.



Figure 8: A child interacting with the playset, showcasing the doll and kitchen accessories.

MAINTENANCE

Cleaning the Playset:

- Wipe down all plastic surfaces with a damp cloth as needed.
- Ensure all toy dough is stored in its original containers after play to prevent drying out.
- The kitchen sink can be used for pretend cleanup.

TROUBLESHOOTING

Dough Consistency:

- If toy dough becomes stiff, try kneading it with slightly damp hands to restore pliability.
- Always store dough in airtight containers to maintain freshness.

SPECIFICATIONS

Feature	Detail
Product Dimensions	15.75 x 3.35 x 12.2 inches
Item Weight	10 pounds
Item Model Number	100183
Manufacturer	ZURU
Recommended Age	36 months - 15 years

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official ZURU website. Keep your purchase receipt for any warranty claims.