

[Manuals.plus](#) /

› [Timco](#) /

› Timco HC-116 Professional Hair Trimmer and Finisher Instruction Manual

Timco HC-116

Timco HC-116 Professional Hair Trimmer and Finisher Instruction Manual

Model: HC-116

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Timco HC-116 Professional Hair Trimmer and Finisher. Please read this manual thoroughly before operating the device and retain it for future reference. This versatile tool is designed for professional hair cutting, finishing, and beard maintenance.

SAFETY INFORMATION

- Always ensure the device is unplugged before cleaning or performing any maintenance.
- Do not immerse the trimmer in water or other liquids.
- Keep the device away from children.
- Use only the accessories provided or recommended by Timco.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PACKAGE CONTENTS

Upon unpacking, please verify that all items listed below are included:

- Timco HC-116 Professional Hair Trimmer
- 5 Guide Combs (#0, #1, #2, #3, #4)
- Blade Oil

- Cleaning Brush
- Blade Protector
- Instruction Manual (this document)

PRODUCT OVERVIEW

The Timco HC-116 is a compact and powerful hair trimmer designed for precision. Its ergonomic design ensures comfortable handling during use.



Figure 1: Front view of the Timco HC-116 Hair Trimmer.







Figure 2: Back view of the Timco HC-116 Hair Trimmer.

Key Features:

- **Detachable Blade:** For easy cleaning and maintenance.
- **Powerful Rotary Motor:** Ensures efficient and precise cutting.
- **Versatile Use:** Suitable for trimming, finishing, and beard grooming.
- **Compact Design:** Measures approximately 12cm (Height) x 3.5cm (Width) x 4cm (Length).
- **Stainless Steel Blade:** Durable and sharp for consistent performance.

SETUP

1. **Unpack the Trimmer:** Carefully remove all components from the packaging.
2. **Inspect for Damage:** Check the trimmer and accessories for any signs of damage. Do not use if damaged.
3. **Connect to Power:** Plug the trimmer's power cord into a suitable electrical outlet. The trimmer operates via electric cable and does not require batteries.
4. **Attach Guide Comb (Optional):**





Figure 3: Timco HC-116 Hair Trimmer with guide combs.



Figure 4: Included guide combs for length adjustment.

To adjust the cutting length, select one of the 5 provided guide combs (#0, #1, #2, #3, #4). Align the comb with the trimmer blade and push it firmly until it clicks into place. Ensure it is securely attached before use. To remove, gently pull the comb away from the blade.

5. **Apply Blade Oil:** Before first use, apply a small drop of the included blade oil to the teeth of the blade. This ensures smooth operation and prolongs blade life.

OPERATING INSTRUCTIONS

General Operation:

1. Ensure the trimmer is properly set up as described in the "Setup" section.
2. Press the power button to turn the trimmer ON.
3. Hold the trimmer firmly and guide it through the hair against the direction of hair growth.
4. Use smooth, even strokes for best results.
5. Press the power button again to turn the trimmer OFF after use.

Specific Uses:

- **Hair Cutting and Finishing:** Use the appropriate guide comb for desired hair length. For detailed finishing work, the trimmer can be used without a guide comb for close cuts.
- **Beard Trimming and Maintenance:** Select a guide comb to maintain your desired beard length. For outlining and detailing, remove the guide comb and carefully use the blade edge.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your Timco HC-116 trimmer.

1. **Cleaning the Blade:**
 - Ensure the trimmer is unplugged.
 - The blade is detachable for easy cleaning. Gently push the blade assembly forward to detach it from the trimmer body.
 - Use the provided cleaning brush to remove any hair clippings from the blade and the trimmer head.
 - Reattach the blade by aligning it and pushing it back until it clicks securely into place.
2. **Oiling the Blade:**
 - After each cleaning, or at least once a month with regular use, apply 1-2 drops of blade oil across the teeth of the blade.
 - Turn the trimmer on for a few seconds to distribute the oil evenly.
 - Wipe off any excess oil with a soft cloth.
3. **Storage:**
 - Store the trimmer in a dry place, away from moisture.
 - Use the blade protector to cover the blade when not in use to prevent damage and keep it clean.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working electrical outlet. Test the outlet with another appliance.
Trimmer pulls hair or cuts poorly.	Blades are dull; blades are dirty/clogged; insufficient oil.	Clean the blades thoroughly with the cleaning brush. Apply blade oil. If the problem persists, the blades may need replacement.

Problem	Possible Cause	Solution
Excessive noise or vibration.	Blades are not properly aligned or secured; lack of lubrication.	Ensure the detachable blade is securely attached. Apply blade oil. If the issue continues, contact customer support.

SPECIFICATIONS

- **Model:** HC-116
- **Brand:** Timco
- **Power Source:** Electric Cable
- **Blade Material:** Stainless Steel
- **Dimensions (L x W x H):** 40 x 38 x 120 millimeters (approx. 4cm x 3.8cm x 12cm)
- **Special Feature:** Detachable Blade
- **Included Accessories:** 5 Guide Combs, Blade Oil, Cleaning Brush, Blade Protector
- **Target Audience:** Men, Women
- **Batteries Required:** No

CUSTOMER SUPPORT

For further assistance, questions, or warranty information, please contact Timco customer service. Refer to your product packaging or the official Timco website for contact details.

Note: This product is from a small business. Your support is appreciated.

