

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Legami](#) /
- › [Legami Singing in the Shower Bluetooth Speaker User Manual](#)

## Legami SHOW0005

# Legami Singing in the Shower Bluetooth Speaker

MODEL: SHOW0005

Brand: Legami

## INTRODUCTION

Thank you for purchasing the Legami Singing in the Shower Bluetooth Speaker. This device is designed to provide a hands-free audio experience in wet environments, featuring a built-in microphone for calls and a suction cup for easy mounting. Please read this manual carefully to ensure proper use and maintenance of your speaker.

## PRODUCT OVERVIEW AND PACKAGE CONTENTS

Before you begin, please check the package contents.

### Package Contents:

- Legami Singing in the Shower Bluetooth Speaker
- USB Charging Cable
- Integrated Suction Cup

### Speaker Components:



**Figure 1: Front View.** Shows the speaker's top surface with integrated control buttons for power, play/pause, track navigation, and call management. The speaker features a white body with colorful raindrop patterns and the text "AFTER RAIN comes THE RAINBOW".




**Figure 2: Side View.** Displays the side of the speaker, revealing the DC 5V USB charging port, protected by a rubber flap.



**Figure 3: Bottom View.** Illustrates the transparent suction cup attached to the base of the speaker, designed for secure mounting on smooth surfaces.



**Figure 4: USB Charging Cable.** The included USB cable for charging the speaker.



**Figure 5: Control Diagram.** A detailed diagram from the product packaging illustrating the functions of each button: Power (ON/OFF), Play/Pause, Rewind (short press) / Volume Down (long press), Forward (short press) / Volume Up (long press), and Pick Up/End Call. It also shows the DC 5V slot, USB cable inclusion, and built-in microphone.

## SETUP GUIDE

### 1. Charging the Speaker:

1. Locate the DC 5V charging port on the side of the speaker (refer to Figure 2).
2. Open the protective rubber flap.
3. Connect the supplied USB charging cable to the speaker's port and the other end to a USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light will illuminate. Charging takes approximately 1 hour.
5. Once fully charged, the indicator light will change or turn off. Disconnect the cable and close the rubber flap to maintain water resistance.

*Note: A full charge provides up to 2 hours of playback time.*

### 2. Bluetooth Pairing:

1. Ensure the speaker is fully charged.
2. Press and hold the **Power button**  on the speaker's top surface for a few seconds until you hear an audible prompt or see an indicator light flashing, indicating it's in pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
4. Search for available devices. The speaker should appear as "Legami Singing in the Shower" or a similar name.
5. Select the speaker from the list to initiate pairing.
6. Once paired, you will hear a confirmation sound, and the indicator light will stop flashing.

*Note: The speaker has a maximum range of 10 meters (33 feet) from the paired device.*

### 3. Mounting the Speaker:

- Ensure the surface where you intend to mount the speaker is clean, smooth, and dry (e.g., shower wall, tile, glass).
- Press the integrated suction cup firmly against the desired surface until it adheres securely.
- To remove, gently pull the edge of the suction cup to release the vacuum.

## OPERATING INSTRUCTIONS

### Power On/Off:

- To turn **ON**: Press and hold the **Power button**  for approximately 3 seconds.
- To turn **OFF**: Press and hold the **Power button**  for approximately 3 seconds.

### Music Playback:

- **Play/Pause**: Press the **Play/Pause button**  once to play or pause music.
- **Next Track**: Short press the **Forward button** .
- **Previous Track**: Short press the **Rewind button** .
- **Volume Up**: Long press the **Forward button** .
- **Volume Down**: Long press the **Rewind button** .

### Call Management (Hands-Free Function):

- **Answer Call**: Press the **Call button**  once when a call comes in.
- **End Call**: Press the **Call button**  once during a call.
- **Reject Call**: Press and hold the **Call button**  for approximately 2 seconds when a call comes in.
- **Redial Last Number**: Double-press the **Call button** .

*The integrated microphone allows for clear communication during calls.*

## MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the charging port's rubber flap is securely closed before exposing the speaker to water.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.
- **Suction Cup Care:** For optimal adhesion, periodically clean the suction cup and the mounting surface.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in constant use.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker fully (approx. 1 hour).
Cannot pair with device.	Bluetooth is off on your device; speaker is not in pairing mode; speaker is already paired with another device; devices are too far apart.	Ensure Bluetooth is enabled on your device. Turn the speaker off and on again to enter pairing mode. Disconnect from other devices. Ensure devices are within 10 meters.
No sound or low volume.	Volume on speaker or device is too low; speaker is not connected; audio source issue.	Increase volume on both the speaker and your connected device. Ensure the speaker is successfully paired. Try playing audio from a different application or device.
Call quality is poor.	Speaker is too far from mouth; environmental noise; weak Bluetooth connection.	Speak closer to the speaker. Reduce background noise. Ensure stable Bluetooth connection.
Suction cup not holding.	Surface is not clean, smooth, or dry; suction cup is dirty.	Clean both the surface and the suction cup thoroughly. Ensure the surface is completely dry.

## SPECIFICATIONS

<b>Model Number</b>	SHOW0005
<b>Brand</b>	Legami
<b>Dimensions (L x W x H)</b>	8.5 x 5 x 8.5 cm (3.35 x 1.97 x 3.35 inches)
<b>Weight</b>	170 Grams (0.37 lbs)

<b>Material</b>	ABS and Silicone
<b>Connectivity Technology</b>	Bluetooth, USB
<b>Bluetooth Range</b>	Up to 10 meters (33 feet)
<b>Battery Life</b>	Up to 2 hours playback
<b>Charging Time</b>	Approximately 1 hour
<b>Water Resistance</b>	Yes (Water-resistant)
<b>Speaker Output Power</b>	5 Watts
<b>Audio Output Mode</b>	Stereo
<b>Compatible Devices</b>	Desktop computer, Laptop, Smartphone, Tablet
<b>Special Features</b>	Bluetooth, Integrated Microphone

## WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Legami website. Keep your proof of purchase for any warranty claims.

### Online Resources:

- [Legami Official Website](#)