

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZONETECH](#) /

› [ZONETECH 12V Car Heated Steering Wheel Cover Instruction Manual](#)

ZONETECH WC0012-G

ZONETECH 12V Car Heated Steering Wheel Cover Instruction Manual

Model: WC0012-G

Brand: ZONETECH

INTRODUCTION

This manual provides instructions for the safe and effective use of your ZONETECH 12V Car Heated Steering Wheel Cover. Please read thoroughly before installation and operation to ensure proper function and safety.

SAFETY INFORMATION

- Do not use the heated steering wheel cover if it slides or does not fit securely on your steering wheel.
- It is prohibited to adjust the product while driving. Ensure all connections are secure before starting your journey.
- Keep the product away from fire sources and flammable materials.
- Always unplug the 12V DC car plug when the vehicle is off or not in use to prevent draining your car battery.
- If the magnetic connector cannot return to the heating state while driving, ignore it and concentrate on driving. Reinstall after stopping the car.
- Ensure the magnetic head is fully aligned for normal operation.

PRODUCT FEATURES

- **Warm Ride:** Provides warmth and comfort in cold weather. Plugs into a standard 12V cigarette lighter adapter.
- **Breathable Layer:** Microfiber and mesh construction allows air circulation for comfortable warmth.
- **Premium Quality:** Constructed from durable materials for long-lasting use throughout the winter and beyond.
- **Universal Fit:** Designed to fit most steering wheels with a diameter of 14.5 to 15 inches, providing a snug fit.
- **Automatic Temperature Regulation:** An integrated thermostat automatically regulates the temperature from 90°F (32°C) up to 110°F (43°C).

PACKAGE CONTENTS

Verify that all items are included in your package:

- 1 x ZONETECH Heated Steering Wheel Cover
- 1 x 12V DC Car Plug with Spiral Spring Cable
- 1 x USB Power Cable (for magnetic connection)
- Cable Ties (quantity may vary, typically 6-8 for securing cables)
- Tape Pads (for securing magnetic connector)

SETUP AND INSTALLATION

1. **Install Cover:** Carefully pull the heated steering wheel cover over your vehicle's steering wheel. Ensure the seam is positioned at the top and the stitching is on the right side for proper alignment of the magnetic connector.

PERFECT FOR DRIVING
Best Driving Experience



**SOFT
MATERIAL**



**HEATING
PLUG**



**12V DC
CAR PLUG**

Image: Person installing the black heated steering wheel cover onto a car's steering wheel.

2. **Secure Magnetic Connector:** Identify the magnetic connector on the cover. Use the provided cable ties to secure both ends of the magnetic connector's wire to the steering wheel column, ensuring it is kept in a straight line and at the same height. If there is a height difference, use the provided tape pads to raise the lower end for proper alignment.



Image: Close-up showing the magnetic connector being secured to the steering wheel column with cable ties and tape pads.

3. **Connect Power:** Plug the 12V DC car plug into your vehicle's cigarette lighter adapter.

EASY TO INSTALL

3 Steps Process Which
Takes 1-2 Minutes




Image: The 12V DC car plug being inserted into a car's cigarette lighter socket.

4. **Connect USB (if applicable):** Connect the USB power cable to the magnetic connector on the steering wheel cover. The blue light on the USB cable will illuminate when power is connected.

RELAXING WARM

Constant Temperature &
Voltage Protection



Image: Close-up showing the USB cable connected to the magnetic part of the steering wheel cover, with a blue light indicating power.

Note: Use at least 3 cable ties to prevent slippage. The wire should be secured in the middle of the Velcro strap.

OPERATING INSTRUCTIONS

1. Once installed and plugged in, the steering wheel cover will begin to heat.
2. The thermostat automatically regulates the temperature between 90°F (32°C) and 110°F (43°C).
3. Heating time may vary depending on your vehicle's battery life and ambient temperature. Newer vehicles may heat faster. Expect approximately 1-2 minutes for the cover to reach optimal warmth.
4. For driving, ensure the spiral cord is positioned to allow full range of motion for the steering wheel without obstruction.

Video: Demonstrates the VaygWay Car Heated Steering Wheel Cover, showing its features and how it provides warmth.

Video: Shows the universal fit and heating function of the heated steering wheel cover.

Video: Highlights the 12V power and heating capabilities of the steering wheel cover.

Video: Provides installation instructions for a heated steering wheel cover, demonstrating how to secure it.

MAINTENANCE

- The soft microfiber material can be cleaned. For best results, follow any specific care instructions provided on the product label.
- If any adhesive residue is left from tape pads during installation or removal, it can typically be wiped off with a wet wipe.

TROUBLESHOOTING

Problem	Solution
Cover is not heating.	Check the 12V DC car plug connection. Ensure your vehicle is running or accessory power is on. Verify the magnetic connector is properly aligned and connected.
Power cord gets in the way while driving.	Ensure the spiral cord is routed to allow full steering wheel movement without obstruction. Use the provided cable ties to secure the cord away from moving parts and your hands.
Cover does not fit or is too loose/tight.	Ensure your steering wheel diameter is between 14.5 and 15 inches. Installation may require some effort for a tight fit. If it's too loose, it may slide and should not be used.
Magnetic connector disconnects during turns.	Re-secure the magnetic connector with tape pads and cable ties, ensuring proper alignment. If it frequently disconnects, re-evaluate the cable routing to minimize tension.
Product drains car battery.	Always unplug the 12V DC car plug when the vehicle is off or not in use. This product draws power continuously when plugged in.

SPECIFICATIONS

- **Model Number:** WC0012-G
- **Power Input:** 12V DC
- **Material:** Microfiber
- **Color:** Black
- **Item Diameter:** 15 Inches
- **Temperature Range:** 90°F (32°C) to 110°F (43°C) (automatically regulated)
- **Item Weight:** 1.46 pounds
- **Product Dimensions:** 16.69 x 13.35 x 2.2 inches

WARRANTY

Warranty information for the ZONETECH 12V Car Heated Steering Wheel Cover is not explicitly provided in the product details. Please refer to the retailer's return policy or contact ZONETECH customer support for specific warranty details.

CUSTOMER SUPPORT

For further assistance, technical support, or any inquiries regarding your ZONETECH 12V Car Heated Steering Wheel Cover, please contact ZONETECH customer support through their official channels or the retailer where the product was purchased.

