BITUXX LEX21

BITUXX LEX21 Stackable Shoe Box Set Instruction Manual

Brand: BITUXX | **Model:** LEX21 (Model Number: 18236)

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your BITUXX LEX21 Stackable Shoe Box Set. Please read these instructions carefully before use to ensure proper functionality and longevity of the product. This set includes three individual shoe boxes designed for organized storage.

2. Safety Information

- Keep all packaging materials away from children to prevent choking hazards.
- Ensure all components are securely connected during assembly to prevent collapse.
- Do not overload the shoe boxes. Adhere to the recommended shoe size (up to EU size 47).
- Avoid placing heavy objects on top of stacked boxes that could compromise stability.
- This product is intended for indoor use only.

3. Package Contents

Your BITUXX LEX21 Stackable Shoe Box Set (Model 18236) includes the following components for three shoe boxes:

- 3 x Front Panels (with magnetic closure)
- 3 x Back Panels
- 6 x Side Panels
- 3 x Top Panels
- 3 x Bottom Panels

4. Assembly Instructions

The BITUXX LEX21 shoe boxes feature a simple click-together assembly. Follow these steps for each box:

1. **Prepare Panels:** Lay out one bottom panel, one top panel, two side panels, one front panel, and one back panel for a single box.

2. **Attach Side Panels:** Connect the two side panels to the grooves on the bottom panel. Ensure they click firmly into place.
3. **Attach Back Panel:** Slide the back panel into the grooves of the side panels and the bottom panel. Press firmly until it clicks.
4. **Attach Top Panel:** Place the top panel onto the assembled sides and back, aligning the grooves. Press down until all connections click securely.
5. **Install Front Panel:** Align the front panel with the opening. The magnetic closure mechanism should face outwards. Insert the tabs on the front panel into the corresponding slots on the top and bottom edges of the box opening. Push until it clicks into place.
6. **Verify Assembly:** Gently test the stability of the assembled box and the functionality of the magnetic front door.

Repeat these steps for the remaining two shoe boxes.



Image: An assembled shoe box with its front door open, illustrating the access point.



Image: Detail of the magnetic closure, showing how the door secures.

5. Operating Instructions

- **Placing Shoes:** Open the front door by gently pulling it forward. Place one pair of shoes inside the box. Close the door, ensuring the magnetic closure engages.
- **Stacking Boxes:** The BITUXX LEX21 shoe boxes are designed to be stackable. Align the bottom of an upper box with the top of a lower box. The integrated grooves will interlock, providing stability for vertical stacking.
- **Visibility:** The transparent front and side panels allow for easy identification of the shoes stored inside without needing to open the box.



Image: Two shoe boxes demonstrating the stackable design, with shoes visible inside.

6. Maintenance and Care

- **Cleaning:** Wipe the shoe boxes with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Avoid abrasive cleaners or harsh chemicals, as these may damage the plastic.
- **Drying:** Ensure the boxes are completely dry before storing shoes or stacking.
- **Ventilation:** The boxes feature small ventilation holes to help prevent odor buildup. Ensure these holes are not obstructed.

7. Troubleshooting

- **Box is unstable:** Ensure all panels are fully clicked into their respective grooves. Disassemble and reassemble if necessary, applying firm pressure.

- **Front door does not close properly:** Check for any obstructions around the door frame or the magnetic closure. Ensure the door is correctly aligned in its slots.
- **Boxes do not stack securely:** Verify that the top and bottom panels of adjacent boxes are correctly aligned and interlocked.

8. Specifications

Brand	BITUXX
Model	LEX21 (18236)
Material	Plastic
Color	White
Dimensions (L x W x H)	36 x 21 x 26 cm (per box)
Weight	Approximately 3.06 kg (for the set of 3)
Special Features	Stackable, Transparent, Magnetic Closure

9. Warranty and Support

For warranty information or technical support, please refer to the purchase documentation or contact your retailer. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question