

[Manuals.plus](#) /

› [ZEBRONICS](#) /

› ZEBRONICS Zeb Buds 20 Wired Earphones User Manual

ZEBRONICS ZEB-BUDS 20

ZEBRONICS Zeb Buds 20 Wired Earphones User Manual

Model: ZEB-BUDS 20

1. INTRODUCTION

Thank you for purchasing the ZEBRONICS Zeb Buds 20 wired stereo earphones. These in-ear earphones are designed for clear audio playback and convenient communication, featuring a built-in microphone and in-line volume control. This manual provides essential information for proper setup, operation, and maintenance of your earphones.



Image 1.1: Overview of the ZEBRONICS Zeb Buds 20 wired earphones in red.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 unit of ZEBRONICS Zeb Buds 20 Earphone

3. PRODUCT OVERVIEW

The Zeb Buds 20 earphones are equipped with features for an optimal audio experience and ease of use.

3.1 Key Components

- **In-Ear Design:** Ergonomically shaped earbuds for a comfortable and secure fit.
- **14mm Drivers:** Large drivers for enhanced audio output.
- **In-line Microphone:** Integrated microphone for hands-free calling.
- **In-line Volume Controller:** Buttons for adjusting audio volume and managing calls/media playback.
- **3.5mm Audio Jack:** Standard connector for wide compatibility with various devices.
- **1.2 Metre Braided Cable:** Durable and tangle-free cable for extended use.




Image 3.1: Detail of the metallic design on the earbud housing.



Image 3.2: Illustration of the 1.2 meter cable length.

4. SETUP

Setting up your Zeb Buds 20 earphones is a simple process.

4.1 Connecting to a Device

1. Locate the 3.5mm audio jack on your audio device (smartphone, tablet, laptop, etc.).
2. Insert the 3.5mm connector of the Zeb Buds 20 earphones firmly into the audio jack of your device.
3. Ensure the connection is secure for optimal audio quality.



Image 4.1: The 3.5mm audio jack for connecting to devices.

5. OPERATING INSTRUCTIONS

The in-line remote provides convenient control over your audio and calls.

5.1 In-line Control Functions

- **Volume Up (+):** Press to increase audio volume.
- **Volume Down (-):** Press to decrease audio volume.
- **Multi-function Button (Center):**
 - Single press: Play/Pause music, Answer/End calls.
 - Double press: Skip to the next track.
 - Triple press: Go to the previous track.
 - Long press: Activate voice assistant (if supported by your device).



Image 5.1: The in-line remote control for media and call management.

6. MAINTENANCE

Proper care will extend the lifespan of your earphones.

- **Cleaning:** Gently wipe the earbuds and cable with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the earphones in a clean, dry place when not in use. Avoid extreme temperatures.
- **Cable Care:** Avoid pulling the cable forcefully or wrapping it too tightly to prevent internal damage. The braided cable is designed to be tangle-free, but proper handling is still recommended.
- **Water Exposure:** These earphones are not water-resistant. Avoid exposure to water or excessive moisture.

7. TROUBLESHOOTING

If you encounter issues with your earphones, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound or low volume	• Earphones not fully plugged in. • Device volume too low or muted. • Incorrect audio output selected on device. • Damaged cable or connector.	• Ensure the 3.5mm jack is fully inserted. • Increase volume on your device and using the in-line controller. • Check device audio settings to ensure earphones are selected as output. • Test with another device to rule out earphone damage.
Microphone not working	• Microphone port blocked. • Incorrect input selected on device. • Damaged microphone.	• Ensure the microphone is not covered. • Check device audio input settings. • Test with another device or application.
Controls not responding	• Incompatibility with device. • Damaged in-line controller.	• Some older devices may not fully support all in-line control functions. • Test with another compatible device.

8. SPECIFICATIONS

Detailed technical specifications for the ZEBRONICS Zeb Buds 20 earphones:

- **Brand:** ZEBRONICS
- **Model Name:** ZEB-BUDS 20
- **Colour:** Red
- **Ear Placement:** In Ear
- **Form Factor:** In Ear
- **Noise Control:** None
- **Drivers:** 14mm Dynamic Driver
- **Cable Length:** 1.2 Metre
- **Cable Features:** Tangle Free
- **Headphone Jack:** 3.5 mm Jack
- **Control Type:** Volume Control
- **Control Method:** Remote
- **Compatible Devices:** Phones, Tablets, Audio Devices with 3.5mm Input Port, Laptops
- **Material:** Plastic (Enclosure)
- **Item Weight:** 50 Grams
- **Water Resistance Level:** Not Water Resistant
- **Country of Origin:** China

9. WARRANTY AND SUPPORT

For warranty claims and technical assistance, please refer to the information below:

9.1 Warranty Information

- The ZEBRONICS Zeb Buds 20 earphones come with a **6 months carry-in warranty**.
- Warranty service requires carrying the product to an authorized service center.
- Please retain your purchase receipt for warranty validation.

9.2 Manufacturer Contact Information

Manufacturer: Zebronics India Private Limited

Importer: Zebronics India Private Limited

Packer: Zebronics India Private Limited

For further support or inquiries, please visit the official ZEBRONICS website or contact their customer service.