

Manuals.plus /

› Foxnovo /

› Podcast Equipment Microphone for PC: Foxnovo Dual Audio Channel Computer/Phone Microphone with Stand for Recording music Gaming Sound Card Provides 9 Scene Modes and 9 Sound Effects (Black) - User Manual

Foxnovo Foxnovo Dual Audio Channel

Foxnovo Podcast Equipment Microphone User Manual

Model: Foxnovo Dual Audio Channel

PRODUCT OVERVIEW

This Foxnovo Podcast Equipment Microphone is a versatile audio solution designed for PC and phone use, ideal for recording music, gaming, and live streaming. It features a dual audio channel sound card with 9 scene modes and 9 sound effects to enhance your audio experience.

WHAT'S IN THE BOX

The package includes the following components:

- Microphone x 1
- Sound Card x 1
- 220cm Cannon Audio Cable x 1
- 290cm Earphone x 1
- 3.5mm Audio Adapter Cable x 2
- Micro USB Charging Cable x 1
- Microphone Stand Set x 1
- Microphone Spray Guard x 1



Figure 1: Foxnovo Podcast Equipment Microphone and Sound Card components.

SETUP GUIDE

Follow these steps to set up your Foxnovo Podcast Equipment Microphone:

1. Cell Phone Connection

Connect the microphone and sound card for use with a single cell phone. This setup supports Bluetooth connectivity for audio input.

1. Connect the microphone to the sound card using the Cannon Audio Cable.
2. Connect your headset to the "Headset" port on the sound card.
3. Connect one of the 3.5mm Audio Adapter Cables from the "Live" port on the sound card to your cell phone's audio

jack.

Your browser does not support the video tag.

Video 1: Demonstrates the connection process for the condenser microphone with a sound card, including various setup configurations and sound effects. This video is provided by the seller, Fanswan.

Note: The sound card supports Bluetooth (BT) connection for accompanying audio. To enable, navigate to your phone's Bluetooth settings and pair with the device (e.g., "S500" as shown in the video).



Figure 2: Illustrates the Bluetooth connection process for the sound card with a mobile device.

2. Dual Phone Connections

For live streaming or recording with two mobile devices (e.g., one for live broadcast, one for accompaniment), follow these steps:

1. Connect the microphone to the sound card using the Cannon Audio Cable.
2. Connect your headset to the "Headset" port on the sound card.
3. Connect one 3.5mm Audio Adapter Cable from the "Live" port on the sound card to your primary cell phone (for live broadcast).
4. Connect the second 3.5mm Audio Adapter Cable from the "Accompany" port on the sound card to your secondary cell phone (for background music or sound effects).

LIVE BROADCAST ON TWITCH

9 Sound effects, thanks' make
your live stream interesting



Figure 3: Diagram showing how to connect two mobile phones to the sound card for live streaming or recording.

3. Computer Accompaniment with Cell Phone Live

This setup allows you to use your computer for accompaniment while live streaming from your cell phone.

1. Connect the microphone to the sound card using the Cannon Audio Cable.
2. Connect your headset to the "Headset" port on the sound card.
3. Connect the Micro USB Charging Cable from the "OTG/USB" port on the sound card to your computer's USB port.
4. Connect a 3.5mm Audio Adapter Cable from the "Live" port on the sound card to your cell phone's audio jack.

VOICE CHANGING IN-GAME

Help you disguise your real voice in the game



Figure 4: Illustrates the connection method for using a computer for accompaniment during a mobile live stream.

OPERATING INSTRUCTIONS

The Foxnovo sound card offers various scene modes and sound effects to customize your audio output.

Scene Modes

The sound card provides 9 distinct scene modes to alter your voice or audio environment:

- **KTV:** Simulates a karaoke room environment.
- **POP:** Optimized for pop music vocals.
- **PRO:** Professional audio mode.
- **ORIGIN:** Original voice output.
- **MALE:** Male voice changer.
- **MC:** Master of Ceremonies mode.
- **FEMALE:** Female voice changer.
- **CHILD:** Child voice changer.
- **MONSTER:** Monster voice changer.

SUPER VERSATILE SOUND CARD

9 Scene Modes and 9 Sound Effects
meet all your entertaining needs



Figure 5: Overview of the sound card's interface, highlighting the various scene modes and sound effects.

Sound Effects

Enhance your live streams or recordings with 9 built-in sound effects:

- **LYRIC:** Adds a lyrical effect.
- **CLAP:** Applause sound effect.
- **EXULT:** Exultation sound effect.
- **THX:** "Thank you" sound effect.
- **KISS:** Kiss sound effect.
- **TECHNO:** Techno music beat.
- **LAUGH:** Laughter sound effect.
- **AWKWARD:** Awkward silence sound effect.
- **DISCO:** Disco music beat.

Real-time Monitoring: The sound card allows you to monitor your voice in real-time through your connected headset, helping you to hear what you're singing or speaking and adjust your rhythm.



MONITOR YOUR VOICE IN REAL-TIME

Hear what you're sing, grasp your rhythm

Figure 6: User demonstrating real-time voice monitoring during a recording session.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Foxnovo Podcast Equipment Microphone:

- Keep the microphone and sound card clean by wiping them with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Store the equipment in a cool, dry place away from direct sunlight and extreme temperatures.
- Handle cables carefully to prevent kinks or damage.
- Ensure all connections are secure before and during use to prevent signal loss or damage.

TROUBLESHOOTING

If you encounter issues with your Foxnovo Podcast Equipment Microphone, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
No sound from microphone	Incorrect cable connection, low volume settings, microphone not powered.	Check all cable connections. Ensure microphone and sound card volume levels are adequate. Verify the sound card is charged or connected to power.
Sound is distorted or has static	Loose connections, interference, incorrect gain settings.	Secure all cables. Move away from other electronic devices. Adjust microphone gain and sound card volume levels.
Voice changer/sound effects not working	Incorrect mode selected, software conflict.	Ensure the desired scene mode or sound effect button is pressed. Restart the sound card and connected devices.
Bluetooth connection issues	Device not discoverable, interference, already paired with another device.	Ensure Bluetooth is enabled on both devices. Unpair from other devices if necessary. Try restarting Bluetooth on your phone and the sound card.

SPECIFICATIONS

Feature	Detail
Microphone Form Factor	Tri-Capsule Array
Item Dimensions (L x W x H)	5.51 x 4.72 x 8.66 inches
Power Source	Corded Electric
Hardware Platform	PC
Frequency Response	20 KHz
Noise Level	135 dB
Item Weight	2.92 pounds
Connectivity Technology	Bluetooth, USB
Connector Type	USB
Special Feature	Stand
Compatible Devices	Personal Computer, Smartphone
Color	Black
Polar Pattern	Unidirectional

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Foxnovo website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Visit the Foxnovo Store for more products and information.