

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AXA](#) /

› [AXA Juno Steady - Bicycle Rear Light LED - Rear Bicycle Light - Dynamo Powered - Integrated Reflector - Visible up to 600 m, Red](#)

## AXA Rücklicht Juno Steady 50mm

# AXA Juno Steady Bicycle Rear Light Instruction Manual

Brand: AXA | Model: Rücklicht Juno Steady 50mm

## 1. INTRODUCTION

Thank you for choosing the AXA Juno Steady Bicycle Rear Light. This dynamo-powered LED rear light is designed to enhance your visibility and safety on the road. Featuring an integrated reflector and visible up to 600 meters, the Juno Steady is a reliable and durable addition to your bicycle.

Key features include:

- Powerful Lighting:** Provides bright and effective illumination.
- Easy to Install:** Designed for straightforward mounting.
- Durable Construction:** Built to withstand various weather conditions.
- Steady Mode:** Maintains light output even when the bicycle is stationary.
- Versatile Connectivity:** Can be connected to both flank and hub dynamos, and is compatible with 6V e-bike battery packs via practical pressure connections.

## 2. SAFETY INFORMATION

Always prioritize safety when cycling. Ensure your light is correctly installed and functioning before each ride. Adhere to local traffic laws regarding bicycle lighting.

- Ensure the light is securely mounted and does not obstruct any moving parts of the bicycle.
- Regularly check the light's functionality, especially before night rides.
- Do not attempt to modify the light or its electrical connections, as this may void the warranty and pose a safety risk.
- Keep the reflector clean for maximum visibility.

## 3. PACKAGE CONTENTS

Please verify that all components are present in the package:

- AXA Juno Steady Bicycle Rear Light
- 2 x Mounting Nuts

## 4. SETUP AND INSTALLATION

---

The AXA Juno Steady is designed for pack carrier mounting. Follow these steps for proper installation:

- Positioning:** Identify a suitable mounting point on your bicycle's rear rack. The light should be positioned to provide maximum visibility to the rear.
- Mounting:** Secure the light to the pack carrier using the provided nuts. Ensure the light is firmly attached and does not wobble.
- Electrical Connection:** The Juno Steady can be connected to either a flank dynamo, a hub dynamo, or a 6V e-bike battery pack. Use the practical pressure connections on the light for wiring. Ensure correct polarity if applicable (refer to your dynamo or e-bike system's manual for specific wiring diagrams).



The AXA Juno Steady rear light securely mounted on a bicycle's rear rack.



Rear view of the light, illustrating the mounting bolt positions for attachment to a rack.



Top view of the light, highlighting the practical pressure connections for electrical wiring.

## 5. OPERATION

---

The AXA Juno Steady is a dynamo-powered light, meaning it generates its own electricity as you ride. It features a 'Steady Mode' function.

- Automatic Activation:** The light will illuminate automatically when the bicycle is in motion and connected to a functioning dynamo.

- **Steady Mode:** Thanks to its integrated capacitor, the light will remain illuminated for a period even when the bicycle stops, such as at traffic lights. This ensures continuous visibility and safety.



The AXA Juno Steady rear light illuminated, demonstrating its visibility on a bicycle at night.



A direct rear view of the illuminated AXA Juno Steady, showcasing its bright output.

## 6. MAINTENANCE

---

The AXA Juno Steady is built with durable construction and is water-resistant (IPX6 rated). Regular maintenance will ensure its longevity and optimal performance.

- **Cleaning:** Wipe the light and reflector with a soft, damp cloth to remove dirt and grime. Avoid using abrasive cleaners or solvents.
- **Connection Check:** Periodically inspect the electrical connections to ensure they are secure and free from corrosion.
- **Mounting Check:** Ensure the light remains securely mounted to the bicycle rack. Tighten nuts if necessary.

## 7. TROUBLESHOOTING

---

If you experience issues with your AXA Juno Steady light, consider the following:

- **Light Not Illuminating:**
  - Check all electrical connections from the dynamo to the light. Ensure they are secure and correctly wired.
  - Verify that your dynamo is functioning correctly.
  - Ensure the bicycle is moving at a sufficient speed for the dynamo to generate power.
- **Dim Light:**
  - Clean the light's lens and reflector.
  - Check for any loose or corroded electrical connections.
- **Light Flickers:**

- Inspect wiring for any damage or intermittent connections.
- Ensure the dynamo is providing a consistent power supply.

If problems persist, contact AXA customer support or a qualified bicycle mechanic.

## 8. SPECIFICATIONS

Detailed technical specifications for the AXA Juno Steady Bicycle Rear Light:

Feature	Specification
Brand	AXA
Model Name	Rücklicht Juno Steady 50mm
Part Number	93961495SC
Color	Black
Material	Plastic
Power Source	Dynamo operated
Water Resistance Level	Water Resistant
International Protection Rating	IPX6
Item Weight	0.06 Kilograms
Mounting Type	Pack carrier
Number of Settings	1
Auto Part Position	Rear
Size	50mm
Included Components	Lighting, 2 x nuts



Front view of the AXA Juno Steady, showcasing its design and integrated reflector.



A direct frontal view of the light, emphasizing the LED and reflector elements.



Side profile view of the AXA Juno Steady,  
showing its compact form factor.

## 9. WARRANTY AND SUPPORT




For information regarding warranty coverage, returns, or technical support, please refer to the official AXA website or contact your retailer. Keep your proof of purchase for any warranty claims.

For further assistance, you may visit the AXA official website or contact their customer service department directly.

© 2024 AXA. All rights reserved.

### Related Documents - Rücklicht Juno Steady 50mm

	<p><a href="#"><u>AXA Blueline 50 Series Bicycle Lights: Instruction Manual</u></a></p> <p>Comprehensive instruction manual for the AXA Blueline 50 series bicycle lights, covering mounting, setup, connection (dynamo and e-bike), and operation modes (Switch, Steady Auto, 50-T Steady Auto). Includes warranty information.</p>
	<p><a href="#"><u>AXA Blueline 30 Series Bicycle Light: Instruction Manual and Product Overview</u></a></p> <p>Comprehensive guide to the AXA Blueline 30 Series bicycle lights, covering mounting, connection options (dynamo, battery, rear light), operation modes (Switch, Steady Auto, Steady Auto-T), and warranty information. Includes multilingual instructions.</p>
	<p><a href="#"><u>AXA Slim 50-80 Series Bicycle Light Instruction Manual</u></a></p> <p>Instruction manual for the AXA Slim 50-80 Series bicycle light, covering content packaging, mounting, and dynamo connection. Includes warranty information and company details.</p>

	<p><b><a href="#">AXA Blueline 30 Series Bicycle Light - Instruction Manual</a></b></p> <p>Official instruction manual for the AXA Blueline 30 Series bicycle lights. Learn about mounting, setup, dynamo and e-bike connections, operation modes (30 Switch, Steady Auto, T Steady Auto), warranty, and eco-friendly disposal.</p>
	<p><b><a href="#">AXA Echo 15 Bicycle Light Instruction Manual</a></b></p> <p>This manual provides instructions for mounting, setting up, connecting, and operating the AXA Echo 15 bicycle light. It covers connections to head lights, dynamos, and e-bike batteries, as well as the 30-switch operation. Disposal and warranty information are also included.</p>
	<p><b><a href="#">AXA Juno ST 50/80 mm Bicycle Light Instruction Manual</a></b></p> <p>Instruction manual for the AXA Juno ST bicycle light, covering content packaging, mounting, connection, warranty information, and disposal instructions. Includes multilingual support.</p>