

[Manuals.plus](#) /

> [Xiaomi](#) /

> [Xiaomi Mi Computer Monitor Light Bar User Manual](#)

Xiaomi 30769

Xiaomi Mi Computer Monitor Light Bar User Manual

Model: 30769

Brand: Xiaomi

INTRODUCTION

The Xiaomi Mi Computer Monitor Light Bar is designed to provide optimal lighting for your workspace without causing screen glare or taking up valuable desktop space. Featuring an asymmetric optical design, high color rendering index, and a convenient wireless remote control, it offers a comfortable and efficient lighting solution for various tasks.



Image: The Xiaomi Mi Computer Monitor Light Bar and its accompanying wireless remote control.

SAFETY INFORMATION

- Ensure the product is installed securely to prevent falling.
- Use only the specified power source (USB Type-C, 5V).
- Do not disassemble or modify the product.
- Keep away from water and high humidity environments.
- Avoid direct eye exposure to the light source for prolonged periods.
- Dispose of batteries responsibly according to local regulations.

PACKAGE CONTENTS

- Mi Computer Monitor Light Bar
- Wireless Remote Control
- USB Type-C Cable
- User Manual (this document)

SETUP

1. Installing the Light Bar

1. Attach the light bar to the top of your monitor. The magnetic connection ensures easy and secure placement.



Image: Close-up of the magnetic connection points for easy attachment.

2. Adjust the angle of the light bar to direct illumination onto your desktop, avoiding screen reflection. The asymmetric optical design is specifically engineered for this purpose.



Image: Illustration demonstrating the asymmetric light distribution to prevent screen glare.

3. Connect the USB Type-C cable from the light bar to a USB port on your computer or a compatible power adapter. The light bar will automatically turn on when connected to a powered computer.

2. Installing Batteries in the Remote Control

1. Remove the base plate of the remote control.
2. Insert two AAA batteries, ensuring correct positive (+) and negative (-) alignment. Batteries are not included.
3. Replace the base plate.

OPERATING INSTRUCTIONS

The wireless remote control provides easy access to all lighting functions.

Fewer restrictions and more freedom


Adjustable colour temperature and brightness



Short press
Turn lights on/off



Long press
Computer modes



Rotate
Adjust brightness



Press and rotate
Adjust colour
temperature

Image: Visual guide to the remote control's functions.

- **Short Press:** Turn the light bar on or off.
- **Long Press:** Switch between different computer modes (if applicable).
- **Rotate:** Adjust the brightness level of the light.
- **Press and Rotate:** Adjust the color temperature (warm to cool white).

The light bar features a high Ra95 color rendering index, ensuring objects are displayed in their full, natural color. It is also flicker-free to reduce eye fatigue during long-term use.



Image: High Ra95 color rendering index ensures accurate color representation.

Your browser does not support the video tag.

Video: An overview of the Xiaomi Mi Computer Monitor Light Bar, showcasing its features and operation.

MAINTENANCE

- To clean the light bar, gently wipe it with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Ensure the light bar is disconnected from power before cleaning.
- Regularly check the remote control batteries and replace them when necessary to ensure optimal performance.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Light bar does not turn on.	Ensure the USB Type-C cable is securely connected to a powered USB port. Check if the computer is turned on.
Remote control is unresponsive.	Check and replace the AAA batteries in the remote control. Ensure the remote control is within range of the light bar. If issues persist, try re-pairing by holding down the remote control button until the light bar flashes (refer to specific pairing instructions if available in the full PDF manual).
Light bar does not fit securely on a thin monitor.	The light bar is designed for various monitor thicknesses. For very thin monitors, some users have found success by adding a small, soft spacer (e.g., folded cardboard or foam) between the monitor's back and the light bar's clip to provide a more snug fit.
Cannot change light temperature.	Ensure you are pressing and rotating the remote control dial simultaneously. If the issue persists after battery replacement, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Xiaomi
Model Number	30769
Dimensions	1.02"D x 1.02"W x 0.67"H
Item Weight	1.37 pounds (620 Grams)
Material	Aluminum
Light Source Type	LED
Wattage	5 watts
Power Source	Corded Electric (USB Type-C)
Controller Type	Remote Control (2.4GHz wireless)
Batteries Required	2 AAA batteries (for remote control)
Special Feature	No screen reflection, Adjustable color temperature and brightness, High Ra95 color rendering index, Flicker-free
Installation Type	Tabletop (monitor clip)
Connectivity Protocol	Wi-Fi (for remote control connection)
Energy Efficiency Class	A_TO_G (Refer to EPREL Database for details)

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Xiaomi website or contact your local distributor.

A comprehensive Instructions for Use (IFU) document is available in PDF format for further reference:

[Download Full User Manual
\(PDF\)](#)