

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Outsunny](#) /

› [Outsunny 10' x 10' Steel Outdoor Pergola Gazebo Instruction Manual](#)

## Outsunny B08W2CNJRP

# Outsunny 10' x 10' Steel Outdoor Pergola Gazebo Instruction Manual

Model: B08W2CNJRP

## 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Outsunny 10' x 10' Steel Outdoor Pergola Gazebo. Please read all instructions carefully before assembly and use to ensure safe and proper operation.

## 2. SAFETY INFORMATION

### WARNING:

- Secure the pergola to a stable foundation.
- Do not use this product in extreme weather conditions such as storms, heavy winds, or heavy rain.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.
- Ensure all connections are tight and secure after assembly and periodically during use.

## 3. PARTS LIST

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Powder-coated steel frame components
- PA coated 180gsm polyester fabric canopy with drainage grommets
- Expansion screws for mounting
- Ground stakes for soft ground installation
- Wall mounts (4 units) for wall fixation
- Galvanized steel nails/fasteners
- Velcro fixation straps
- Gourd top decorations



Image: Close-up of various components including galvanized steel nails, elegant gourd top decoration, Velcro fixation, and four wall mounts.

## 4. SETUP AND ASSEMBLY

---

Assembly requires at least two people. Follow these general steps for setting up your pergola. Refer to the included diagram for specific part identification and connection points.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Frame:** Connect the powder-coated steel frame components according to the provided diagrams. Ensure all galvanized steel nails/fasteners are firmly connected.
3. **Attach Canopy:** Secure the PA coated polyester fabric canopy to the assembled frame using the Velcro fixation straps. Ensure the canopy is evenly spread and taut.
4. **Install Decorations:** Attach the elegant gourd top decorations to the designated points on the frame.
5. **Secure to Ground:**
  - For soft ground: Insert ground stakes into the foot of each leg for added stability.
  - For hard surfaces or wall attachment: Use the provided expansion screws and four wall mounts to fix the pergola to a stable wall or ground surface.



Image: The pergola gazebo installed, demonstrating its lean-to design against a wall.



Image: Illustration of the solid base and how to use screws to pin the pergola to the ground for stability.

Your browser does not support the video tag.

Video: Official product video demonstrating the Outsunny 84C-038GY Pergola Gazebo in an outdoor setting, highlighting its features and appearance.

## 5. OPERATING INSTRUCTIONS

The Outsunny Pergola Gazebo is designed to provide shade and enhance your outdoor living space.

- **Shade Provision:** The PA coated polyester fabric canopy offers UV protection, reducing sun exposure.
- **Water Drainage:** The canopy is equipped with drainage grommets to prevent water accumulation during light showers. Ensure these grommets are clear of debris to function effectively.
- **Positioning:** The lean-to design allows for versatile placement against a wall, providing shade for doors, windows, or patio areas.



Image: Detail showing the drainage holes in the canopy designed to prevent rainwater accumulation.

## 6. MAINTENANCE

Regular maintenance will extend the life and appearance of your pergola.

- **Canopy Cleaning:** Clean the polyester fabric canopy with mild soap and water. Rinse thoroughly and allow to air dry completely before storage or prolonged use. Do not use harsh chemicals.
- **Frame Care:** The powder-coated steel frame is designed to resist rust. Wipe down the frame with a damp cloth to remove dirt and debris. Inspect for any scratches or chips in the coating and touch up if necessary to prevent rust.
- **Fastener Check:** Periodically check all bolts, screws, and connections to ensure they remain tight. Tighten as needed.
- **Winter Storage:** In areas with harsh winters, it is recommended to disassemble and store the canopy and frame indoors to protect them from extreme weather conditions.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Water pooling on canopy	Drainage grommets are blocked or insufficient for heavy rain. Canopy not taut enough.	Clear drainage grommets of debris. Ensure canopy is stretched tightly. <b>Note:</b> This pergola is not designed for heavy rain; remove canopy or disassemble in such conditions.
Pergola instability	Loose fasteners. Improper anchoring to ground/wall.	Tighten all bolts and screws. Ensure ground stakes are fully inserted or wall mounts are securely fastened to a stable structure.
Canopy detaching from frame	Velcro straps worn or insufficient. Strong winds.	Inspect Velcro straps for damage and replace if necessary. Ensure canopy is securely attached. Do not use in strong winds.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Outsunny
Model Number	B08W2CNJRP
Material	Alloy Steel, Polyester
Product Dimensions (L x W x H)	117"L x 117"W x 78" - 98.5"H
Item Weight	57.4 Pounds
Frame Material	Metal (Powder-coated steel)
Water Resistance Level	Water Resistant (Canopy with drainage holes)
UV Protection	Yes
Assembly Required	Yes
Color	Gray
UPC	842525175593

# DURABLE & PRACTICAL DESIGN

Beautiful streamlined design reduces resistance

8 Drainage holes prevent rainwater accumulation



Image: Dimensional drawing of the pergola, illustrating its overall length, width, and height.

## 9. WARRANTY AND SUPPORT

This product is offered with a 30-day easy return policy. For any questions, missing parts, or support needs, please contact Aosom Direct customer support. Contact information can typically be found on your purchase receipt or the seller's website.