

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Remington](#) /

› [Remington R6 Style Aqua R6000 Rotary Shaver User Manual](#)

Remington R6000

Remington R6 Style Aqua R6000 Rotary Shaver User Manual

Model: R6000

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your Remington R6 Style Aqua R6000 Rotary Shaver. Keep this manual for future reference.

- Ensure the device is disconnected from the power source before cleaning.
- Rinse the shaver head thoroughly with cold water and allow it to air dry completely.
- Change the shaving head regularly to maintain optimal performance and hygiene.
- Do not use the device near an open water source or during charging, unless specifically stated in these instructions.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

PRODUCT OVERVIEW

The Remington R6 Style Aqua R6000 is a versatile rotary shaver designed for both dry and wet shaving. Its advanced features ensure a close and comfortable shave.



Image: The Remington R6 Style Aqua R6000 Rotary Shaver, showcasing its sleek design.

Key Features:

- **Aqua Blade System:** Designed for 100% waterproof use, allowing for comfortable dry or refreshing wet shaving.
- **Dual Track Blades:** Equipped with two tracks of blades for efficient and fast shaving.
- **Flexible Pivoting Head:** The shaver head pivots to adapt to the contours of your face, ensuring maximum contact and a smooth shave.
- **Extendable Pop-up Trimmer:** Integrated trimmer for precise detailing of sideburns and facial hair.
- **Cordless Operation:** Provides up to 60 minutes of cordless runtime on a full charge.
- **USB Charging:** Convenient USB charging capability with a full charge in 90 minutes and a 5-minute quick charge option.
- **LED Indicators:** Features 2 three-position LED indicators to display battery status.
- **Travel Pouch:** Includes a travel pouch for easy storage and portability.

SETUP

Charging Your Shaver:

1. Before first use, charge your shaver for 90 minutes.
2. Ensure the shaver is switched off.
3. Connect the USB charging cable to the shaver's charging port.
4. Plug the other end of the USB cable into a standard USB power adapter (not included) or a powered USB port.
5. The LED indicators will show the charging status. A full charge provides up to 60 minutes of cordless use.
6. A 5-minute quick charge provides enough power for a single shave.



Image: The shaver connected to its USB charging cable, illustrating the charging process.

OPERATING YOUR SHAVER

General Shaving Tips:

- For best results, hold the shaver at a right angle to your skin.
- Stretch your skin with your free hand to make the hairs stand upright.
- Use short, circular motions.
- Avoid pressing too hard, as this can cause irritation.

Dry Shaving:

Ensure your face is clean and dry before dry shaving. Simply turn on the shaver and begin shaving.

Wet Shaving:

The R6 Style Aqua R6000 is 100% waterproof, allowing for comfortable wet shaving with foam or gel, or even in the shower.

1. Apply shaving foam or gel to your face.
2. Turn on the shaver and shave as usual.
3. Rinse the shaver head under running water during and after shaving to prevent build-up.



Image: The shaver head with water droplets, demonstrating its waterproof capability for wet shaving.

Using the Pop-up Trimmer:

To activate the pop-up trimmer, slide the trimmer release button located on the back of the shaver. Use the trimmer for precise shaping of sideburns, moustaches, or beards.



Image: The shaver head with the protective stubble styler attachment, useful for maintaining short beard styles.

MAINTENANCE

Regular cleaning and maintenance will ensure your shaver performs optimally and extends its lifespan.

Cleaning After Each Use:

1. Turn off the shaver and disconnect it from the power source.
2. Press the release button to open the shaver head assembly.
3. Rinse the shaver head and the internal hair chamber under warm running water.
4. Shake off excess water and allow the parts to air dry completely before closing the shaver head.
5. Do not use harsh cleaning agents or abrasive materials.



Image: The shaver and its protective cover resting on a wet surface, highlighting its waterproof design for easy cleaning.

Replacing Shaver Heads:

For continued optimal performance, it is recommended to replace the shaver heads every 12 months, or sooner if performance degrades. Replacement heads are available from Remington authorized retailers.



Image: Packaging for a Remington replacement shave head, illustrating the availability of spare parts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 90 minutes.

Problem	Possible Cause	Solution
Poor shaving performance.	Shaver heads are dirty or worn.	Clean the shaver heads thoroughly. If performance does not improve, replace the shaver heads.
Skin irritation after shaving.	Pressing too hard, dull blades, or sensitive skin.	Shave with lighter pressure. Consider replacing shaver heads. Use a pre-shave lotion or shave wet with foam/gel.
Trimmer not working effectively.	Trimmer blades are clogged with hair.	Clean the trimmer blades. Ensure the trimmer is fully extended.

SPECIFICATIONS

Model Number:	R6000 (41218560100)
Brand:	Remington
Power Source:	Rechargeable Battery
Special Feature:	100% Waterproof (Wet & Dry Use)
Blade Material:	Stainless Steel
Head Type:	Rotary, Flexible Pivoting Head, Dual Track Blades
Cordless Runtime:	Up to 60 minutes
Charging Time:	90 minutes (Full Charge), 5 minutes (Quick Charge)
Charging Type:	USB Charging
Dimensions:	5.9 x 5.9 x 15 cm
Weight:	160 g
Color:	Black with Aqua accents
Included Components:	Rotary Shaver, USB Charging Cable, Protective Head Attachment, Travel Pouch

WARRANTY AND SUPPORT

Remington products are manufactured to the highest quality standards. For information regarding warranty, product registration, or customer support, please visit the official Remington website or contact their customer service department.

Official Remington Website: es.remington-europe.com

You can also find more styling tips and product information at: es.remington-europe.com/trends-and-tips