

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Replacement Parts](#) /
- › [Replacement Belt for Welbilt ABM-6000 Bread Maker Machine User Manual](#)

### Replacement Parts ABM-6000

# Replacement Belt for Welbilt ABM-6000 Bread Maker Machine User Manual

Model: ABM-6000 | Brand: Replacement Parts

## INTRODUCTION

This manual provides detailed instructions for the proper installation and maintenance of your new replacement drive belt for the Welbilt ABM-6000 Bread Maker Machine. Please read this manual thoroughly before attempting any installation or maintenance to ensure safe and correct operation.

This replacement belt is designed to restore the functionality of your Welbilt ABM-6000 bread maker by replacing a worn or broken drive belt, which is crucial for the kneading paddle's operation.

## IMPORTANT SAFETY INFORMATION

- Always unplug the bread maker from the power outlet before attempting any installation, maintenance, or cleaning.
- Ensure the bread maker is completely cool before handling any internal components.
- Use appropriate tools for disassembly and reassembly to avoid damage to the appliance or injury.
- If you are unsure about any step, consult a qualified technician.
- Keep small parts away from children.

## PRODUCT OVERVIEW

The replacement belt is a critical component for the Welbilt ABM-6000 bread maker, transmitting power from the motor to the kneading paddle mechanism. This ensures proper mixing and kneading of dough.



**Image 1:** Replacement drive belt for Welbilt ABM-6000 bread maker. This image shows the black rubber belt, which is designed to fit the internal drive system of the specified bread machine model.

*Note: No additional product images or videos were provided in the product data.*

## INSTALLATION INSTRUCTIONS

---

Replacing the drive belt requires careful disassembly and reassembly of the bread maker. Follow these steps precisely:

1. **Prepare the Bread Maker:** Unplug the Welbilt ABM-6000 bread maker from the power outlet. Allow it to cool completely if it has been recently used.
2. **Access the Internal Mechanism:**
  - Carefully turn the bread maker upside down.
  - Locate and remove the screws securing the bottom panel. These are typically Phillips head screws. Keep track of all screws, as they may vary in size.
  - Gently remove the bottom panel to expose the motor, drive shaft, and existing belt.
3. **Remove the Old Belt:**
  - Identify the old drive belt. It will be stretched, cracked, or broken.
  - Carefully slide the old belt off the motor pulley and the larger drive wheel. You may need to gently pry it off if it's still partially intact.
4. **Install the New Belt:**
  - Place the new replacement belt around the smaller motor pulley first.
  - Next, stretch the belt over the larger drive wheel. This may require some force and careful manipulation. Ensure the belt is seated correctly in the grooves of both pulleys.
  - Verify that the belt is taut and centered on both pulleys.
5. **Test the Mechanism (Before Reassembly):**
  - Manually rotate the larger drive wheel to ensure the belt moves smoothly and the kneading shaft rotates without obstruction.
  - Check for any rubbing or misalignment.
6. **Reassemble the Bread Maker:**

- Carefully replace the bottom panel, aligning it correctly.
- Secure the bottom panel with all the screws that were removed earlier. Do not overtighten.
- Ensure all screws are in place and the panel is securely fastened.

7. **Final Test:** Plug the bread maker back into the power outlet and run a short cycle (e.g., a kneading cycle) to confirm proper operation of the new belt. Listen for any unusual noises.

## MAINTENANCE

---

To prolong the life of your replacement belt and bread maker:

- **Regular Inspection:** Periodically (e.g., every 6-12 months, or if performance degrades) inspect the belt for signs of wear, cracking, or stretching. This requires opening the bottom panel as described in the installation steps.
- **Keep Clean:** Ensure no dough or debris accumulates around the pulleys or belt, as this can cause premature wear or slippage.
- **Avoid Overloading:** Do not overload the bread maker with ingredients beyond its specified capacity, as this puts excessive strain on the motor and drive belt.
- **Proper Storage:** Store the bread maker in a cool, dry place when not in use. Extreme temperatures can affect the rubber material of the belt.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Kneading paddle not turning.	Belt is broken or slipped off pulleys.	Unplug unit, open bottom panel, inspect belt. Reinstall or replace if necessary.
Grinding or squealing noise during operation.	Belt misalignment or debris on pulleys.	Unplug unit, open bottom panel, check belt alignment and clean pulleys.
Bread maker motor runs, but paddle does not move.	Belt is completely broken or severely stretched.	Unplug unit, open bottom panel, replace the belt.

If troubleshooting steps do not resolve the issue, contact a qualified service technician.

## SPECIFICATIONS

---

**Product:** Replacement Drive Belt

**Compatibility:** Welbilt ABM-6000 Bread Maker Machine

**Material:** Durable Rubber

**Model Number:** ABM-6000 (for compatible machine)

**UPC:** 343393929344

**Brand:** Replacement Parts

## WARRANTY INFORMATION

---

This replacement part is typically covered by a limited manufacturer's warranty against defects in materials and workmanship. Please refer to the specific warranty terms provided by the seller or manufacturer at the time of purchase for details regarding coverage period and claims process. Keep your proof of purchase for

warranty purposes.

Warranty does not cover damage resulting from improper installation, misuse, or normal wear and tear.

## **CUSTOMER SUPPORT**

---

For further assistance, technical support, or inquiries regarding this replacement belt, please contact the seller or the manufacturer of the "Replacement Parts" brand. You may find contact information on your purchase receipt or the product packaging.

When contacting support, please have your product model (Welbilt ABM-6000) and purchase details ready.