

Bestway Beach Bounce House

Bestway H2OGO! Beach Bounce House Inflatable Water Slide Park Instruction Manual

MODEL: BEACH BOUNCE HOUSE (B08W8TLM5P)

1. Introduction

This manual provides essential instructions for the safe setup, operation, and maintenance of your Bestway H2OGO! Beach Bounce House Inflatable Water Slide Park. Please read all instructions carefully before assembly and use to ensure a safe and enjoyable experience. Retain this manual for future reference.

2. Important Safety Information

The safety of users is paramount. Failure to follow these instructions can result in serious injury. This product is intended for outdoor domestic use only.

- **Adult Supervision Required:** Always ensure constant, competent adult supervision of children using the water park. Never leave children unattended.
- **Age and Weight Limits:** This product is designed for children aged 3-8 years. The maximum weight recommendation is 500 pounds (227 kg) total, with a maximum of 6 players at one time. Individual user weight should not exceed 100 lbs (45 kg).
- **Clearance Area:** Set up the water park on a level, soft surface (e.g., grass) at least 6.5 feet (2 meters) away from any structures, fences, trees, power lines, or other obstacles.
- **No Diving or Sliding Headfirst:** Instruct users never to dive or slide headfirst. Always slide feet first.
- **Water Depth:** The splash pool is shallow. Do not allow users to dive into the splash pool.
- **Secure Anchoring:** Always use the provided ground stakes to securely anchor the inflatable unit to prevent movement during use.
- **Blower Operation:** The air blower must remain on continuously while the inflatable is in use. Ensure the blower is placed on a stable surface and kept away from water.
- **Inspect Before Use:** Before each use, inspect the inflatable for any damage, tears, or punctures. Do not use if damaged.

- **Weather Conditions:** Do not use in windy or stormy conditions. Deflate and store the unit.
- **No Sharp Objects:** Keep all sharp objects, jewelry, and eyeglasses away from the inflatable to prevent damage and injury.

3. Package Contents

Verify that all components are present before beginning assembly:

- 1 x Inflatable Water Park Unit (Beach Bounce House)
- 1 x Air Blower (110-120V)
- 8 x Ground Stakes
- 1 x Sprinkler Sprayer Hose
- 1 x Repair Kit
- 1 x Storage Bag



Image: The complete Bestway H2OGO! Beach Bounce House Inflatable Water Slide Park, showing the main inflatable unit, the orange air blower, eight orange ground stakes, and a blue storage bag.

4. Setup Instructions

Follow these steps for quick and proper setup:

1. **Unpack and Position:** Unroll the inflatable water park on a flat, clear, and soft surface in your backyard. Ensure there are no sharp objects underneath or around the setup area.
2. **Connect Air Blower:** Attach the air blower to the inflation tube of the inflatable unit. Ensure the connection is secure.
3. **Inflate:** Plug the air blower into a suitable electrical outlet and turn it on. The inflatable unit will begin to inflate within approximately 2 minutes. The blower must remain on continuously during use.
4. **Secure with Stakes:** Once fully inflated, use the provided ground stakes to anchor the inflatable unit firmly to the ground at all designated anchor points. This prevents the unit from shifting or lifting during play.
5. **Connect Water Hose:** Attach a standard garden hose to the sprinkler sprayer hose connection point on the inflatable. Turn on the water supply to activate the water features.



Image: The orange air blower connected to the blue inflation tube of the water park, ready for inflation.




Image: A set of eight orange ground stakes, used to anchor the inflatable unit to the ground for stability.

5. Operating the Water Park


Once fully set up and inflated, the Bestway H2OGO! Beach Bounce House offers multiple play areas:

- **Bounce House:** The central bouncing area is enclosed with mesh safety walls for secure play.
- **Water Slide:** Users can slide down from the bounce house into the extra-large splash pool. Ensure children slide feet first.
- **Splash Pool:** The surrounding pool area collects water for splashing and cooling off.
- **Water Wall/Sprinkler:** The integrated sprinkler system provides a continuous spray of water for added fun.



Image: Multiple children enjoying the inflatable water park, with one child on the slide and others in the splash pool and bounce area.

BEACH BOUNCE KIDS INFLATABLE EMGA WATER PARK



**BUILT-IN
SPRINKLER**



**EXTRA-LARGE
SPLASH POOL**



**GIANT
BOUNCER**

Image: A child sliding down the orange water slide, landing safely in the splash pool.




Image: Two children playing inside the bounce house, visible through the protective mesh walls.

6. Maintenance and Storage

Proper care ensures the longevity of your water park:

- **Cleaning:** After each use, drain all water from the splash pool. Clean the inflatable unit with a mild soap solution and water. Rinse thoroughly and allow it to air dry completely before storage.
- **Drying:** Ensure the inflatable is completely dry to prevent mold and mildew. You may need to run the blower for an extended period after draining to dry the internal surfaces.
- **Deflating:** Turn off and unplug the air blower. The unit will deflate on its own.
- **Folding:** Once deflated and dry, carefully fold the inflatable unit to minimize wrinkles.
- **Storage:** Store the water park and all accessories in the provided storage bag in a cool, dry place, away from direct sunlight and extreme temperatures. Protect from rodents and insects.
- **Repair Kit:** Use the included repair kit for small punctures or tears according to the instructions provided with the kit.

7. Troubleshooting

Refer to this section for common issues:

- **Inflatable Not Fully Inflating:**
 - Ensure the air blower is continuously running and plugged into a working outlet.
 - Check for any large tears or openings in the inflatable fabric.
 - Verify the inflation tube is securely attached to the blower.
- **Water Leaks from Seams:**
 - Small amounts of air or water may escape from seams; this is normal and part of the manufacturing process.
 - For larger leaks, locate the source and use the repair kit.
- **Insufficient Water Flow:**
 - Check that the garden hose is properly connected and the water supply is fully open.
 - Ensure the sprinkler hose is not kinked or blocked.

8. Product Specifications

Feature	Detail
Model Name	Beach Bounce House
Dimensions (L x W x H)	11 ft. 11 in. x 11 ft. 2 in. x 5 ft. (3.63 m x 3.40 m x 1.52 m)
Maximum Weight Recommendation	500 Pounds (227 kg)
Maximum Number of Players	6
Splash Pool Water Capacity	298 gallons (1128 L)
Blower Voltage	110-120V
Item Weight	42.9 pounds (19.46 kg)
UPC	821808533824
ASIN	B08W8TLM5P



Image: Dimensional diagram of the inflatable water park, indicating its overall length, width, and height.

9. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official Bestway website. Keep your proof of purchase for any warranty claims.