

Morpilot 7261537

Morpilot 7261537 Multitool Knife User Manual

Model: 7261537

[Contents](#) [Features](#) [Setup](#) [Operation](#) [Safety](#) [Package](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

INTRODUCTION

Thank you for choosing the Morpilot 7261537 Multitool Knife. This versatile 15-in-1 tool is designed for various outdoor activities, emergencies, and everyday tasks. It combines essential functions into a compact and durable design, including a knife, saw, fire starter, and compass. Please read this manual carefully to understand the proper use, maintenance, and safety precautions for your multitool.

SAFETY INFORMATION

- **Sharp Edges:** The main blade and saw are extremely sharp. Handle with extreme care to prevent injury.
- **Keep Out of Reach of Children:** This product is not a toy and contains sharp components. Store it securely away from children.
- **Proper Use:** Use each tool for its intended purpose only. Misuse can lead to damage to the tool or personal injury.
- **Folding Mechanisms:** Ensure all tools are fully locked in place before use and fully folded before storage.
- **Fire Starter:** Use the fire starter responsibly and only in appropriate, safe environments. Be aware of surroundings and potential fire hazards.
- **Maintenance:** Regularly inspect the tool for any damage or wear. Do not use if damaged.

PACKAGE CONTENTS

The Morpilot 7261537 Multitool Knife package includes:

- Morpilot 15-in-1 Multitool Knife
- Flint Fire Starter with integrated compass and whistle

- User Manual (this document)



Image: Contents of the Morpilot Multitool Knife package, including the multitool, fire starter, and user manual.

PRODUCT FEATURES (15-IN-1 TOOLS)

The Morpilot 7261537 Multitool Knife integrates 15 essential tools for various applications:

1. Large Blade
2. Wood Saw
3. Bottle Opener
4. Can Opener
5. Corkscrew
6. Phillips Screwdriver
7. Flathead Screwdriver (small)
8. Flathead Screwdriver (medium)
9. Flathead Screwdriver (large)
10. Scissors
11. Fish Scaler
12. Hook Remover
13. Nail File
14. Nail Cleaner

15. Key Ring

Additionally, the separate flint fire starter includes a compass and a whistle.



Image: The Morpilot Multitool Knife with its various tools extended, showing its compact design and overall dimensions.

SETUP AND FIRST USE

Your Morpilot Multitool Knife comes ready for use. No assembly is required. Before first use, familiarize yourself with the location and operation of each tool.

1. **Unfolding Tools:** Carefully unfold each tool one at a time. Some tools may require a firm pull to deploy.
2. **Locking Mechanism:** Ensure that any tool with a locking mechanism (e.g., the main blade) is fully engaged before applying pressure during use. This prevents accidental folding and potential injury.
3. **Folding Tools:** To fold a tool back into the handle, disengage any locking mechanism (if present) and carefully push the tool back until it is fully recessed.

4. **Fire Starter:** The fire starter rod is separate. Remove it from its protective casing. The striker is typically integrated into the multitool or the fire starter casing itself.

OPERATING INSTRUCTIONS

General Tool Use

Always ensure a firm grip on the multitool handle when using any of its components. Apply steady, controlled pressure. Avoid excessive force that could damage the tool or cause injury.



Image: Examples of the Morpilot Multitool Knife in use for tasks such as opening bottles, scaling fish, carving wood, and cutting with scissors.

Using the Fire Starter

The flint fire starter is designed to create sparks for igniting tinder. It is effective even in rain and wind.

1. **Prepare Tinder:** Gather dry, fine tinder (e.g., cotton balls, dry grass, wood shavings, birch bark).
2. **Scrape Coating:** If new, scrape off the black protective coating from the ferrocerium rod to expose the shiny metal underneath.
3. **Position:** Hold the ferrocerium rod firmly at an angle over your tinder.
4. **Strike:** Use the sharp edge of the striker (often a serrated part of the multitool or a dedicated striker on the

fire starter casing) to scrape down the rod with quick, firm strokes. Aim the sparks directly onto the tinder.

5. **Ignite:** Once the tinder catches a spark, gently blow on it to encourage a flame.



Rainproof



Windproof

Image: A user demonstrating how to use the fire starter, producing sparks. The image highlights its rainproof and windproof capabilities.

Using the Compass and Whistle

The fire starter unit also includes a small compass and a whistle for navigation and signaling.

- **Compass:** Hold the compass level and away from metallic objects or strong magnetic fields to ensure an accurate reading. The needle will point North.
- **Whistle:** To use the whistle, place it to your lips and blow sharply. Use it for signaling in emergencies or to attract attention.




Image: A person blowing the integrated whistle and a close-up view of the compass, both part of the fire starter accessory.

MAINTENANCE

- **Cleaning:** After each use, especially if exposed to dirt, moisture, or corrosive substances, clean the multitool. Use a damp cloth to wipe down surfaces. For stubborn dirt, a small brush and mild soap can be used. Ensure the tool is completely dry before folding and storing.
- **Lubrication:** Periodically apply a small amount of light machine oil (e.g., mineral oil or gun oil) to the pivot points of the tools to ensure smooth operation and prevent rust.
- **Sharpening:** The main blade and saw may dull over time with use. Sharpen the blade using a suitable knife sharpener. The saw teeth are generally not user-sharpenable.
- **Storage:** Store the multitool in a dry environment to prevent corrosion. Keep it in its original packaging or a protective sheath when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Tools are stiff or hard to open/close.	Dirt, debris, or lack of lubrication.	Clean the tool thoroughly and apply a small amount of lubricant to the pivot points.
Blade feels dull.	Normal wear and tear from use.	Sharpen the blade using a suitable knife sharpener.
Fire starter not producing sparks.	Protective coating still present, or improper striking technique.	Ensure the black protective coating is scraped off. Use a firm, quick stroke with the striker at a steep angle.
Compass not pointing North accurately.	Magnetic interference from nearby objects.	Move away from electronic devices, metal objects, or strong magnetic fields. Hold the compass level.

SPECIFICATIONS

Brand: Morpilot
Model Number: 7261537
Number of Tools: 15 (Multitool Knife) + 3 (Fire Starter: Flint, Compass, Whistle)
Dimensions (Folded): Approximately 3.54 x 0.98 x 0.59 inches (90 x 25 x 15 mm)
Weight: Approximately 0.19 Kilograms (190 grams)
Material: Stainless Steel (tools), Durable Plastic (handle)
UPC: 810074380126

WARRANTY AND SUPPORT

Morpilot products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or contact Morpilot customer support directly. If you encounter any issues or have questions regarding your Morpilot 7261537 Multitool Knife, please contact our customer service team for assistance.

Customer Support: Please visit the official Morpilot website or refer to your purchase documentation for contact details.