Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC LT82N7115

JVC 82-inch 4K UHD HDR Smart TV User Manual

Model: LT82N7115

Introduction

Thank you for purchasing the JVC 82-inch 4K UHD HDR Smart TV, Model LT82N7115. This television offers an immersive viewing experience with its Ultra HD 4K resolution and High Dynamic Range (HDR) capabilities. Equipped with smart features, it provides access to popular streaming services like Amazon Instant Video, Netflix, and YouTube, directly from your TV. This manual provides essential information for setting up, operating, and maintaining your new television.

Safety Information

Please read all safety instructions carefully before using your television. Keep this manual for future reference.

- Do not expose the TV to rain or moisture to prevent fire or electric shock.
- Ensure proper ventilation. Do not block ventilation openings.
- Place the TV on a stable, level surface to prevent it from falling.
- Protect the power cord from being walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

Package Contents

Verify that all items listed below are included in your package:

- JVC 82-inch 4K UHD HDR Smart TV (Model: LT82N7115)
- Remote Control
- Power Cable
- User Manual (Catalog)
- TV Stand (if applicable, not explicitly listed but implied for a TV)




Image: The JVC 82-inch 4K UHD HDR Smart TV. The screen displays a vibrant image of two storks, one with its wings spread, standing on a nest made of branches, set against a clear blue sky with white clouds. The JVC logo is visible at the bottom center of the TV frame.

Setup

1. Stand Installation (if not wall-mounted)

1. Carefully place the TV screen-down on a soft, flat surface to prevent scratches.
2. Attach the stand legs to the designated slots on the bottom of the TV using the provided screws. Ensure they are securely fastened.

2. Connecting Devices

Your JVC Smart TV offers various connectivity options:

- **HDMI Ports (x3):** Connect Blu-ray players, game consoles, cable boxes, or other HDMI-enabled devices.
- **USB Ports (x2):** Connect USB drives for media playback or firmware updates.
- **RJ45 (Ethernet) Port (x1):** For a wired internet connection.
- **AV Ports (x2):** For connecting older devices using composite video and stereo audio cables.
- **Optical Audio Output (x1):** For connecting to soundbars or home theater systems with optical input.

3. Initial Power-On and Network Setup

1. Connect the power cable to the TV and a power outlet.
2. Press the power button on the TV or remote control to turn it on.
3. Follow the on-screen instructions to select your language, country, and perform channel scanning.
4. For smart features, connect the TV to your home network via Wi-Fi or Ethernet. Navigate to the network settings and follow the prompts to connect.

Operating

Remote Control Functions

Familiarize yourself with the remote control buttons for easy navigation and control of your TV's features.

- **Power Button:** Turns the TV on or off.
- **Input/Source:** Switches between connected input sources (HDMI, AV, TV).
- **Navigation Buttons (Up/Down/Left/Right/OK):** For menu navigation and selection.
- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes TV channels.
- **Smart TV Buttons:** Dedicated buttons for quick access to supported internet services like Netflix, Amazon Instant Video, and YouTube.
- **Menu/Settings:** Accesses the TV's main settings menu.
- **Back/Exit:** Returns to the previous screen or exits the current menu.

Smart TV Features

Your JVC Smart TV allows you to enjoy a wide range of online content:

- **Streaming Apps:** Directly access pre-installed applications such as Amazon Instant Video, Netflix, and YouTube. Ensure your TV is connected to the internet.
- **App Store:** Explore and download additional applications from the TV's app store (if available).
- **Web Browser:** Browse the internet directly on your TV screen.

Maintenance

Proper care will extend the life of your JVC TV.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for electronics, applied to the cloth, not directly to the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked to prevent overheating.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, replace it immediately with an approved cord.

Troubleshooting

Before contacting customer support, try the following solutions for common issues:

Problem	Possible Solution
No Power	Check if the power cable is securely connected to both the TV and the power outlet. Try a different outlet.
No Picture, but Sound is Present	Ensure the correct input source is selected. Check cable connections (HDMI, AV).
No Sound, but Picture is Present	Check volume level and mute setting. Verify audio cable connections. If using external audio, check its power and input.

Problem	Possible Solution
Remote Control Not Working	Replace batteries. Ensure no obstructions between the remote and the TV's IR sensor.
Cannot Connect to Wi-Fi	Ensure your Wi-Fi router is on and working. Re-enter the Wi-Fi password. Try restarting both the TV and the router.

Specifications

Feature	Detail
Brand	JVC
Model Name	LT82N7115
Screen Size	82 inches (209 cm visible diagonal)
Display Technology	LED
Resolution	4K UHD
Refresh Rate	120 Hz
Special Feature	Flat Screen
Connectivity Technology	Wi-Fi
Supported Internet Services	Amazon Instant Video, Netflix, YouTube
Product Dimensions	210 x 22 x 123 cm
Product Weight	50 kg
Included Components	Remote Control, User Manual, Power Cable
ASIN	B08WB1C55V

Warranty and Support

For warranty information or technical support, please refer to the warranty card included in your package or visit the official JVC website. When contacting support, please have your TV's model number (LT82N7115) and serial number ready.
For further assistance, you may also refer to theJVC Brand Page on Amazon.

© 2024 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08WB1C55V

More documents and user manuals: **https://manuals.plus/**