

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Remington](#) /

> [Remington PG3160 Ultimate Precision Multigroomer User Manual](#)

Remington PG3160

Remington PG3160 Ultimate Precision Multigroomer User Manual

Model: PG3160

INTRODUCTION

This manual provides comprehensive instructions for the Remington PG3160 Ultimate Precision Multigroomer. It covers essential information regarding product features, setup, operation, maintenance, and troubleshooting to ensure optimal performance and user safety.

IMPORTANT SAFETY INSTRUCTIONS

- Keep out of reach of children.
- Avoid contact with skin and eyes.
- Unplug the device before cleaning.
- Do not use near water or when bathing.
- Handle with care to avoid injury.

PRODUCT FEATURES

- **Ultimate Precision:** Reversible T-blade for precise cuts and trims at multiple angles.
- **High Visibility Design:** Cutaway neck design ensures a clear view during trimming.
- **Customizable Looks:** 14 length and style settings for versatile grooming.
- **Easy Cleanup:** Durable, removable, and washable attachments.
- **Skin-Close Performance:** Factory-set, zero gap blades for comfortable trimming.
- **Durable Blades:** Self-sharpening Japanese grade steel blades for long-lasting precision.
- **Cordless Operation:** Advanced rechargeable battery provides up to 60 minutes of cordless run time.
- **Universal Charging:** USB charging cable included (wall adapter not included).

REVERSIBLE T-BLADE

For Precise Cuts & Trims



An image illustrating the reversible T-blade feature of the Remington Multigroomer, showing how it pivots for precise cuts and trims.

CUTAWAY NECK DESIGN

See What You're Trimming



A person using the Remington Multigroomer to trim hair, demonstrating the cutaway neck design that provides clear visibility of the trimming area.



An arrangement of various trimming guards, indicating the 14 length and style options available with the Remington Multigroomer.



FACTORY-SET
**ZERO GAP
BLADES**

For Comfortable,
Skin-Close Trimming

A close-up of the Remington Multigroomer's head, emphasizing the factory-set, zero gap blades designed for comfortable, skin-close trimming.



JAPANESE GRADE STEEL BLADES

Self Sharpening for Long-Lasting Precision.

A man using the Remington Multigroomer to trim his beard, illustrating the precision offered by the Japanese grade steel blades.

PACKAGE CONTENTS

- Ultimate Precision Multigroomer
- Storage Pouch
- USB Charging Cable
- Various trimming guards (11-piece set)

SETUP

1. **Initial Cleaning:** Before first use, clean all removable parts with warm, soapy water. Allow them to dry completely.
2. **Charging:** Connect the USB charging cable to the multigroomer and a standard 5V DC output USB adapter (not included). Charge the device fully before its first use.
3. **Attaching Guards:** Select the desired trimming guard for your preferred length. Align the guard with the trimmer head and snap it into place securely.



A close-up of the Remington Multigroomer's charging port connected to a USB cable, demonstrating its universal USB charging capability.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button to turn the device on. Press it again to turn it off.
2. **Trimming:** Guide the trimmer against the direction of hair growth. Use the reversible T-blade for precise lines and detailing. Adjust the angle as needed for different areas.
3. **Length Adjustment:** Utilize the various trimming guards to achieve your desired hair length.

MAINTENANCE

1. **Cleaning Blades:** After each use, turn off and unplug the multigroomer. Remove any attached guards. Rinse the blades and guards under running water.
2. **Drying:** Allow all parts to air dry completely before reassembling or storing the device.
3. **Storage:** Store the multigroomer and its accessories in the provided storage pouch in a dry place.

TROUBLESHOOTING

If you encounter issues with your Remington PG3160 Multigroomer, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Connect it to the USB charging cable and allow sufficient time for charging.
- **Poor trimming performance:** Check if the blades are clean and free of hair debris. Ensure the correct guard is securely attached. The blades are self-sharpening, but excessive build-up can affect performance.
- **Battery not holding charge:** Ensure the USB charging cable is properly connected to both the device and a working power source. If issues persist, contact customer support.

SPECIFICATIONS

Feature	Detail
Product Dimensions	0.88 x 2.16 x 3.96 inches; 11.36 ounces
Model Number	PG3160

Feature	Detail
UPC	074590555547
Manufacturer	Remington
Recommended Uses	Trimming, Grooming
Hair Type	All
Target Audience	Unisex-Adults
Power Source	Cordless Rechargeable
Blade Material	Stainless Steel
Color	Black



The Remington Multigroomer held in a hand, with measurements showing its compact size: 6.8 inches in length and 1.4 inches for the blade width.

WARRANTY AND SUPPORT

The Remington PG3160 Ultimate Precision Multigroomer comes with a **5-year manufacturer's warranty**. For further assistance, product registration, or to view other Remington products, please visit the official Remington store: [Remington Store](#).

© 2024 Remington. All rights reserved.