Manuals+

Q & A | Deep Search | Upload

Raycon RBE775-23E-BLA

Raycon Everyday Wireless Bluetooth Over Ear Headphones

Model: RBE775-23E-BLA | Brand: Raycon

Introduction

Welcome to the user manual for your Raycon Everyday Wireless Bluetooth Over Ear Headphones. These headphones are designed to provide a superior audio experience with features like Active Noise Cancelling, Awareness Mode, and a built-in microphone, all while ensuring comfort and durability for daily use.

WHAT'S IN THE BOX

- Raycon Everyday Wireless Bluetooth Over Ear Headphones
- Charging Cable (USB-C)
- 3.5mm Audio AUX Cable
- User Manual (this document)



Image: Raycon Everyday Headphones in Frost White, showcasing the headphones and included cables.

SETUP

Initial Charge

Before first use, fully charge your headphones. Connect the provided USB-C charging cable to the charging port on the headphone and plug the other end into a compatible USB power source. The LED indicator will show charging status.

Bluetooth Pairing

- 1. Ensure your headphones are powered off.
- 2. Press and hold the Power button until the LED indicator flashes, indicating pairing mode.
- 3. On your device (smartphone, tablet, computer), navigate to the Bluetooth settings.
- 4. Select "Raycon Everyday Headphones" from the list of available devices.
- 5. Once connected, a voice prompt will confirm successful pairing.

The headphones support Bluetooth 5.0 with a range of up to 33 feet.



Image: Front view of Raycon Everyday Headphones, highlighting their design.

OPERATING INSTRUCTIONS

Controls

Button/Control	Function	
Power Button (Middle)	Press and hold to Power On/Off. Short press to Play/Pause music.	
Volume Up (+)	Short press to increase volume. Long press for next track.	
Volume Down (-)	Short press to decrease volume. Long press for previous track.	

Button/Control	Function
ANC/Awareness Mode Button	Short press to toggle between Active Noise Cancellation, Awareness Mode, and Normal Mode.

Active Noise Cancellation (ANC)

Activate ANC to minimize ambient noise, allowing for an immersive audio experience. This mode uses audio-neutralizing algorithms to cancel out external sounds.



Image: Diagram illustrating the Active Noise Cancellation feature of the headphones.

Awareness Mode

Switch to Awareness Mode to allow some ambient sound to pass through, keeping you aware of your surroundings while still enjoying your audio. This is useful for safety in urban environments or when needing to hear announcements.



Image: Diagram illustrating the Awareness Mode feature of the headphones.

Making/Receiving Calls

The built-in microphone allows for clear hands-free calls. Use the Power button to answer or end calls. Your phone's volume controls will adjust call volume.

Your browser does not support the video tag.

Video: An official Raycon video demonstrating the features and usage of the headphones, including call functionality.

CHARGING

Your Raycon Everyday Headphones offer up to 38 hours of battery life on a single charge. A quick 15-minute charge provides approximately 2 hours of playback. Use the provided USB-C cable for optimal charging.



Image: Visual representation of the impressive battery life and quick charge capability.

MAINTENANCE

- Cleaning: Wipe the headphones with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Storage: When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.
- Water Resistance: The headphones are IPX4 water-resistant, meaning they are protected from splashing water from any direction. Do not submerge them in water.



Image: Raycon Everyday Headphones in their folded, portable state.

TROUBLESHOOTING

Problem	Solution
Headphones won't turn on.	Ensure the headphones are fully charged.
Cannot pair with device.	Ensure headphones are in pairing mode (flashing LED). Turn off and on Bluetooth on your device. Forget device and re-pair.

Problem	Solution
No sound or low volume.	Check headphone and device volume levels. Ensure headphones are connected to the correct device. Try re-pairing.
ANC not working effectively.	Ensure ANC mode is activated. Check for proper fit over ears to create a good seal.

SPECIFICATIONS

Model Name: The Everyday Headphones - White Connectivity Technology: Wireless (Bluetooth 5.0) Wireless Communication Technology: Bluetooth

Noise Control: Active Noise Cancellation

Headphones Jack: 3.5 mm Jack (for wired connection)

Item Weight: 7.5 ounces

Water Resistance Level: IPX4 Water Resistant

Frequency Range: 20Hz-20KHz

Control Method: Touch

Battery Life: Up to 38 Hours (Playback)
Bluetooth Range: 10 Meters (33 Feet)
Audio Driver Size: 40 Millimeters

Earpiece Shape: Over Ear

Material: Plastic

Manufacturer: Raycon UPC: 811162030763

WARRANTY AND SUPPORT

For warranty information, product support, or additional inquiries, please visit the official Raycon support page or contact customer service through the Raycon Store on Amazon.

Raycon Store: https://www.amazon.com/stores/RayconGlobal/page/717D4FCE-EFA3-469D-9C3E-35F98E78579A

Documents - Raycon - RBE775-23E-BLA



[pdf] Datasheet Safety Datasheet Test Report

Safety Data Sheet Raycon The Impact True Wireless Active Noise Canceling Earbuds with Charging Case Bluetooth Carbon Black RBE775 23E BLA Staples 24573451 sds staples msds ||| Safety Data Sheet Fiche de donnes de scurit Report No.: MTi230217003-21A1 Date of issue: Fed. 17, 2023 Sample Name: Nom de I chantillon: Li-ion Battery Model: Modle: 501015 Applicant: Candidat: DongGuan Nengyou Energy Science and Technology Co.,Ltd. Address: Address: Building B, No.353, Qing...

lang:en score:21 filesize: 1.46 M page_count: 27 document date: 2023-07-20