

Liebherr CNP-371-23 088 NF 201.1X60 A+++

Liebherr CNP-371-23 088 NF 201.1X60 A+++ Combi Refrigerator User Manual

Model: **CNP-371-23 088 NF 201.1X60 A+++** | Brand: **Liebherr**

1. INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your new Liebherr CNP-371-23 088 NF 201.1X60 A+++ Combi Refrigerator. Please read this manual carefully before using the appliance to ensure safe and efficient operation. Keep this manual for future reference.



Image 1.1: Front view of the Liebherr CNP-371-23 088 NF 201.1X60 A+++ Combi Refrigerator. This appliance features a clean white finish with a HardLine door design and a vertical recessed grip handle. The upper section is the refrigerator compartment, and the lower section is the freezer compartment.

2. PRODUCT OVERVIEW AND FEATURES

2.1 Design and Construction

- **Door Design:** HardLine
- **Color:** White
- **Door Material:** Steel
- **Side Wall Material:** Steel
- **Handle:** Vertical recessed grip on both sides
- **Door Opening Direction:** Right, reversible

2.2 Control and Functions

- **Digital Temperature Display:** Located in the MagicEye, behind the door.
- **Control Type:** Buttons
- **Adjustable Cooling Circuits:** 2
- **Temperature Zones:** 2
- **Temperature Display:** For both refrigerator and freezer compartments.
- **Malfunction Warning Signal:** Optical and audible.
- **Door Open Alarm:** Audible for the refrigerator compartment.
- **Child-Proof Device:** Included for safety.
- **SuperFrost Function:** Timer-controlled for rapid freezing.

2.3 Refrigerator Compartment

- **Defrosting Method:** Automatic
- **Cooling:** Circulating air cooling
- **Lighting:** LED ceiling lighting
- **Number of Shelves:** 4 (3 height-adjustable)
- **Shelf Material:** Glass
- **Bottle Storage:** Grid bottle shelf (2 bottle racks)
- **Can Shelves:** 2
- **Egg Trays:** Included
- **Vegetable Drawers:** 1

2.4 Freezer Compartment

- **Technology:** NoFrost
- **Star Rating:** 4-star
- **Defrosting Method:** Automatic
- **Storage Time in Case of Malfunction:** 26 hours
- **Freezing Capacity (24h):** 10 kg
- **Number of Drawers:** 3
- **VarioSpace:** Yes
- **Ice Cube Tray:** 1
- **FrostSafe-System:** Drawers closed on all sides with transparent front.

3. SETUP AND INSTALLATION

Before installation, ensure the appliance is placed on a stable, level surface away from direct sunlight or heat

sources. Allow sufficient space for ventilation around the unit as specified in the installation guide (not provided in this general manual). The door opening direction is reversible; consult a qualified technician if you wish to change it.

- Unpack the appliance carefully and remove all packaging materials.
- Clean the interior of the appliance with a damp cloth and mild detergent before first use.
- Connect the appliance to a properly grounded electrical outlet (240 Volts).
- Allow the appliance to stand upright for at least 4 hours before plugging it in to allow the refrigerant to settle.

4. OPERATING INSTRUCTIONS

Your Liebherr Combi Refrigerator is designed for intuitive operation. The MagicEye digital display and control buttons are located behind the door for a sleek exterior.

- **Initial Startup:** After plugging in, the appliance will begin cooling. The temperature display will show the current internal temperatures.
- **Temperature Adjustment:** Use the control buttons to set the desired temperatures for both the refrigerator and freezer compartments independently. Refer to the on-screen prompts for specific adjustments.
- **SuperFrost Function:** Activate SuperFrost for rapid freezing of fresh food. This function automatically deactivates after a set period to save energy.
- **Alarms:** The appliance features optical and audible alarms for malfunctions and an audible alarm if the refrigerator door is left open. Address the cause of the alarm promptly.
- **Child Lock:** The child-proof device prevents accidental changes to settings. Consult the specific instructions for activating/deactivating this feature.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your appliance.

- **Cleaning:** Disconnect the appliance from the power supply before cleaning. Clean the interior and exterior surfaces regularly with a mild detergent and warm water. Avoid abrasive cleaners or solvents.
- **Automatic Defrosting:** Both the refrigerator and freezer compartments feature automatic defrosting (NoFrost in the freezer), eliminating the need for manual defrosting.
- **Door Seals:** Periodically check the door seals for cleanliness and integrity. Clean them with warm water and ensure they are sealing properly to maintain energy efficiency.
- **Interior Components:** Shelves and drawers can be removed for easier cleaning. Wash them by hand with warm, soapy water.

6. TROUBLESHOOTING

If you encounter issues with your appliance, refer to the following common troubleshooting steps. For problems not listed here, contact customer support.

Problem	Possible Cause	Solution
Appliance not cooling	No power, thermostat set too high, door not closed properly.	Check power connection, adjust temperature settings, ensure door is fully closed.
Excessive noise	Appliance not level, objects touching the back wall.	Adjust leveling feet, move objects away from the back.

Problem	Possible Cause	Solution
Water on the floor	Drain hole blocked (refrigerator), excessive humidity.	Clear the drain hole, ensure proper ventilation.
Door alarm sounds frequently	Door not closing completely, door seal damaged.	Check for obstructions, inspect and clean door seal.

7. SPECIFICATIONS

- **Model Name:** CNP-371-23 088 NF 201.1X60 A+++
- **Manufacturer:** LIEBHERR
- **Product Reference:** CNP371
- **ASIN:** B08WHF3CDW
- **External Dimensions (H/W/D):** 201.1 cm / 60.0 cm / 65.5 cm (79.17 in / 23.62 in / 25.79 in)
- **Weight (without packaging):** 74.0 kg (163.14 lbs)
- **Energy Efficiency Class:** A+++
- **Energy Consumption (24h):** 0.456 kWh
- **Annual Energy Consumption:** 167 kWh/a
- **Climate Class:** SN-T
- **Sound Power Level:** 40 dB
- **Total Net Capacity:** 338 liters
- **Refrigerator Compartment Net Capacity:** 243 liters
- **Freezer Compartment Net Capacity:** 95 liters
- **Total Gross Capacity:** 368 liters
- **Voltage:** 240 Volts
- **Form Factor:** Bottom Freezer

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or visit the official Liebherr website. In case of technical issues or service requests, please contact Liebherr customer support. Ensure you have your model number and serial number ready when contacting support.

Liebherr Official Website: home.liebherr.com