

Muvit CANDY

Muvit Candy Wireless Keyboard Mouse Combo User Manual

Model: CANDY

[Overview](#) [Setup](#) [Operation](#) [Introduction](#) [Product Maintenance](#) [Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

Thank you for purchasing the Muvit Candy Wireless Keyboard Mouse Combo. This manual provides detailed instructions for setting up, operating, and maintaining your new wireless peripheral set. Please read this manual carefully before use to ensure optimal performance and longevity of your product.

2. PRODUCT OVERVIEW

2.1 Components

- Wireless Keyboard (100-key mini keyboard with circular punk key caps)
- Wireless Mouse
- USB Receiver (for 2.4GHz wireless connection)

2.2 Key Features

- **2.4GHz Wireless Technology:** Provides a stable and reliable connection with an effective range of up to 10 meters.
- **Full-size 100-Key Layout:** Includes conventional keyboard, numeric keypad, and directional keys for comprehensive functionality.
- **Multimedia Hotkeys:** FN+F1~F12 keys support various shortcut functions such as play/pause, volume control, and more.
- **Intelligent Power-Saving:** Features an intelligent power-saving chip with three power-saving modes to extend battery life.
- **Plug and Play:** No drivers required; simply insert the USB receiver to connect both keyboard and

mouse.

- **Ergonomic Design:** Designed for comfortable use during extended periods.
- **Optical Mouse:** Compact and precise optical tracking.



Figure 2.1: The Muvit Candy Wireless Keyboard and Mouse Combo in blue, showcasing its compact design and circular keycaps.




Figure 2.2: The Muvit Candy keyboard and mouse combo positioned alongside a laptop, demonstrating its size and compatibility with portable devices.



Figure 2.3: A detailed view of the Muvit Candy keyboard's circular punk keycaps, highlighting their unique design and removable nature.

3. SETUP GUIDE

3.1 Battery Installation

The keyboard and mouse require 2 AA batteries each (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the underside of the keyboard and mouse.
2. Open the battery compartment cover.
3. Insert the AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

3.2 Connecting the USB Receiver

The Muvit Candy combo uses a single USB receiver for both the keyboard and mouse.

1. Locate the USB receiver, typically stored in the battery compartment of the mouse or in the product packaging.
2. Plug the USB receiver into an available USB port on your computer (PC, Laptop, Desktop).
3. The system will automatically detect and install the necessary drivers. No manual driver installation is required.
4. Once detected, the keyboard and mouse are ready for use.



Figure 3.1: The Muvit Candy keyboard, mouse, and the compact USB receiver, illustrating the components required for wireless connectivity.

4. OPERATION

4.1 Basic Use

Once connected, the keyboard and mouse function like standard wired peripherals. The 2.4GHz wireless technology ensures a strong and secured signal, allowing you to operate your computer from a distance of

up to 10 meters.

4.2 Multimedia Functions (Keyboard)

The keyboard features dedicated multimedia functions accessible via the 'FN' key combined with the F1-F12 keys. Refer to the keycap legends for specific functions:

- FN + F1: Media Player
- FN + F2: Volume Down
- FN + F3: Volume Up
- FN + F4: Mute
- FN + F5: Previous Track
- FN + F6: Next Track
- FN + F7: Play/Pause
- FN + F8: Stop
- FN + F9: Home Page
- FN + F10: Email
- FN + F11: My Computer
- FN + F12: Calculator

4.3 Power Saving Modes

The combo is equipped with an intelligent power-saving chip. If inactive for a period, the devices will enter a sleep mode to conserve battery. To wake them up, simply press any key on the keyboard or move the mouse.

4.4 Compatibility

The Muvit Candy Wireless Keyboard Mouse Combo is compatible with a wide range of operating systems, including:

- Windows (Windows 7, Windows 8, Windows 10)
- Mac OS
- Vista

It is ideal for use with PCs, Laptops, Desktops, and Gaming PC setups.



Figure 4.1: A user actively typing on the Muvit Candy keyboard, demonstrating its use in a typical desktop environment with a monitor.



Figure 4.2: The Muvit Candy keyboard and mouse shown with a tablet, illustrating the effective wireless operating distance of approximately 6 meters.

5. MAINTENANCE

5.1 Cleaning

To maintain the appearance and functionality of your keyboard and mouse:

- Use a soft, dry cloth to wipe down the surfaces.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the finish.
- For the keyboard, you may use compressed air to remove debris from between the keys.

5.2 Battery Replacement

When the keyboard or mouse becomes unresponsive or exhibits delayed input, it is likely time to replace the batteries. Follow the battery installation steps in Section 3.1.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low or dead batteries	Replace batteries in both keyboard and mouse.
Intermittent connection or lag	USB receiver not properly connected or too far from devices	Ensure USB receiver is securely plugged in. Move devices closer to the receiver (within 10m). Avoid obstructions.
Keyboard/Mouse not detected	USB receiver issue or port issue	Try plugging the USB receiver into a different USB port on your computer. Restart your computer.
Specific keys/mouse buttons not working	Software conflict or physical damage	Ensure no conflicting software is running. Check for physical damage. If problem persists, contact support.






7. SPECIFICATIONS

Feature	Detail
Brand	Muvit
Model	CANDY
Connectivity Technology	2.4GHz Wireless, USB (for receiver)
Keyboard Description	Ergonomic, 100-key mini with circular punk key caps
Mouse Movement Detection	Optical
Hand Orientation (Mouse)	Right
Compatible Devices	Laptop, PC, Desktop
Operating System Compatibility	Mac OS, Windows 10, Windows 7, Windows 8, Vista
Power Source	Battery Powered (2*AA batteries required, not included)
Product Dimensions	12 x 8 x 4 cm
Item Model Number	CANDY
ASIN	B08WHKWP49
Date First Available	23 September 2021

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the product packaging or contact Muvit customer service through their official website or the retailer where the product was purchased. Please have your product model number (CANDY) and ASIN (B08WHKWP49) ready when contacting support.

Related Documents - CANDY

	<p>Manuale d'Uso e Manutenzione Lavastoviglie Candy</p> <p>Guida completa per l'utilizzo sicuro ed efficiente della tua lavastoviglie Candy. Include istruzioni su installazione, programmi, manutenzione e risoluzione problemi.</p>
	<p>Candy Oven User Manual: Comprehensive Guide to Operation and Maintenance</p> <p>Official user manual for Candy ovens, providing detailed instructions on safety, installation, operation, cleaning, maintenance, and troubleshooting. Available in English, French, German, and Dutch.</p>
	<p>Candy VC.CANDY 21 SK Hob User Manual and Installation Guide</p> <p>Comprehensive user manual and installation guide for the Candy VC.CANDY 21 SK hob, providing detailed instructions on safety, operation, cleaning, and troubleshooting.</p>
	<p>Candy Перална Машина: Пълно Ръководство за Безопасна и Ефективна Употреба</p> <p>Открийте как да използвате вашата нова Candy перална машина безопасно и ефективно с това изчерпателно ръководство. Включва инструкции за инсталация, поддръжка, програми и съвети за пестене на енергия и вода.</p>
	<p>Candy Washer Dryer User Manual: Installation, Operation, and Maintenance</p> <p>Comprehensive user manual for Candy washer dryers, covering installation, safety guidelines, practical tips, maintenance, and troubleshooting. Learn how to use your Candy appliance efficiently and safely.</p>



REFRIGERATOR
User Manual

CANDY CHASD4385EWC	1
CANDY CHASD4385EBC	1
1. Introduction	2
2. Safety	3
3. Installation	4
4. Operation	5
5. Maintenance	6
6. Troubleshooting	7
7. Appendix	8

* Please read this manual carefully before using refrigerator.
* Thank you for your purchase.

[Candy CHASD4385EWC/EBC Refrigerator User Manual](#)

Comprehensive user manual for Candy CHASD4385EWC and CHASD4385EBC refrigerators, covering installation, operation, maintenance, safety, and troubleshooting. Learn how to use your Candy refrigerator efficiently and safely.